


Installation

Industrial Generator Sets



Models:

10–3250 kW

KOHLER®

Power Systems

ISO 9001
KOHLER
POWER SYSTEMS
NATIONALLY REGISTERED

TP-5700 12/16t

California Proposition 65

WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

California Proposition 65

WARNING

This product contains and/or emits chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

California Proposition 65

WARNING

Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with exhaust system.
- Do not idle the engine except as necessary.

For more information go to
www.P65warnings.ca.gov/diesel

Product Identification Information

Product identification numbers determine service parts. Record the product identification numbers in the spaces below immediately after unpacking the products so that the numbers are readily available for future reference. Record field-installed kit numbers after installing the kits.

Generator Set Identification Numbers

Record the product identification numbers from the generator set nameplate(s).

Model Designation _____

Specification Number _____

Serial Number _____

Accessory Number	Accessory Description
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

Controller Identification

Record the controller description from the generator set operation manual, spec sheet, or sales invoice.

Controller Description _____

Engine Identification

Record the product identification information from the engine nameplate.

Manufacturer _____

Model Designation _____

Serial Number _____

Table of Contents

Product Identification Information	2
Safety Precautions and Instructions	7
Introduction	13
Abbreviations	13
List of Related Materials	13
Service Assistance	14
Section 1 General	15
Section 2 Loading and Transporting	17
2.1 Lifting	17
2.1.1 General Precautions	17
2.1.2 Weight and Center of Gravity	17
2.1.3 Lifting the Generator Set	18
2.1.4 Lifting the Subbase Fuel Tank	19
2.1.5 Lifting the Generator Set with Attached Enclosure	20
2.1.6 Lifting the Generator Set, Enclosure, and Subbase Fuel Tank Assembly	21
2.1.7 Lifting Single Point Lift Assemblies	22
2.2 Generator Set Transporting	22
Section 3 Location	23
3.1 Location Factors	23
3.2 Mounting Surface	24
3.2.1 Single-Pad Mounting	24
3.2.2 Dual-Pad Mounting	24
3.2.3 Four-Pad Mounting	24
3.2.4 Mounting Pad Specifications	24
3.3 IBC Seismic Installation	25
3.4 Vibration Isolation	25
3.5 Dual-Bearing Alternator Alignment	27
Section 4 Air and Cooling	29
4.1 General	29
4.2 Air-Cooled Engines	29
4.3 Liquid-Cooled Engines	29
4.3.1 System Features	29
4.3.2 Installation Considerations	29
4.3.3 Recommended Coolant	30
4.4 Unit-Mounted Radiator Cooling	30
4.4.1 System Features	30
4.4.2 Installation Considerations	31
4.5 Remote Radiator Cooling	31
4.5.1 General	32
4.5.2 Vent Lines	33
4.5.3 Fill Lines (Balance or Static)	35
4.5.4 Location Considerations	35
4.5.5 Installation Considerations	35
4.5.6 Surge (Expansion) Tank for Horizontal Discharge Radiator	36
4.5.7 Procedure to Fill with Deaeration	37
4.5.8 Procedure to Fill without Deaeration	37
4.5.9 Checks after Initial Startup	37
4.6 City Water Cooling	38
4.6.1 System Features	38
4.6.2 Installation Considerations	38
4.7 Cooling Tower	39
4.8 Block Heaters	39

Table of Contents, continued

Section 5 Exhaust System	41
5.1 Flexible Exhaust Line	41
5.2 Condensation Trap	41
5.3 Piping	42
5.4 Double-Sleeved Thimbles	42
5.5 Exhaust Outlet	43
5.6 Exhaust System Backpressure	43
Section 6 Fuel Systems	51
6.1 Diesel Fuel Systems	51
6.1.1 Main Tank	51
6.1.2 Day Tanks	53
6.1.3 Fuel Lines	54
6.1.4 Auxiliary Fuel Pumps	54
6.2 Gas Fuel Systems, Common Components	55
6.2.1 Gas Lines	55
6.2.2 Gas Regulators	55
6.3 LP Fuel Systems	56
6.3.1 LP Gas Vapor-Withdrawal Systems	56
6.3.2 LP Gas Liquid-Withdrawal Systems	57
6.4 Natural Gas Systems	57
6.5 Combination Systems	58
6.5.1 Combination Natural Gas and LP Gas	58
6.6 Pipe Size Requirements for Gas Fuel Systems	59
Section 7 Electrical System	61
7.1 Generator Set Voltage Reconnection	61
7.2 Electrical Connections	62
7.3 Load Lead Connections	62
7.4 Grounding and Grounded Conductor (Neutral) Connections	63
7.5 Terminal Connector Torque	64
7.6 Batteries	65
7.7 Battery Chargers	65
7.7 Component and Accessory Power Source Requirements	66
7.9 Optional Accessories	66
7.9.1 Bus Bar Kits/Bus Lugs	67
7.9.2 Gas Fuel Valve Kit	67
7.9.3 Line Circuit Breaker	67
7.9.4 Run Relay Kit	67
7.9.5 Wireless Monitor	68
7.10 Wiring Connections	68
Section 8 Decision-Maker® 550 Controller Accessories	71
8.1 Accessories and Connections	71
8.1.1 Audiovisual Alarm Kit	71
8.1.2 Common Failure Relay Kit	72
8.1.3 Controller (Customer) Connection Kit	72
8.1.4 Float/Equalize Battery Charger Kit with Alarm Option	72
8.1.5 Ground Fault Annunciation	74
8.1.6 Idle (Speed) Mode Feature	75
8.1.7 Low Fuel (Level/Pressure) Switch	76
8.1.8 Prime Power Switch Kit	76
8.1.9 Remote Emergency Stop Kit	77
8.1.10 Remote Reset Feature	77
8.1.11 Remote Serial Annunciator (RSA III)	78
8.1.12 Shunt-Trip Line Circuit Breaker	80
8.1.13 Single-Relay Dry Contact Kit	80

Table of Contents, continued

8.1.14	Ten-Relay Dry Contact Kit	81
8.1.15	Twenty-Relay Dry Contact Kit	82
8.2	Accessory Connections	83
Section 9	Decision-Maker® 3000 Controller Accessories	87
9.1	Accessories and Connections	87
9.1.1	Common Fault/Failure (32A) Relay	87
9.1.2	Float/Equalize Battery Charger Kit with Alarm Option	88
9.1.3	Input/Output (I/O) Module Board	88
9.1.4	Low Fuel (Level/Pressure) Switch	89
9.1.5	Prime Power Switch Kit	89
9.1.6	Remote Emergency Stop Kit	90
9.1.7	Remote Reset Feature	90
9.1.8	Remote Serial Annunciator (RSA III)	91
9.1.9	Shunt-Trip Line Circuit Breaker	93
9.2	Accessory Connections	93
Section 10	Decision-Maker® 3500 Controller Accessories	97
10.1	Accessories and Connections	97
10.1.1	Fifteen-Relay Dry Contact	97
10.1.2	Remote Emergency Stop Kit	98
10.1.3	Remote Serial Annunciator (RSA III)	99
10.2	Accessory Connections	101
Section 11	Decision-Maker® 6000 Controller Accessories	103
11.1	Accessories and Connections	103
11.1.1	Audiovisual Alarm Kit	103
11.1.2	Common Failure Relay Kit	104
11.1.3	Float/Equalize Battery Charger Kit with Alarm Option	104
11.1.4	Ground Fault Annunciation	105
11.1.5	Idle (Speed) Mode Feature	106
11.1.6	Low Fuel (Level/Pressure) Switch	106
11.1.7	Prime Power Switch Kit	107
11.1.8	Remote Emergency Stop Kit	107
11.1.9	Remote Reset Feature	108
11.1.10	Remote Serial Annunciator (RSA III)	108
11.1.11	Shunt-Trip Line Circuit Breaker	110
11.1.12	Single-Relay Dry Contact Kit	111
11.1.13	Ten-Relay Dry Contact Kit	111
11.1.14	Twenty-Relay Dry Contact Kit	113
11.2	Accessory Connections	114
Section 12	Remote Adjustment/Control Systems	117
12.1	Automatic Transfer Switches	117
12.2	Decision-Maker® 550 Controller, Voltage Regulator and Paralleling Applications	118
12.3	Decision-Maker® 3000 Controller Voltage Regulator	118
12.4	Decision-Maker® 3500 Controller Voltage Regulator	118
12.5	Decision-Maker® 6000 Controller Voltage Regulator and Paralleling Applications	118
12.6	Decision-Maker® 8000 Controller Voltage Regulator and Paralleling Applications	118
12.7	Remote Speed Adjustment	118
12.8	Remote Voltage Adjustment	119
12.9	Remote Wiring	121
12.10	Voltage Regulator DVR 2000/ Remote Voltage Regulator Kit, 350 kW and Above	121

Table of Contents, continued

Appendix A Abbreviations	123
Appendix B Common Hardware Application Guidelines	125
Appendix C General Torque Specifications	126
Appendix D Fuel Physical Properties	127
Appendix E Gas Fuel Vapor Pressures	128
Appendix F Gas Fuel System Installation Planning	129

Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

CAUTION


Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

 WARNING

Accidental starting. Can cause severe injury or death. Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

(Decision-Maker® 3+ and 550 Controllers)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(Decision-Maker® 3000, 3500, and 6000 Controllers)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) If the controller is not already in the MAN (manual) mode, press the Controller Mode button and then press the MAN mode button. (2) If the generator set is running, press and hold the Manual-Stop button for at least 2 seconds to stop the generator set. (3) Press the Controller Mode button and then press the controller Off mode button. (4) Disconnect the power to the battery charger, if equipped. (5) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(Decision-Maker® 8000 Controller)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Shut down the generator set. (2) Place the controller in Out of Service mode. (3) Press the emergency stop button. (4) Disconnect the power to the battery charger, if equipped. (5) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(APM802 Controller)

Battery

⚠ WARNING

Sulfuric acid in batteries. Can cause severe injury or death. Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

⚠ WARNING

Explosion. Can cause severe injury or death. Relays in the battery charger cause arcs or sparks. Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire

⚠ WARNING

Risk of fire. Can cause severe injury or death. Do not smoke or permit flames or sparks near fuels or the fuel system.

Servicing the fuel system. A flash fire can cause severe injury or death. Do not smoke or permit flames or sparks near the fuel mixer, fuel line, fuel filter, or other potential sources of fuel vapors. When removing the fuel line or fuel system be aware that liquid propane can cause frostbite on contact.
(Gas-fueled Model)

Servicing the fuel system. A flash fire can cause severe injury or death. Do not smoke or permit flames or sparks near the fuel injection system, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or fuel system.
(Diesel-fueled Model)

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

Exhaust System


WARNING Carbon monoxide. Can cause severe nausea, fainting, or death. The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building unless the exhaust gas is piped safely outside. Never operate the generator set where exhaust gas could accumulate and seep back inside a potentially occupied building.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea

If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Fuel System


WARNING Explosive fuel vapors. Can cause severe injury or death. Use extreme care when handling, storing, and using fuels.


WARNING Avoid high pressure fluids. Can cause severe injury or death. Do not work on high pressure fuel or hydraulic systems without protective equipment to protect hands, eyes, and body. Avoid the hazard by relieving pressure before disconnecting fuel injection pressure lines. Search for leaks using a piece of cardboard. Always protect hands, eyes, and body from high pressure fluids. If an accident occurs, seek medical attention immediately.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Explosive fuel vapors can cause severe injury or death. Take additional precautions when using the following fuels:

Gasoline—Store gasoline only in approved red containers clearly marked GASOLINE.

Propane (LPG)—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

Natural Gas—Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

Fuel tanks. Explosive fuel vapors can cause severe injury or death. Gasoline and other volatile fuels stored in day tanks or subbase fuel tanks can cause an explosion. Store only diesel fuel in tanks.

Draining the fuel system. Explosive fuel vapors can cause severe injury or death. Spilled fuel can cause an explosion. Use a container to catch fuel when draining the fuel system. Wipe up spilled fuel after draining the system.

Gas fuel leaks. Explosive fuel vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LPG vapor or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6–8 ounces per square inch (10–14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

LPG liquid withdrawal fuel leaks. Explosive fuel vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LPG liquid withdrawal fuel system for leakage by using a soap and water solution with the fuel system test pressurized to at least 90 psi (621 kPa). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Hazardous Noise

⚠ CAUTION

Hazardous noise. Can cause hearing loss. Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ Moving Parts

⚠ DANGER

Hazardous voltage. Will cause severe injury or death. Disconnect all power sources before opening the enclosure.

⚠ WARNING
 
Hazardous voltage. Moving parts. Can cause severe injury or death. Operate the generator set only when all guards and electrical enclosures are in place.

⚠ WARNING

Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death. If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

⚠ CAUTION

Welding the generator set. Can cause severe electrical equipment damage. Never weld components of the generator set without first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Welding on the generator set. Can cause severe electrical equipment damage. Before welding on the generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine battery-charging alternator connections. (5) Attach the weld ground connection close to the weld location.

Installing the battery charger. Hazardous voltage can cause severe injury or death. An ungrounded battery charger may cause electrical shock. Connect the battery charger enclosure to the ground of a permanent wiring system. As an alternative, install an equipment grounding conductor with circuit conductors and connect it to the equipment grounding terminal or the lead on the battery charger. Install the battery charger as prescribed in the equipment manual. Install the battery charger in compliance with local codes and ordinances.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Engine block heater. Hazardous voltage can cause severe injury or death. The engine block heater can cause electrical shock. Remove the engine block heater plug from the electrical outlet before working on the block heater electrical connections.


Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically. *(600 volts and under)*

Heavy Equipment

⚠ WARNING

Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage. Do not use lifting eyes. Lift the generator set using lifting bars inserted through the lifting holes on the skid.

⚠ WARNING

Unbalanced and elevated weight. Improper lifting can cause severe injury or death and equipment damage. Do not lift the generator set from the engine or alternator eyes. Never stand under a unit being lifted. Always maintain a safe distance from the unit being lifted. See the lifting instructions in the installation manual that was provided with the unit.

Hot Parts

⚠ WARNING

Hot coolant and steam. Can cause severe injury or death. Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure.

⚠ WARNING

Hot engine and exhaust system. Can cause severe injury or death. Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Servicing the engine heater. Hot parts can cause minor personal injury or property damage. Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

Notice

NOTICE
This generator set has been rewired from its nameplate voltage to 246242

NOTICE

Voltage reconnection. Affix a notice to the generator set after reconnecting the set to a voltage different from the voltage on the nameplate. Order voltage reconnection decal 246242 from an authorized service distributor/dealer.

NOTICE

Parallel Operation. This product includes features intended to support operation in parallel with the utility grid, but these features have not been evaluated for compliance with specific utility interconnection protection standards or requirements.

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

Notes

This manual provides installation instructions for industrial generator sets. Operation manuals and wiring diagram manuals are available separately.

Some additional model-specific installation information may be included in the respective generator set controller operation manual.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

Abbreviations

This publication makes use of numerous abbreviations. Typically, the word(s) are spelled out along with the abbreviation in parentheses when shown for the first time in a section. Appendix A, Abbreviations, also includes many abbreviation definitions.

List of Related Materials

Separate literature contains, communication, firmware, and other additional information not provided in this manual. Figure 1 lists the available literature part numbers.

Manual Description	Literature Part No.
Generator Set/Controller Wiring Diagram Manual	Multiple Part Numbers Contact your Distributor/Dealer
Monitor III Converters, Connections, and Controller Setup	TT-1405
Monitor III Software Spec Sheet	G6-76
Monitor III Converter, Modbus®/Ethernet Spec Sheet	G6-79
Monitor III Software Operation Manual	TP-6347
Modbus® Communications Protocol Operation Manual	TP-6113
Program Loader Software Installation	TT-1285
SiteTech™ Software Operation Manual	TP-6701
Remote Serial Annunciator (RSA)	TT-1625
Decision-Maker® Paralleling System (DPS) Spec Sheet	G6-110
Decision-Maker® Paralleling System (DPS) Operation Manual	TP-6747
Battery Charger, 10 amp float/equalize	TT-680
Battery Charger, 6 amp float/equalize	TT-1342
Battery Charger, ESCR II	TP-7025
500-1000REZK Engine Installation Manual	TP-6995
1000REZCK Engine Installation Manual	TP-7022
1300REZCK Engine Installation Manual	TP-7023
Decision-Maker® 8000 Operation Manual	TP-6990
KD Model Operation Manual	TP-7070

Figure 1 Related Literature

Service Assistance

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KOHLERPower.com.
- Look at the labels and decals on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems Netherlands B.V.
Kristallaan 1
4761 ZC Zevenbergen
The Netherlands
Phone: (31) 168 331630
Fax: (31) 168 331631

Asia Pacific

Power Systems Asia Pacific Regional Office
Singapore, Republic of Singapore
Phone: (65) 6264-6422
Fax: (65) 6264-6455

China

North China Regional Office, Beijing
Phone: (86) 10 6518 7950
(86) 10 6518 7951
(86) 10 6518 7952
Fax: (86) 10 6518 7955

East China Regional Office, Shanghai
Phone: (86) 21 6288 0500
Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office
Bangalore, India
Phone: (91) 80 3366208
(91) 80 3366231
Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office
Tokyo, Japan
Phone: (813) 3440-4515
Fax: (813) 3440-2727

Industrial power systems give years of dependable service if installed using the guidelines provided in this manual and in applicable codes. Incorrect installation can cause continuing problems. Figure 1-1 illustrates a typical installation.

Your authorized generator set distributor/dealer may also provide advice about or assistance with your installation.




Figure 1-1 Typical Stationary-Duty Generator Set Installation

This manual references several organizations and their codes that provide installation requirements and guidelines such as the National Fire Protection Association (NFPA) and Underwriter's Laboratories Inc. (UL).

- NFPA 54 National Fuel Gas Code
- NFPA 70 National Electrical Code®; the National Electrical Code is a registered trademark of the NFPA
- NFPA 99 Standard for Health Care Facilities
- NFPA 101 Life Safety Code
- NFPA 110 Emergency and Standby Power Systems
- UL 486A–486B Wire Connectors
- UL 486E Equipment Wiring Terminals for Use with Aluminum and/or Copper Conductors
- UL 2200 Stationary Engine Generator Assemblies

These organizations provide information specifically for US installations. Installers must comply with all applicable national and local codes.

Before beginning generator set installation, record the following data from the generator set's specification sheet and keep this data accessible for reference during installation:


- Dimensions and weight (verify dimensions and weight using the submittal data)
- Exhaust outlet size and maximum allowable backpressure
- Battery CCA rating and quantity
- Fuel supply line size and fuel pressure requirement (gas models)
- Air requirements

Section 2 Loading and Transporting

The loading and transporting processes expose the generator set to many stresses and the possibility of improper handling. Therefore, after transporting industrial generator sets:

- Check the alignment of the radiator and supports to ensure that the radiator is evenly spaced from the generator and that supports are square and of even length. Check the radiator fan for uniform alignment and equal clearance within the radiator shroud. Adjust if necessary.
- After confirming the correct alignment, tighten the hardware to its specified torque. Reference Appendix C, General Torque Specifications.

2.1 Lifting

⚠ WARNING

Unbalanced and elevated weight. Improper lifting can cause severe injury or death and equipment damage.
Do not lift the generator set from the engine or alternator eyes. Never stand under a unit being lifted. Always maintain a safe distance from the unit being lifted. See the lifting instructions in the installation manual that was provided with the unit.

2.1.1 General Precautions

Follow these general precautions when lifting all generator sets and related equipment.

- Install proper size rigging at the skid lifting eyes providing a direct pull on the skid lifting eye. Make sure the rigging does not work as a pry bar lever against the lifting eye.
- Do not lift the generator set using the lifting eyes attached to the engine and/or alternator as these lifting eyes can not support the total weight of the generator set.
- Always protect cables, chains, and straps from sharp edges.




Figure 2-1 Improper Lifting Hook Placement (above 1000 kW)

- Generator sets typically above 1000 kW may have reinforcing plates on the skid. Do not attach lifting hooks to the reinforcing plate. See Figure 2-1.
- Lifting should only be conducted by those trained and experienced in lifting and rigging to achieve a safe and effective lift. Consideration needs to be given to, but not necessarily limited to, the following items:
 - Weight and center of gravity of the equipment being lifted
 - Weight and center of gravity of the lifting device
 - Boom angles
 - Selection of rated rigging
 - Stability of lifting foundation
 - Wind and weather conditions
 - Local or regional codes that may require or restrict types of rigging.
- Use a spreader bar to prevent lifting cables from contacting air cleaners, shrouds, and other protruding components. If the cables still do not clear these components, remove the components.

2.1.2 Weight and Center of Gravity

Refer to the respective specification sheet and/or the submittal drawing for the weight and center of gravity of all components being lifted. The total combined weight and center of gravity must be known to select the proper rigging. If the weight and center of gravity is not readily available, contact your distributor/dealer.

As applicable, determine the weight and center of gravity of the following components:

- Generator set
- Enclosure system (includes silencer, inlet baffles, louvers, etc.)
- Subbase fuel tank (lift only empty fuel tanks).

2.1.3 Lifting the Generator Set

The distributor/lifting contractor should choose one of the following methods to lift the generator set depending upon the location circumstances and the generator set's weight and size. Remove cover plates as needed to access the generator set skid lifting eyes.

Single Spreader Bar and Hook Method

Refer to Figure 2-2.

Double Spreader Bar and Hook Method

Refer to Figure 2-3.

Single Spreader Bar and Skid Lifting Bar Method

Refer to Figure 2-4.

Double Spreader Bar and Skid Lifting Bar Method

Refer to Figure 2-5.




Figure 2-2 Single Spreader Bar and Hook Method




Figure 2-3 Double Spreader Bar and Hook Method




Figure 2-4 Single Spreader Bar and Skid Lifting Bar Method




Figure 2-5 Double Spread Bar and Skid Lifting Bar Method

2.1.4 Lifting the Subbase Fuel Tank

This section deals with lifting the subbase fuel tank as a single unit.

- The subbase fuel tank *must* have lifting eyes in order to use the following methods.
- The subbase fuel tank must be empty. Do not lift a fuel tank containing fuel (or any liquid).
- Remove any vent piping longer than 1 m (3.3 ft.) from the fuel tank. Do not lift a fuel tank with attached vent piping longer than 1 m (3.3 ft.).
- Attach one or two spreader bars as shown.

Fuel Tank with Single Spread Bar Method

Refer to Figure 2-6.

Fuel Tank with Double Spread Bar Method

Refer to Figure 2-7.




Figure 2-6 Fuel Tank with Single Spread Bar Method




Figure 2-7 Fuel Tank with Double Spread Bar Method

2.1.5 Lifting the Generator Set with Attached Enclosure

Enclosure Attached Directly to the Generator Set Skid

Refer to Figure 2-8. Lift the assembly by lifting on the skid as shown in 2.1.3 Lifting Methods for Generator Set.

Do not attach hoisting equipment to the enclosure.




Figure 2-8 Typical Enclosure Attached Directly to the Generator Set Skid

Enclosure Attached Directly to the Subbase Fuel Tank

Refer to Figure 2-9. Lift the assembly by lifting on the subbase fuel tank lifting eyes. Lift using all of the lifting eyes provided on the subbase fuel tank. Select the procedure from the following illustrations based on the matching number of available subbase fuel tank lifting eyes.

Do not attach hoisting equipment to the enclosure.

Enclosure Attached to the Enclosure Base and Assembled to the Subbase Fuel Tank

Refer to Figure 2-10.

With the subbase fuel tank detached from the enclosure base, lift only the enclosure and generator set using the enclosure base lifting eyes. Lift using all of the lifting eyes provided on the enclosure base. Select the procedure from the following illustrations based on the matching number of available enclosure base lifting eyes.




Figure 2-9 Typical Enclosure Attached Directly to the Subbase Fuel Tank

Lift the entire enclosure, generator set, and subbase fuel tank assembly by lifting on the subbase fuel tank lifting eyes. Lift using all of the lifting eyes provided on the subbase fuel tank. Select the procedure from the following illustrations based on the matching number of available subbase fuel tank lifting eyes. Do not attach hoisting equipment to the enclosure base.




Figure 2-10 Typical Enclosure Attached to the Enclosure Base and Assembled to the Subbase Fuel Tank

2.1.6 Lifting the Generator Set, Enclosure, and Subbase Fuel Tank Assembly

When using the subbase fuel tank to lift the generator set and/or enclosure as a package, use ALL of the lifting eyes on the subbase fuel tank.

Hoisting using Four Eye Lifting Method

Apply the same lifting methods using single or double spreader bars as shown in 2.1.3 Lifting the Generator Set.

Hoisting using Six Eye Lifting Method

Apply one spreader bar and two chain falls (Figure 2-11) or three spreader bars and two chain falls (Figure 2-12) for six eye lifting.

- Install a pair of outer slings to the maximum angle as shown in Figure 2-11 and Figure 2-12.
- Remove the slack from the slings in the system but do not lift the unit.
- Install adjustable chain falls and strap or cable them from the spreader bar to the middle lifting eyes. Adjust to remove the slack.
- Check and remove any slack that has developed in the primary slings and check that all chains/straps/cables are carrying load.




Figure 2-11 Six Eyes, Single Spreader Bar, and Two Chain Falls Lifting Method




Figure 2-12 Six Eyes, Three Spreader Bars, and Two Chain Falls Lifting Method

Hoisting using Eight Eye Lifting Method

Apply two spreader bars and four chain falls (Figure 2-13) for eight eye lifting.

- Install a pair of outer slings up to the maximum angle as shown in Figure 2-13.
- Remove the slack from the slings in the system but do not lift the unit.
- Install adjustable chain falls and strap or cable them from the spreader bar to the middle lifting eyes. Adjust to remove the slack.
- Check and remove any slack that has developed in the primary slings and check that all chains/straps/cables are carrying load.




Figure 2-13 Eight Eyes, Two Spreader Bars, and Four Chain Falls Lifting Method

Hoisting using Ten Eye Lifting Method

Apply three spreader bars and six chain falls (Figure 2-14) for ten eye lifting.

- Install a pair of outer slings up to the maximum angle as shown in Figure 2-14.
- Remove the slack from the slings in the system but do not lift the unit.
- Install adjustable chain falls and strap or cable them from the spreader bar to the middle lifting eyes. Adjust to remove the slack.
- Check and remove any slack that has developed in the primary slings and check that all chains/straps/cables are carrying load.




Figure 2-14 Ten Eyes, Three Spreader Bars, and Six Chain Falls Lifting Method

Hoisting using Twelve Eye Lifting Method

Apply three spreader bars and eight chain falls (Figure 2-15) for twelve eye lifting.

- Install a pair of outer slings up to the maximum angle as shown in Figure 2-15.
- Remove the slack from the slings in the system but do not lift the unit.
- Install adjustable chain falls and strap or cable them from the spreader bar to the middle lifting eyes. Adjust to remove the slack.
- Check and remove any slack that has developed in the primary slings and check that all chains/straps/cables are carrying load.

2.1.7 Lifting Single Point Lift Assemblies

Some units have an enclosure integral to the skid and attach a single point lifting eye located at the top and center of the enclosure. The entire assembly may be lifted with this eye.




Figure 2-15 Twelve Eyes, Three Spreader Bars, and Eight Chain Falls Lifting Method

2.2 Generator Set Transporting

Follow these guidelines when transporting the generator set:

- Select the transporting vehicle/trailer based on the dimensions and weight of the generator set as specified in the generator set dimension drawing or specification sheet. Ensure that the gross weight and overall height of the generator set and vehicle/trailer in transport does not exceed applicable transportation codes.
- Use low boy-type trailers that meet clearance requirements when transporting units larger than 1000 kW. Load large (unboxed) radiator-equipped generator sets with the radiator facing the rear to reduce wind resistance during transit. Secure fans to prevent fan rotation in transit.
- Securely fasten the generator set to the vehicle/trailer. Even the heaviest of generator sets can move during shipment unless they are secured. Fasten the generator set to the vehicle/trailer bed with a correctly sized chain routed through the mounting holes of the generator set skid (or tank, if equipped). Use chain tighteners to remove slack from the mounting chain. Do not use strapping over the top of an enclosed generator set as damage to the enclosure may occur.
- Always cover a non-enclosed unit with a heavy-duty canvas or tarpaulin secured to the generator set or trailer.

3.1 Location Factors

Ideally, the generator set should be mounted on concrete at ground level. For above-ground installations, including roof installations, weight considerations are especially important. The building engineer determines whether the structure can support the weight of the generator set.

The location of the generator set must meet the following criteria.

General:

- Mounting surface is square and horizontally level at all four edges.
- Support the weight of the generator set and related equipment such as fuel storage tanks, batteries, radiators, and mounting pad(s). Keep in mind that the mounting pad weight may exceed the weight of the generator set.
- Mounting pad should be designed to prevent the vibration of a running unit from causing mounting pad distortion and affecting engine/alternator alignment.
- Meet applicable fire rating codes and standards.
- Install the unit so that the risk of contact by people with the hot generator set surfaces is minimized.
- Position the generator set over a noncombustible surface. If the mounting surface directly under or near the generator set is porous or deteriorates from exposure to engine fluids, construct a containment pan for spilled fuel, oil, coolant, and battery electrolyte. Do not allow accumulation of combustible materials under the generator set.
- Permit vibration isolation and dampening to reduce noise and prevent damage.
- Be clean, dry, and not subject to flooding.
- Provide easy access for service and repair.

Indoor Installations:

- Allow adequate ventilation with a minimum amount of ductwork.
- Allow safe expulsion of exhaust.

- Allow for storage of sufficient fuel to sustain emergency operation. See the generator set specification sheet for fuel consumption.
- Allow for locating the fuel tank within the vertical lift capabilities of the fuel pump and any auxiliary pumps. See Section 6, Fuel Systems.
- Minimize the risk of public or unauthorized access.
- Provide adequate protection to prevent injury in the stub-up area. If the stub-up area opening is exposed, provide a cover or fill in the area to avoid the risk of tripping or falling into the stub-up opening.

Outdoor Installations:

- Select a location that provides adequate air flow. Avoid locations next to tall buildings that block normal air flow and cause air vacuum pockets. Avoid areas that are subject to high winds, excessive dust, or other airborne contaminants. High dust areas may require more frequent air cleaner maintenance. High temperature conditions affect generator set efficiency. Select a shaded area away from direct sunlight and/or other heat-producing equipment when practical.
- Avoid areas with combustible materials, including but not limited to building materials as well as natural surroundings. Keep dry field grass, foliage, and combustible landscaping materials a safe distance from the exhaust system.
- The subsoil location must have a bearing strength capable of supporting the generator set and mounting pad combined weight. Analysis by a qualified technician or engineer is recommended to determine the proper excavation material required.
- If the generator set enclosure is mounted on multiple pads where it is elevated above the main surface it may cause discharge air recirculation underneath the unit. A typical location could be a building roof where the main surface is uneven for a single pad. Refer to 4.3.2 Installation Considerations for information to minimize discharge air recirculation.
- Select a location that provides adequate space to access and service the unit. Allow for adequate clearance to open and close access doors. Avoid locations on a hill or steep embankment unless provision is made to include a servicing platform.

3.2 Mounting Surface

Figure 3-1 shows typical mounting surface details for sizing the concrete surface beyond the generator set and allowing for clearances during generator set service. Follow the dimensional details provided in Figure 3-2, Figure 3-3, or Figure 3-4 depending upon the mounting method.




Figure 3-1 Mounting Surface Detail (top view)

3.2.1 Single-Pad Mounting

The manufacturer recommends a single, level concrete mounting pad as shown in Figure 3-2. This method provides maximum stability for the generator set; however, draining the oil and servicing the generator set may require raising the set from the pad.

Use an oil drain pump if clearance below the oil drain or extension is insufficient for a pan large enough to hold all the engine's oil.




Figure 3-2 Single-Pad Mounting

3.2.2 Dual-Pad Mounting

The two-pad arrangement shown in Figure 3-3 provides easy access to conveniently drain the oil. Follow the oil draining considerations outlined in Section 3.2.1.




Figure 3-3 Dual-Pad Mounting

3.2.3 Four-Pad Mounting

The four-pad arrangement shown in Figure 3-4 provides more room under the engine for service than the previous two methods. Follow the oil draining considerations outlined in Section 3.2.1.




Figure 3-4 Four-Pad Mounting

3.2.4 Mounting Pad Specifications

Mounting pad weight. The weight of the single mounting pad or combined weight of multiple mounting pads should equal or exceed the combined weight of the generator set and attached accessories.

To determine the weight of the mounting pad(s), determine the volume (length x width x height) of each pad in cubic meters (cubic feet). Multiply this result by 2400 kg (150 lb.) to determine a pad's weight. In multiple-pad installations, add the weights of all pads to determine the total mounting pad weight.

Mounting pad specifications. Mounting pad composition should follow standard practice for the required loading. Typical specifications call for 17238–20685 kPa (2500–3000 psi) concrete reinforced with eight-gauge wire mesh or No. 6 reinforcing bars on 305 mm (12 in.) centers. The top surface of the mounting pad on which the generator set mounts should be within a flatness of 3 mm (1/8 in.).

The recommended concrete mixture by volume is 1:2:3 parts of cement, sand, and aggregate, respectively. Surround the pad with a 200–250 mm (8–10 in.) layer of sand or gravel for proper support and isolation of a pad located at or below grade.

Anchor the generator set to the concrete using bolts cast into the surface of the pad. Otherwise, drill holes in the mounting pad prior to generator set placement and use expansion anchor bolts. Anchor the generator set skid or fuel tank (if equipped) using all of the provided anchor holes on the bottom of the skid.

Note: Refer to the generator set and accessory dimension drawings for conduit and fuel-line placement. The drawings give dimensions for electrical and fuel connection roughins and stubups including model specific clearances.

3.3 IBC Seismic Installation

International Building Code (IBC) seismic installations involve additional mounting and installation considerations. Refer to respective seismic installation ADV drawing(s) for seismic isolator requirements.

3.4 Vibration Isolation

Use one of the vibration isolation types detailed in the following paragraphs. Also, connections between the generator set or its skid and any conduits, fuel lines, or exhaust piping must include flexible sections to prevent breakage and to isolate vibration. These connections are detailed in subsequent sections.

Isolator types. The two primary types of isolators are neoprene and spring-type. Figure 3-5 shows neoprene isolators between the engine-generator and the skid, referred to as integral vibration isolation mounting. Integral vibration isolation units come from the factory with neoprene vibration isolation. Neoprene isolators provide 90% vibration isolation efficiency and are often sufficient for installations at or below grade.




Figure 3-5 Neoprene-Type Integral Vibration Isolators

Figure 3-6 through Figure 3-10 shows the spring-type isolator kit installed *with* direct-mounted units. Direct-mounted units have no factory vibration isolation. Spring-type isolators provide 98% vibration efficiency and are recommended for above grade installations and other locations where vibration sensitivity could be an issue.

Generator sets with integral vibration isolation. Skids for generator sets 20 kW and larger use I or C section-fabricated steel with a width of 52–76 mm (2–3 in.) per channel. The length varies with the size of the unit, resulting in a static load on the generator set skid of 69–172 kPa (10–25 psi) if the total bottom surface of the channel is in contact with the mounting pad.




Figure 3-6 Vibration Isolators GM39515 and GM41122




Figure 3-7 Vibration Isolators GM66019, GM66304, and GM76149




Figure 3-9 Vibration Isolator GM66025




Figure 3-8 Vibration Isolators GM66020, GM66022, GM66023, GM66024, and GM66313




Figure 3-10 Vibration Isolator GM84038

Generator sets with direct mounting. Larger generator sets typically mount directly to a structural steel base. For these units, install the recommended vibration isolators between the base and the mounting pad in the holes provided. Because of the reduced mounting surface area of these individual mounts, the static load on the mounting surface increases to the range of 345–690 kPa (50–100 psi).

Generator sets mounted on subbase fuel tanks. Do not install vibration spring isolators under the subbase fuel tank.

Dual isolation. For applications involving integral vibration isolators and where the factory does not offer spring-type isolators as a standard accessory, spring-type isolators may be installed under the skid provided

they equal the number of neoprene isolators, are inline front-to-back with the existing neoprene isolators, and additional support plates are installed, as required. See Figure 3-11.

3.5 Dual-Bearing Alternator Alignment

Generator sets equipped with dual-bearing alternators require alignment after mounting the generator set skid to a mounting pad. Refer to Service Bulletin SB-566 for details.

Note: Dual-bearing alternators used on REZCK model generator sets do not require alignment.




Figure 3-11 Accessory Vibration Mount Location

Notes

4.1 General

Combustion and heat dissipation require an ample flow of clean, cool air regardless of whether the generator set is air- or liquid-cooled. Approximately 70% of the heat value of fuel consumed by an engine is lost through the cooling and exhaust systems.

Battery compartment ventilation. To prevent the accumulation of explosive gases, ventilate compartments containing batteries.

4.2 Air-Cooled Engines

Refer to the generator set specification sheet for air requirements. Generally, airflow requirements do not present a problem since air-cooled models are designed for outside installation.

When planning outside installation, consider how buildings and landscaping affect airflow. Also consider seasonal changes such as snow or foliage accumulation and potential flooding conditions. Follow a regular maintenance routine to remove snow and foliage accumulations.

4.3 Liquid-Cooled Engines

4.3.1 System Features

Generator sets designed for interior installation feature liquid cooling systems. The three most common liquid cooling systems are unit-mounted radiator, remote radiator, and city-water cooling. Observe the common installation considerations outlined below as well as the installation considerations for your generator set's cooling system as detailed in subsequent sections.

4.3.2 Installation Considerations

Intake and outlet openings. Provide air intake and air outlet openings for generator sets located in a building or enclosure. Keep air inlets and outlets clean and unobstructed. Position the air inlet into the prevailing wind and the air outlet in the opposite direction.

Elevated outdoor installations. If the generator set enclosure is mounted on multiple pads, in cases where a single pad is not practical such as an uneven building roof, it may cause discharge air recirculation under the unit. Enclosures are constructed with the intent of single pad mounting where the unit is sealed to prevent discharge air recirculation. If multiple pad installation is unavoidable, use a single pad above the multiple pads

and fabricate flashing/skirting around the multiple pads to minimize unwanted discharge air recirculation.

Ventilating fans. Some buildings tend to restrict airflow and may cause generator set overheating. Use ventilating fans and/or ductwork to increase airflow in the building if the generator set's cooling fan does not provide adequate cooling. See Figure 4-1. Remote radiator and city-water cooled models require ventilating fans. When using ductwork and ventilating fans, check the exhaust fan capacity in m³/min. (cfm). If using exhaust fans, install fan-operated louvers with exhaust fans to regulate airflow. See Figure 4-2. Follow the fan manufacturer's recommendations to determine the size of the inlet and outlet openings.




Figure 4-1 Ventilating Fan




Figure 4-2 Exhaust Fan-Operated Louvers

Thermostatically-controlled louvers. Do not allow uncontrolled recirculation of air within an enclosure. The ventilation system must provide a temperature differential sufficient to prevent high engine temperature shutdown on even the hottest days.

In areas of great temperature variation, install movable louvers to thermostatically regulate airflow and room temperature. See Figure 4-3 and Figure 4-4. Refer to 4.4.2, Installation Considerations, Louver use for further information.




Figure 4-3 Stationary Air Inlet Louvers




Figure 4-4 Moveable Air Inlet Louvers

In cold climate interior installations using controlled recirculation to recover heat, install thermostatically activated louvers and fans to prevent the generator set and engine room from overheating.

Electric louvers are usually connected to the optional generator set run relay. Typically, the louvers are energized to open when the generator set is operating. However, some louvers are energized to close and when deenergized are spring-actuated to open when the generator set is operating.

Filters. Install a furnace-type or similar filter in the inlet opening if the generator set operates in an atmosphere highly contaminated with impurities such as dust and chaff.

Air restrictions. When using a filter, screen, or other air restriction, increase the inlet opening size by the following amounts to compensate for diminished airflow:

- Louvers: Enlarge the opening 50%.
- Window screening: Enlarge the opening 80%.
- Furnace-type filters: Enlarge the opening 120%.

Some engines have maximum air intake restrictions. Refer to the respective generator set specification sheet for specific requirements.

4.3.3 Recommended Coolant

All applications require antifreeze/coolant protection. Add antifreeze/coolant before starting the generator set or energizing the block heater(s). Most diesel engine manufacturers require the use of an inhibitor additive to the antifreeze/coolant.

Use a proper mixture of glycol (ethylene, propylene, or extended life organic acid), water, and supplemental coolant additive (SCA) based on the engine manufacturer's recommendations. The antifreeze/coolant and additive mixture reduces corrosion, sludge formation, and cavitation erosion and provides boil and freeze protection.

Refer to the engine manufacturer's operation manual for engine antifreeze/coolant specifications, concentration levels, and inhibitor selection recommendations.

4.4 Unit-Mounted Radiator Cooling

The unit-mounted radiator is the most common cooling system for engine-driven generator sets 20 kW and larger.

4.4.1 System Features

The system's major components include an engine-driven fan and circulating water pump, a radiator, and a thermostat. The pump circulates water through the engine until it reaches operating temperature. Then the engine thermostat opens, allowing water circulation through the radiator. The thermostat restricts water flow as necessary to prevent overcooling. The fan blows air from the engine side of the radiator across the cooling surface.

4.4.2 Installation Considerations

Figure 4-5 shows a typical unit-mounted radiator installation. Note the direction of airflow and refer to the figure as needed during installation.




Figure 4-5 Radiator-Cooled Generator Set Installation

Avoid suction fan use. The alternator airflow should move in the same direction as the engine's standard pusher fan. Using a suction fan to reverse airflow is not recommended because it may interfere with the alternator cooling airflow. This in turn reduces the maximum engine power available because higher temperature combustion air is drawn into the air cleaner.

Use ductwork to direct airflow. Direct the radiator air outside the room or enclosure using sheet metal ductwork with structural supports. Keep ductwork as short, straight, and unobstructed as possible. Combined static pressure restrictions greater than 0.12 kPa or 13 mm (0.5 in.) water column on the radiator inlet and outlet openings cause reduced airflow and contribute to overheating especially in high ambient air temperatures. Use heavy canvas, silicone rubber, or similar flexible material for the connection between the radiator duct flange and the ductwork to reduce noise and vibration transmission.

Outlet and inlet location and sizing. Size the outlet duct area 150% larger than the radiator duct flange area. Size the inlet air opening at least as large but preferably 50% larger than the outlet.

If screens, louvers, or filters are used on either the inlet or outlet, increase the inlet or outlet size according to the recommendations given in Section 4.3.2, Installation Considerations.

Since the exhaust air of larger units is both high volume and high velocity, direct the exhaust flow away from areas occupied by people or animals.

Louver use. Design temperature-controlling louvers to prevent air inlet restrictions and air pressure reductions inside the building. Low building pressure can extinguish pilot lights on gas-fired appliances or cause problems with the building ventilation system.

Additionally, bringing large quantities of winter air into a building wastes building heat and risks frozen water pipes in normally heated spaces. Use dampers and controlled air outlet louvers as shown in Figure 4-6 to eliminate these problems and allow recovery of engine heat to reduce building heat loss. Close the louvers to the exterior and open the interior louvers when the outdoor temperature is below 18°C–21°C (65°F–70°F). Reverse the louver settings when the outdoor temperature is above 21°C–24°C (70°F–75°F).




Figure 4-6 Air Control Louvers

4.5 Remote Radiator Cooling

A remote radiator system allows installation of generator sets in locations where it would otherwise be difficult to bring the volume of air required to cool a unit-mounted radiator. In these systems, the engine water pump pushes coolant through a radiator mounted remotely from the generator set and, typically, in an open area. An electric motor-driven fan mounted on the radiator circulates air across the radiator's cooling fins.

The remote radiators have a Secondary Expansion Deaeration and Drawdown (SEDD) tank. This SEDD tank can be connected to the radiator either as an open or closed tank system. Closed SEDD tanks are typically used when the remote radiator is in close proximity to the generator set and open SEDD tanks are typically used when the remote radiator is located further away.

In order to assess a remote radiator cooling system, the cooling system designer needs the following data. From the respective generator set specification sheet, obtain the:

- Engine jacket water flow, Lpm (gpm)
- Cooling air required for generator set based on 14°C (25°F) rise and an ambient temperature of 29°C (85°F), m³/min. (cfm)
- Maximum static (vertical) head allowable above engine, kPa (ft. H₂O)

From the engine and/or radiator data sheet, obtain the:

- Maximum water pump inlet restriction kPa (psi)
- Maximum allowable coolant pressure differential external to engine kPa (psi)

Note: The REZCK models are not equipped with an engine-driven water pump and primary/secondary thermostats. Selection, sourcing, and installation of the primary/secondary water pumps and primary/secondary thermostats must be provided by the design engineer based on the application requirements using the generator set spec sheet data and the water pump manufacturer's specifications.

The following subsections provide general design guidelines for a remote radiator system.

4.5.1 General

System limitations. Cooling systems are limited by radiator cap ratings. The maximum radiator operating pressure is 138 kPa (20 psi) and the maximum operating temperature is 121°C (250°F). Radiators are available for vertical or horizontal discharge. See Figure 4-7 and Figure 4-8.

Air requirements. Refer to the generator set specification sheet for radiator air and engine/alternator air requirements. Cooling air required for generator sets equipped with a remote radiator is based on a 14°C (25°F) rise and an ambient temperature of 29°C (85°F). The amount of air required to ventilate the generator set room or enclosure determines the size of the air inlet and outlet. Configure the ventilation air inlet and outlet so that air flows across the generator set.

Use a ventilating fan, if necessary, to dissipate alternator and engine heat loss.

Note: All remote radiators are sized for mounting in an open area with no additional external devices attached. Attached devices, confined installation, louvers, dampers, ductwork, or other inlet or outlet air restriction require resizing the radiator to compensate for reduced airflow.




Figure 4-7 Remote Vertical Radiator (Horizontal Discharge) System




Figure 4-8 Remote Horizontal Radiator (Vertical Discharge) System

Static (vertical) head. If the vertical distance from the engine water pump to the radiator (known as *static head*) is within the engine manufacturer's recommendations, and the pressure drop through the piping and remote radiator does not exceed the engine manufacturer's limits, use the engine water pump to circulate water through the remote radiator. The allowable static head ranges from 5.2 m–15.2 m (17 ft.–50 ft.) and is listed on the generator set specification sheet. Exceeding the allowable static head causes excessive pressure on engine components resulting in problems such as leaking water pump seals.

Note: Size the pressure relief valve or cap to remain under the engine pressure limit.

Hot well tank/heat exchanger. When the static (vertical) head exceeds the distance stated in the specification sheet, use a hot well tank or heat exchanger and auxiliary circulating pump as shown in Figure 4-9 or Figure 4-10. Always wire the circulating pump in parallel with the remote radiator fan so that both operate whenever the generator set operates.

A partial baffle divides a hot well tank into two or more compartments. The engine pump forces heated water into the hot side, and the auxiliary pump then draws the water off and forces it into the radiator. After circulating through the radiator, coolant drains back to the cold side of the well where the engine water pump removes it. A hot well or heat exchanger also isolates head pressures from the engine.

Note: The water in the hot well tank drains into the radiator when the generator set is not running.

Note: Determine the size requirements of the remote radiator and hot well tank/heat exchanger for each application. Do not use a standard remote radiator with a hot well tank/heat exchanger.

4.5.2 Vent Lines

Route the vent lines at a continuous upward slope from the engine connection exit to the expansion tank. Port all vent lines individually into the expansion tank above the coolant level.

Locate the vent lines in the expansion tank to prevent splash on the coolant level sensor. Thoroughly vent the systems by installing vent lines to all the vent points on the engine and the charge air cooler circuits including the radiator core. Refer to the installation drawings for vent points.

Size the vent line the same as the connection point on the engine. The vent lines may be slightly larger; however, vent lines sized too large will increase fill line flow and possibly reduce head pressure applied to the engine water pump inlets.




Figure 4-9 Compound Remote Radiator/Hot Well Tank Cooling System




Figure 4-10 Compound Remote Radiator/Heat Exchanger Cooling System

4.5.3 Fill Lines (Balance or Static)

Connect the fill line(s) to the bottom of the expansion tank. Make the lines as short as possible, continuously descending, and connected directly *before* the engine water pump(s). To provide a positive head pressure to the engine water pump inlet, properly locate the fill line (or makeup line). See the installation drawings for the fill line connection points.

Connect the vent and fill lines to the expansion tank at the greatest possible distance from each other to prevent aeration and preheating of the coolant returning down the fill line.

The minimum fill line sizes cannot be smaller than the connection point on the engine. Do not allow fittings on the fill lines to reduce the effective size. If other cooling system components vent too much coolant to the expansion tank, larger diameter fill lines may be needed.

4.5.4 Location Considerations

When choosing the radiator's location:

- For economical installation and operation, locate the radiator as close as practical to the engine and at the same elevation to reduce piping, coolant, and wiring costs.
- Locate the radiator surge tank fill opening and vent line(s) at the highest point in the cooling system.
- Position the radiator no closer than one fan diameter from a wall, another radiator, or any other obstruction that would restrict air movement and future service access.
- Locate the radiator to prevent recirculation of the heated exhaust air back into the intake stream.
- Mount the radiator in an area where prevailing winds do not hamper free airflow.
- Locate the radiator where it is not subject to deep snow or ice accumulation, flooding, industrial fallout, leaf accumulation, heavy dust and chaff, or other detrimental seasonal or environmental conditions.
- For rooftop installations, do not locate the radiator near critical sound areas, building ventilation, or hood exhausts.

4.5.5 Installation Considerations

Note: The REZCK models are not equipped with an engine-driven water pump and primary/secondary thermostats. Selection, sourcing, and installation of the primary/secondary water pumps and primary/secondary thermostats must be provided by the design engineer based on the application requirements using the generator set spec sheet data and the water pump manufacturer's specifications.

When installing the remote radiator:

- Use a remote radiator setup kit, if available, to aid installation. See Figure 4-11.
- Wire the cooling fan motor to the generator set output so that the fan operates whenever the generator set operates. There is no need for a thermostatic control of the fan motor because the engine thermostat prevents overcooling as it does on generator set-mounted radiator systems. Follow all applicable national and local codes when wiring the cooling fan.
- Follow the wiring diagram on the remote radiator's fan motor. The motor rotation must match the fan blade design. The manufacturer supplies most units with counterclockwise fan rotation as viewed from motor side. The fan is a blower type, moving air from the fan side of the radiator, through the core, and out the front side.
- Preferably, connect no devices to either side of the radiator. Resize the radiator if adding louvers or duct work to the radiator to compensate for reduced airflow.
- Ensure that the radiator is level and securely bolted to a firm, solid foundation.
- Brace the radiator as needed, especially in areas with strong winds.
- Use isolators to keep area vibration from affecting the radiator or to keep vibration produced by the radiator from affecting surrounding areas.
- Use hose clamps on all nonthreaded connections.




Figure 4-11 Remote Radiator Setup Kit, Typical

4.5.6 Surge (Expansion) Tank for Horizontal Discharge Radiator

A horizontal discharge remote radiator requires the use of a surge (expansion) tank as shown in Figure 4-7. Locate the tank at the highest point in the cooling system. The surge tank provides venting, surge/expansion protection, and filling/makeup functions.

- Equip the surge tank with a sight-glass gauge, overflow tube, and pressure cap.
- Size the surge tank to handle at least 6%–10% of the total cooling system volume. Follow the engine manufacturer's recommendation when available.
- Connect the main line from the surge tank to the highest point of the remote radiator. Most vertical core radiators have the surge tank as part of the radiator top tank. The setup illustrated in Figure 4-7 provides for radiator and engine deaeration and a positive pressure at the pump suction inlet.
- Use a strainer to filter dirt, scale, and core sand from the coolant line.

Piping. Size water piping between the engine and the remote radiator large enough to eliminate the need for a booster pump. If the cooling system requires a booster pump, contact your distributor/dealer.

Use piping of ample size and with as few short sweep bends or elbows, tees, and couplings as possible. Use long sweep elbows or long bends, if bends are required.

Installation. Support piping externally, not from the radiator or engine.

On standard remote radiators, connect radiator bottom outlets only to the suction side of the pump. Plumb the lines to prevent air from becoming trapped in the lines. Route piping in one general direction, either upward or downward. A combination of both upward and downward piping creates air pockets in the piping. Route vent lines to the expansion/surge tank without creating low spots in the lines.

Flexible connections. Provide flexible connections when connecting piping to the radiator assembly. Use hose clamps at all nonthreaded connections.

Shutoff valves. Locate shutoff valves between the engine and cooling system to allow for isolation of both the radiator and the engine. A shutoff valve eliminates the need to drain the entire cooling system during service.

4.5.7 Procedure to Fill with Deaeration

For radiators designed for full deaeration, fill the radiator according to the following procedure.

1. Fill the cooling system from the bottom when possible. Otherwise, fill the radiator at the filler neck.
2. Next, fill the radiator through one of the top tank or expansion/surge tank inlets located before the final hose connection.
3. Continue filling the system to cover the filler neck bottom until coolant appears in the sight glass located in the radiator top tank.
4. Check and correct any leaks in the system.

4.5.8 Procedure to Fill without Deaeration

For radiators designed without deaeration, fill the radiator according to the following procedure.

1. Initially, fill the radiator through one of the top tank inlets located before the final hose connection for faster and more complete fillup.
2. Fill the cooling system from the bottom when possible. Otherwise, fill the radiator at the filler neck with coolant covering the filler neck bottom until coolant appears in the sight glass located in the radiator top tank.
3. Check for and correct any leaks in the system.

4.5.9 Checks after Initial Startup

If any problems arise during startup, immediately shut down the generator set. See Figure 4-12, Cooling System Checklist. Even after a successful startup, shut down the generator set after 5–10 minutes and recheck the belt tension to make sure no hardware has loosened during operation. Perform another recheck after 8–12 hours of operation.

✓	Operation
	Verify the cooling fan's position in the fan shroud.
	Check the mounting hardware.
	Check the fan motor for free rotation.
	Check V-belts for alignment and tension.
	Fill the system with coolant and check all connections for tightness and leaks.
	Verify that all electrical connections are secure and that the power source matches the motor nameplate.
	Verify that no loose foreign material is in the fan's air stream.
	With the unit running, check for:
	fan clearance
	excessive vibration
	excessive noise
	coolant leaks

Figure 4-12 Cooling System Checklist

4.6 City Water Cooling

4.6.1 System Features

City water-cooling systems use city water and a heat exchanger for cooling. They are similar to remote radiator systems because they require less cooling air than unit-mounted radiator systems. Figure 4-13 shows some of the elements of a typical installation.

The heat exchanger limits the adverse effects of city water chemistry to one side of a heat exchanger, which is relatively easy to clean or replace, while engine coolant circulates in a closed system similar to the radiator system. The heat exchanger allows engine temperature control, permits the use of antifreeze and coolant conditioners, and is suited to the use of an engine block heater as a starting aid.

4.6.2 Installation Considerations

Vibration isolation requirements. Water inlet and outlet connections are mounted on the generator set skid and isolated from engine vibration by flexible sections. If the generator set is vibration-mounted to the skid and the skid is bolted directly to the mounting base, no additional flexible sections are needed between connection points on the skid and city water lines. If the generator set skid is mounted to the base with vibration isolators, use flexible sections between the connection points on the skid and city water lines.

Shutoff valve location. A solenoid valve mounted at the inlet connection point automatically opens when the generator set starts, providing the engine cooling system with pressurized water from city water mains. This valve automatically closes when the unit shuts down. Use an additional customer-supplied valve ahead of the entire system to manually shut off city water for generator set service.




Figure 4-13 City-Water Cooling System with Heat Exchanger

4.7 Cooling Tower

A cooling tower system is a variation of a city water cooling with heat exchanger system. In warm, dry climates, a cooling tower is a suitable source of generator set cooling water.

A cooling tower system consists of the engine cooling system plus a raw-water system. The engine cooling system usually includes the engine water pump, a heat exchanger, a surge tank, and the engine water jacket. The raw-water system consists of the cooling tower, a raw-water pump, and the tube portion of the heat exchanger. A typical system is shown in Figure 4-14.

The engine cooling system circulates coolant through the heat exchanger outer shell. Raw water circulates through the heat exchanger tubes absorbing heat from the engine coolant. The heated raw water flows into a pipe at the top of the cooling tower and sprays down into the tower to cool by evaporation. Because some water is constantly being lost through evaporation, the system must provide makeup water.

4.8 Block Heaters

Block heaters are available as installed accessories on all generator sets. Generator sets installed in NFPA applications generally require use of a block heater. Equip generator sets with block heaters on all standby applications where the generator set is subject to temperatures below 0–20°C (32–68°F). See the respective generator set spec sheet for specific temperature recommendations. Connect the block heater to a power source that is energized when the generator set is not running. The block heater thermostat temperature is set for optimum operation based on the respective engine cooling characteristics.

Note: Block heater damage. The block heater will fail if the energized heater element is not immersed in coolant. Fill the cooling system before turning on the block heater. Run the engine until it is warm and refill the radiator to purge the air from the system before energizing the block heater.




Figure 4-14 Cooling Tower System

Notes

Section 5 Exhaust System

Satisfactory generator set performance requires proper exhaust system installation. Figure 5-1 and Figure 5-2 show typical arrangements of recommended exhaust systems. The following sections detail exhaust system components.

5.1 Flexible Exhaust Line

Install a section of seamless stainless steel flexible exhaust line at least 305 mm (12 in.) long within 610 mm (2 ft.) of the engine exhaust outlet. See Figure 5-1 and Figure 5-2.




Figure 5-1 Exhaust System, End Inlet Silencer




Figure 5-2 Exhaust System, Side Inlet Silencer

The flexible line limits stress on the engine exhaust manifold or turbocharger. Never allow the engine manifold or turbocharger to support the silencer or exhausting piping.

Note: Do not bend the flexible section or use it to compensate for misalignment between the engine exhaust and the exhaust piping.

When using threaded flexible exhaust connectors, place a 152-203 mm (6-8 in.) length of pipe between the flexible exhaust connectors and the exhaust manifold. See Figure 5-1. The pipe reduces the temperature of the flexible connection, simplifies flexible section removal, and reduces strain on the engine exhaust manifold.

5.2 Condensation Trap

Some silencers are equipped with a drain pipe plug for draining condensation; see Figure 5-3. Otherwise, install a wye- or tee-type condensation trap with a drain plug or petcock between the engine and the exhaust silencer as shown in Figure 5-4. The trap prevents condensed moisture in the engine exhaust from draining into the engine after shutdown. Periodically drain collected moisture from the trap.




Figure 5-3 Silencer Condensation Drain Plug




Figure 5-4 Condensation Trap

5.3 Piping

Note: Select piping with a diameter that is the same size as, or larger than, the manifold outlet's inside diameter.

- Keep exhaust lines as short and straight as possible.
- Use schedule 40 black-iron pipe.
- Use sweep elbows with a radius of at least three times the pipe diameter.
- Use exhaust piping that conforms to applicable codes.
- Support the exhaust piping securely, allowing for thermal expansion.
- Insulate the exhaust piping with high-temperature insulation to reduce the heat rejected by exhaust piping and consequently the amount of ventilating air required.

In general, exhaust temperatures measured at the engine's exhaust outlet are less than 538°C (1000°F), except for infrequent brief periods; therefore, low-heat appliance standards apply. Each generator set specification sheet provides exhaust temperatures.

For units with exhaust temperatures below 538°C (1000°F), route the exhaust piping a minimum of 457 mm (18 in.) from combustible material, including building materials and natural surroundings. If exhaust temperatures exceed 538°C (1000°F), the minimum distance is 914 mm (36 in.).

When planning exhaust silencer and piping placement, consider the location of combustible materials. If the proximity of the exhaust system to the combustible materials cannot be avoided, follow a regular maintenance schedule to ensure that combustible materials are kept away from the exhaust pipes after installation. Combustible materials include building materials as well as natural surroundings. Keep dry field grass, foliage, and combustible landscaping material a safe distance from the exhaust system.

5.4 Double-Sleeved Thimbles

If the exhaust pipe passes through a wall or roof, use a double-sleeved exhaust thimble to prevent the transmission of exhaust pipe heat to the combustible material. Figure 5-5 shows construction details of a typical double-sleeved thimble in which exhaust piping passes through a combustible structure. Sheet metal shops usually fabricate thimbles using installation engineer's specifications and drawings.




Figure 5-5 Double-Sleeved Thimbles and Rain Cap

Construct the thimble so it extends at least 254 mm (10 in.) both inside and outside the structure's surface. Openings at both ends of the thimble allow cooling air to circulate through the thimble. If screening is used on the outer end to keep birds and animals from entering the thimble, use a mesh large enough to allow unrestricted air circulation through the thimble. See Section 5.5 for additional exhaust outlet location and protection considerations.

5.5 Exhaust Outlet

Outlet location. Engine performance and efficiency depend on the location of the exhaust outlet. Direct the exhaust outlet away from the air inlet to prevent exhaust gases from entering the air inlet and clogging the dry-type air filter elements. Hot exhaust drawn through the radiator adversely affects engine cooling. Locate the exhaust outlet to prevent exhaust fumes from entering a building or enclosure.

Noise reduction. The exhaust outlet configuration affects the apparent noise level for people or animals in the vicinity. An upward-directed outlet seems quieter than one directed downward or horizontally. Additionally, a 30- to 45-degree angled cut at the end of a horizontal exhaust outlet pipe reduces turbulence at the outlet, thereby reducing the noise level.

Rain cap. To prevent precipitation from entering the exhaust pipe, install a rain cap on vertical outlets. See Figure 5-5. In a climate where freezing is common, do not use a rain cap. Instead, extend the exhaust piping at least 610 mm (24 in.) beyond the roof line and create a gradual U bend at the end to direct the exhaust outlet downward. Keep the pipe outlet at least 457 mm (18 in.) from the roof to prevent hot exhaust from igniting the roof material.

Note: Do not use a rain cap in areas subject to freezing temperatures.

Generator set with enclosure. To avoid exceeding the engine manufacturer's maximum allowable backpressure specification, enclosure tail pipe extensions or attachments are not recommended.

5.6 Exhaust System Backpressure

Exhaust backpressure limits engine power and excessive backpressure causes serious engine damage. Excessive backpressure usually results from one or more of the following reasons:

- The exhaust pipe diameter is too small.
- The exhaust pipe is too long.
- The exhaust system has too many sharp bends.
- The exhaust silencer is too small.
- The exhaust silencer is not the correct design for the application.

Use the following procedure to verify that the installed exhaust system does not exceed the engine's maximum exhaust backpressure limit as specified in the generator set specification sheet.

Exhaust System Backpressure Calculation Procedure

Determine the total backpressure by calculating the effects of the individual exhaust system components and adding the results. Make calculations using either English or metric units. Exhaust pipe references are nominal pipe NPT (in.) sizes. The procedure shows an example with *italic* text. Calculations relate to end inlet silencers.

Note: When calculating backpressure drop for *side* inlet silencers, use the *end* inlet values shown and add 0.75 kPa (0.25 in. of mercury or 3.4 in. of water) to backpressure calculations.

1. Select the exhaust silencer type for the application—hospital, critical, residential, or industrial. See the silencer specification sheet for definitions for each exhaust silencer type. Confirm silencer type availability for your generator set with your authorized distributor/dealer, as some generator sets do not use all four types.

Example: Determine the silencer backpressure for the recommended critical silencer on a 230 kW, 60 Hz diesel generator set.

2. Refer to the generator set specification sheet for:
 - a. Engine exhaust flow at rated kW in m³/min. (cfm)
Example: 57.5 m³/min. (2030 cfm)
 - b. Maximum allowable backpressure in kPa (in. of Hg)
Example: 10.2 kPa (3.0 in. Hg)
3. Refer to the submittal catalog for:
 - a. The recommended critical silencer part number
Example: 343616
 - b. Silencer inlet diameter in mm (in.)
Example: 152 mm (6 in.)
 - c. Silencer inlet position (end or side)
Example: end inlet
 - d. The flexible exhaust adapter part number
Example: 343605
 - e. Flexible exhaust adapter, flexible section length
Example: 857 mm (33.75 in.)

4. Determine the exhaust gas velocity through the silencer as follows:

- a. Using the exhaust silencer inlet diameter determined in step 3, determine corresponding inlet area using Figure 5-6.

Example: 0.0187m^2 (0.201 sq. ft.)

- b. Use this data to calculate the exhaust gas velocity. Divide the engine exhaust flow from step 2 in $\text{m}^3/\text{min.}$ (cfm) by the silencer inlet area m^2 (sq. ft.) to get flow velocity in m (ft.) per minute.

Example:

*$57.5\text{ m}^3/\text{min.} / 0.0187\text{ m}^2 = 3075\text{ m/min.}$
 $(2030\text{ cfm} / 0.201\text{ sq. ft.} = 10100\text{ ft./min.})$*

Nominal Pipe Size, in. NPT	Inlet Area, m^2	Inlet Area, ft^2
1	0.00056	0.0060
1 1/4	0.00097	0.0104
1 1/2	0.00131	0.0141
2	0.00216	0.0233
2 1/2	0.00308	0.0332
3	0.00477	0.0513
4	0.00821	0.0884
5	0.0129	0.139
6	0.0187	0.201
8	0.0322	0.347
10	0.0509	0.548
12	0.0722	0.777
14	0.0872	0.939
16	0.1140	1.227
18	0.1442	1.553

Figure 5-6 Cross Sectional Area for Standard Silencer Sizes

5. Refer to Figure 5-7. Use the exhaust gas velocity determined in step 4 and find the exhaust gas velocity value in thousands on the bottom scale. Move vertically up until this value intersects the curve of the corresponding silencer type as determined in step 1. Move left on the horizontal axis and determine the backpressure drop value in kPa (in. of Hg).

Example: Exhaust velocity, 3075 m/min. (10100 ft./min.) intersects with critical silencer curve B and the corresponding backpressure value is approximately 2.8 kPa (0.85 in. of mercury). Silencer type is end inlet from step 3 information with no additional backpressure drop value per the following note.

Note: When calculating backpressure drop for *side* inlet silencers, use the *end* inlet values shown and add 0.75 kPa (0.25 in. of mercury or 3.4 in. of water) to backpressure calculations.

Note: Refer to Figure 5-8 to calculate in inches of water and feet per minute.

6. Total the number of elbows and flexible sections in the exhaust system between the engine and the exhaust system outlet. Compare the radius of the bend (R) to the pipe diameter where (D) is the nominal pipe diameter in inches. Determine the equivalent length in m (ft.) of straight pipe for the elbows and flexible sections from the following:

Bend Angle	Type	Bend Radius	Conversion Factor
90°	Close	$R = D$	$32 \times D^* / 12$
90°	Medium	$R = 2D$	$10 \times D^* / 12$
90°	Sweep	$R = 4D$	$8 \times D^* / 12$
45°	Close	$R = D$	$15 \times D^* / 12$
45°	Sweep	$R = 4D$	$9 \times D^* / 12$
	Flex Sections		$2 \times \text{Length}^\dagger / 12$
* Use the diameter of the silencer inlet in <i>inches</i> from step 3 for the initial calculation. If the results from step 9 indicate excessive backpressure drop, then recalculate using the larger-diameter pipe size selected. † Use the flexible exhaust adapter length from step 3 and add any additional flex sections in the exhaust system expressed in <i>inches</i>.			

Convert the equivalent pipe length calculated in feet to meters using $\text{ft.} \times 0.305 = \text{m}$, as needed.

Examples:

45° sweep elbows:

$9 \times 6.0\text{ in.} / 12 = 4.5\text{ equiv. ft. or }1.4\text{ equiv. m}$

90° close elbows:

$32 \times 6.0\text{ in.} / 12 = 16.0\text{ equiv. ft. or }4.9\text{ equiv. m}$


Flexible sections:

$2 \times 33.75\text{ in.} / 12 = 5.6\text{ equiv. ft. or }1.7\text{ equiv. m}$

Equivalent of straight pipe:


$4.5 + 16.0 + 5.6 = 26.1\text{ equiv. straight ft.}$

$1.4 + 4.9 + 1.7 = 8.0\text{ equiv. straight m}$



Note: When figuring the silencer pressure drop for side inlet, add 0.75 kPa (0.25 in. of mercury or 3.4 in. of water) to the backpressure.

Figure 5-7 Silencer Backpressure Drop (in. of Hg)



Note: When figuring the silencer pressure drop for side inlet, add 0.75 kPa (86 mm of water or 3.4 in. of water) to the backpressure.

Figure 5-8 Silencer Backpressure Drop (in. of water)

7. Determine the total length of straight pipe used in the exhaust system. Add this calculation to the equivalent length for elbows and flexible sections obtained in step 6.

Example:

Straight pipe = 3.0 m (10 ft.).

Equivalent straight pipe from step 6: 8.0 m (26.1 ft.)

*3.0 m + 8.0 m = 11.0 m or
10 ft. + 26.1 ft. = 36.1 ft. total*

8. Refer to Figure 5-9 if the pipe size is 102 mm (4 in.) or less or Figure 5-10 if the pipe size is 127 mm (5 in.) or larger.

Place a straight edge across the chart with the edge in line with the pipe size in inches (D) on the right column from step 3 and the engine exhaust flow (Q) from step 2 on the left column.

Read backpressure kPa/m or in. of Hg/ft. (ΔP) from the center column. Calculate the total piping system backpressure by multiplying the total equivalent straight pipe in m (ft.) from step 7 by the kPa/m or in. of Hg/ft. of pipe from this step.

Example:

*11.0 equiv. m x 0.04 kPa/m =
0.4 total system backpressure in kPa*

*36.1 equiv. ft. x 0.004 in. Hg/ft. =
0.14 total system backpressure in inches of Hg*

9. Add the backpressure of the piping determined in step 8 to the backpressure of the silencer determined in step 5. The total should not exceed the engine manufacturer's maximum allowable system backpressure determined in step 2 or on the generator set's specification sheet. If the total exceeds the maximum, use a larger pipe size or silencer or both. Repeat the calculation if new components are selected to verify that the system backpressure would not exceed the limit using the larger component(s).

Example:

*0.4 kPa (step 8) + 2.8 kPa (step 5) = 3.2 kPa
Maximum allowable backpressure = 10.2 kPa
3.2 < 10.2 backpressure drop is acceptable*

*0.14 in. Hg. (step 8) + 0.85 in. Hg. (step 5) =
0.99 in. Hg.
Maximum allowable backpressure = 3.0 in. of Hg.
0.99 < 3.0 backpressure drop is acceptable*




Figure 5-9 Backpressure using Pipe Size 4 in. (102 mm) or Less




Figure 5-10 Backpressure using Pipe Size 5 in. (127 mm) or Larger

Notes

Comply with applicable state and local codes when installing any fuel system.

6.1 Diesel Fuel Systems

The main components of a typical diesel fuel system are a main fuel storage tank, a day tank, fuel lines, and an auxiliary fuel pump. See Figure 6-1.

6.1.1 Main Tank

Storage. Because it is less volatile than gas or gasoline, diesel fuel is safer to store and handle. Regulations for diesel storage tank placement are less stringent than the regulations for gas or gasoline storage. In some locations, large main tanks are permitted inside the building or enclosure.




Figure 6-1 Diesel Fuel System

Tank location. Locate fuel storage tanks above ground or bury them underground in accordance with applicable codes. Figure 6-2 shows a commonly used above-ground subbase tank contained in the generator set mounting base.

Provide easy access to fuel filters and sediment drains for regular and frequent service. Clean fuel is especially important to diesel engines, which have easily clogged fuel injectors and pumps.




Figure 6-2 Subbase Fuel Tank

Tank size. Codes requiring standby power often specify a minimum onsite fuel supply. Such requirements are included in NFPA 70, National Electrical Code, and NFPA 99, Standard for Health Care Facilities. Diesel fuel deteriorates if stored for more than one year; therefore, size the tank to ensure that regular generator set exercising will use the tank's contents within one year. If there are no applicable code requirements, the manufacturer recommends a tank sized for eight hours of operation at rated load. Refer to the generator set specification sheet for fuel consumption data.

Tank venting. Vent the main fuel tanks to allow air and other gases to escape to the atmosphere without allowing dust, dirt, and moisture to enter the tank.

Fuel expansion. Never fill the tank more than 95% full to allow for fuel expansion. On overhead main tanks, use a fuel shutoff solenoid to prevent hydraulic lock or tank overflow caused by excessive static head fuel pressures.

Fuel alternatives. Most diesel engines operate satisfactorily on No. 2 domestic burner oil available in most parts of the US. If the site heating system is oil-fired, consider supplying the engine with fuel from the same tank used for heating oil to reduce costs and to ensure a continually fresh fuel supply for the engine. This practice necessitates that the fuel oil meets the engine manufacturer's minimum requirements for wax point, pour point, sulfur content, and cetane number as these factors influence cold weather starting and generator set power output. When supplying multiple applications from the same main fuel tank, provide each with a separate supply line.

6.1.2 Day Tanks

The terms *day tank* and *transfer tank* are interchangeable. Having a day tank adjacent to the engine allows the engine fuel transfer pump to easily draw fuel during startup and provides a convenient location to connect fuel injector return lines. See Figure 6-3.

Connect a float-switch-controlled solenoid antisiphon valve or a float valve to prevent siphoning fuel from the main storage tank if the main tank fuel level is above the day tank inlet.

Tank size. Standard tanks are available in sizes from 38–3952 L (10–1044 gal.) with or without integral electric fuel transfer pumps. Because engines are subject to fuel temperature deration above 38°C

(100°F) and are subject to damage if operated with fuel temperatures above 60°C (140°F), a day tank providing at least four hours of fuel consumption should be used to provide enough capacity to cool the fuel returning from the engine. If smaller day tanks are used, the generator set manufacturer may recommend installing a fuel cooler or routing engine fuel return lines to the main storage tank. See Figure 6-3.

Optional equipment includes fuel level gauges, manual priming pumps, float switches for pump control, float valves, rupture basins, and low level alarms. Remove the plastic shipping plugs and install metallic pipe plugs in all unused fuel tank ports to provide a liquid-tight seal.




Figure 6-3 Diesel Fuel System with Overhead Main Tank and Day Tank

6.1.3 Fuel Lines

The following items describe fuel line selection and application. Never use the fuel piping or fuel line clamps to ground any electrical equipment.

Line type. Use Schedule 40 black-iron pipe, steel tubing, or copper tubing for diesel fuel systems. Diesel fuel reacts adversely with galvanized tanks and piping, producing flaking sediment that quickly clogs filters and causes fuel pump and fuel injector failure. Ensure that any flexible fuel lines used are approved for diesel fuel.

Line size. Use the smallest diameter fuel line that still delivers enough fuel to the engine with an acceptable pressure drop of 6.9 kPa (1.0 psi). Using oversize piping increases the chance of air introduction into the fuel system during engine priming, which increases the potential for fuel pump damage and hard starting.

Flexible connectors. Use flexible connections spanning a minimum of 152 mm (6 in.) between the stationary piping and the engine fuel inlet connection.

Return lines. A diesel system delivers more fuel to the injectors than the engine uses; therefore, a system has one supply line from the fuel tank and at least one return line from the fuel injectors. Size the fuel return lines no smaller than the fuel supply lines.

Route the return fuel line to either the day tank or the main storage tank. Place the return lines as far away from the pickup or fuel diptube as possible to prevent air entry and to keep warm fuel from being reintroduced to the engine. If fuel lines are routed to the day tank, note the day tank size requirements in Section 6.1.2, Day Tanks.

A properly designed fuel return line is unrestricted and as short as possible, and it allows gravity return of fuel to the storage tanks. In installations where gravity return is not possible, obtain approval of the design from the generator set supplier based upon the engine's specifications before installing a fuel system with static head pressure on the return lines. Fuel return line restriction can cause engine hydraulic lock or uncontrollable overspeed on some systems.

6.1.4 Auxiliary Fuel Pumps

Primary, engine-driven fuel pumps typically develop a maximum of 48 kPa (7 psi) pressure and draw fuel to approximately 1.2–1.4 m (4–5 ft.) vertically or 6 m (20 ft.) horizontally. When the main tank is located a greater distance from the engine or for a more reliable fuel system, use an auxiliary pump alone or in connection with a day tank. See Figure 6-3. Limit auxiliary fuel pump pressure to approximately 35 kPa (5 psi).

Use a shutoff solenoid valve wired into the engine run circuit or a check valve to help keep the fuel line primed. Install the check valve on the outlet side of the auxiliary fuel pump to minimize inlet restriction.

Auxiliary fuel pump options. On engines using less than 38 L (10 gal.) of fuel per hour (approximately 100 kW or less), connect an engine starting battery-powered electric fuel transfer pump in series with the engine-driven transfer pump. Locate the electric pump nearer to the fuel tank than to the engine. An auxiliary pump located at the fuel tank approximately doubles the horizontal and vertical distance limits of a single engine-driven pump.

On engines using more than 38 L (10 gal.) of fuel per hour or when drawing fuel more than 1.8 m (6 ft.) vertically or 12 m (40 ft.) horizontally, use an electric motor-driven positive displacement pump with a day tank and float switch. Electrically connect the fuel pump to the transfer switch load side for maximum reliability. This type of pump can typically lift fuel 5.5 m (18 ft.) or draw it horizontally up to 61 m (200 ft.).

Where vertical runs exceed 5.5 m (18 ft.) or horizontal runs exceed 61 m (200 ft.), remote-mount the pump adjacent to the fuel storage tank. This type of installation allows these pumps to push fuel over 305 m (1000 ft.) horizontally or more than 31 m (100 ft.) vertically and deliver adequate fuel for generator sets up to 2000 kW. Always connect a positive-displacement pump directly to a day tank and float switch to protect the engine fuel system from excessive fuel pressures.

6.2 Gas Fuel Systems, Common Components

Gas fuel systems operate on either LP (liquefied petroleum) or natural gas.

Note: Design and install gas fuel systems in accordance with NFPA 54, National Fuel Gas Code, and applicable local codes.

All gas systems include a carburetor, secondary gas regulator, electric gas fuel solenoid shutoff valve, and flexible fuel connector.

6.2.1 Gas Lines

Never use fuel piping to ground electrical equipment. The gas supplier is responsible for installation, repair, and alteration to gas piping.

Line type. Use Schedule 40 black-iron pipe for gas piping. Copper tubing may be used if the fuel does not contain hydrogen sulfide or other ingredients that react chemically with copper.

Line size. Size piping according to the requirements of the equipment. Refer to the generator set specification sheet or the dimension drawing for detailed information on your system. In addition to the actual fuel consumption, consider the following pressure loss factors:

- Pipe length
- Other appliances on the same fuel supply
- Number of fittings

Flexible connections. Rigid-mount the piping but protect it from vibration. Use flexible connections spanning a minimum of 152 mm (6 in.) between the stationary piping and the engine fuel inlet connection.

6.2.2 Gas Regulators

Gas regulators reduce high incoming fuel pressures to lower levels acceptable for engines. Refer to the generator set spec sheet for fuel supply pressures. Install a solenoid valve upstream from the gas regulator and the flexible fuel connector to prevent the accumulation of an explosive mixture of gas and air caused by leaks in the flexible connection or the gas regulator. The generator set installer normally wires the engine battery-powered solenoid valve to the engine starting controls to open the valve when the engine cranks or runs.

For UL compliance, the fuel solenoid valves are needed per UL 2200, Section 35.3.2.2.1.

The typical gas system uses two gas regulators:

- **Primary gas regulator.** Provides initial control of gas from the fuel supply. The primary gas regulator reduces the high pressure from a tank or transmission line to the low pressure required by the secondary gas regulator(s). Typically, the primary gas regulator is set at the higher pressure value when a range is given. The gas supplier typically provides the primary gas regulator, as conditions that dictate the type of gas regulator used vary depending on the method of supplying fuel. The supplier is also responsible for providing sufficient gas pressure to operate the primary gas regulator. Primary gas regulator must be vented to the outside if installed within any building.
- **Secondary gas regulator.** This low-pressure gas regulator is mounted on the engine and limits the maximum inlet pressure to the engine. The engine operates satisfactorily at the lower pressure value when a range is given, but these lower pressures may result in poor response to load changes or a lack of power if the primary gas regulator is not near the engine.

Modification for fuel type. Many gas regulators are compatible with both natural gas and LP gas. Typically, the user installs the spring and retainer in the gas regulator when connecting to natural gas and removes it from the gas regulator when connecting to LP vapor gas. Refer to the appropriate generator set's operation manual and/or the decal attached to the generator set for information regarding spring/adjustment screw usage for specific models. Some models may require new diaphragm kits and/or inverting the gas regulator when changing fuel type.

Rating change. Converting the fuel will change the generator set rating. See the generator set specification sheet for ratings with natural gas and LP. Order a new nameplate with the updated rating and fuel information from an authorized distributor/dealer, if necessary. Provide the following information from the original nameplate:

- Model number
- Spec number
- Serial number
- Fuel (original and new)
- kW
- kVA
- Amps
- Volts
- Hz

Attach the new nameplate over the old one. Do NOT cover the UL listing information on the old nameplate.

Installation position for fuel type. The gas regulator functions normally pointing downward for both natural gas and LP gas. If only natural gas fuel is used, the gas regulator should be installed pointing upward.

Pressure testing. Some gas regulators provide for installation of a pressure gauge to test inlet and outlet pressures. If no such provision is available, install pipe tees in the fuel line to test pressure and use pipe plugs to test unused openings.

6.3 LP Fuel Systems

Fuel characteristics. LP fuel exists as a vapor and a liquid in pressurized tanks. Since LP fuel does not deteriorate in storage, a large supply of fuel can be kept onsite indefinitely for operation during emergency conditions. This makes LP gas ideal for applications with uninterrupted (onsite) fuel supply requirements.

Fuel mixture. LP gas is propane, butane, or a mixture of the two gases. The ratio of butane to propane is especially important when the fuel flows from a large outdoor tank. A fuel supplier may fill the tank in the warm summer months with a mixture composed mainly of butane; however, this mixture may not provide sufficient vaporized pressure at cold temperatures to start and operate the engine. A local fuel supplier is likely to be the best source of information on what size tank is necessary to provide adequate fuel vapor.

The fuel mixture and vaporization pressure at the anticipated temperatures influence the selection of gas regulator equipment. Pure butane gas has little or no vaporization pressure in temperatures below 4°C (40°F). Even at 21°C (70°F), the pressure is approximately 124 kPa (18 psi). Some primary gas regulators do not operate at tank pressures below 207 kPa (30 psi) while others operate at incoming pressures as low as 20.7–34.5 kPa (3–5 psi).

Fuel consumption and tank size. Since LP fuel is supplied in pressurized tanks in liquid form, it must be converted to a vapor state before being introduced into the carburetor. The amount of vapor contained in 3.8 L (1.0 gal.) of liquid (LP) fuel is:

Butane Gas	0.88 m ³ (31.26 cu. ft.)
Propane Gas	1.03 m ³ (36.39 cu. ft.)

See the generator set specification sheets for fuel consumption at different loads, and contact your fuel supplier for information regarding tank sizes.

System types. Single-source gas fuel systems include LP gas vapor-withdrawal and LP gas liquid-withdrawal.

6.3.1 LP Gas Vapor-Withdrawal Systems

A vapor-withdrawal system draws on the fuel vapor that collects in the space above the liquid fuel. Consider the following during installation:

- Generally, allow 10%–20% of tank capacity for fuel expansion from a liquid to a vapor state. The liquid level in LP gas tanks must never exceed 90% of the tank capacity.
- Maintain air temperature surrounding the tank high enough to vaporize the liquid fuel.

Applications in colder climates may require an independent heat source to increase natural vaporization within the tank. Withdraw liquid fuel and vaporize it in an electrically heated, engine water jacket-heated, or LP gas-heated vaporizer. Figure 6-4 shows the components of the vapor-withdrawal system used in a typical stationary application. The LP gas regulator is typically installed in the inverted position (pointing downward).




Figure 6-4 Typical LP Gas Vapor-Withdrawal System

6.3.2 LP Gas Liquid-Withdrawal Systems

LP liquid-withdrawal fuel systems are available for generator sets but are not recommended for automatic standby service. With liquid-withdrawal systems, liquid LP at 1034–1379 kPa (150–200 psi) flows to the engine. A combination of converters (vaporizers) and gas regulators then reduces the pressure to a usable level.

In Figure 6-5, a converter (a combination of a vaporizer and primary and secondary gas regulators) changes the liquid to vapor using heat from the engine's cooling system. For a period following startup, a liquid-withdrawal system may be unable to vaporize enough fuel for an engine running under load until the engine reaches operating temperature. The engine needs time to warm sufficiently to provide adequate heat to vaporize the fuel.




Figure 6-5 LP Gas Liquid Withdrawal System

Some codes prohibit gas fuel pressurization greater than 34.5 kPa (5 psi) inside buildings. This might preclude the use of a liquid-withdrawal system. To ensure code compliance, converters are sometimes located outside the building housing the generator set. However, the great length of pipe between the converter and the carburetor does not allow sufficient heat buildup and heat retention to maintain the fuel in its vapor state, which can cause startup problems.

6.4 Natural Gas Systems

The utility supplies natural gas in a vapor state. A natural gas fuel system consists of the same basic components and operates with the same general sequence as LP gas vapor-withdrawal systems. See Figure 6-6 and Figure 6-7. Note that when the heat content of the fuel falls below 1000 Btu, as it does with sewage-derived and some other natural gas fuels, the generator set will not produce its rated power. The natural gas regulator is typically installed in the upright position (pointing upward).




Figure 6-6 Natural Gas Fuel System with Pressure Gauge




Figure 6-7 Natural Gas Fuel System without Pressure Gauge and with Manual Shutoff Valve

6.5 Combination Systems

Combination fuel source systems include:

- Natural gas and LP gas

6.5.1 Combination Natural Gas and LP Gas

Some applications use natural gas as the main fuel and LP gas as the emergency fuel when natural gas is not available.

The natural gas and *LP gas, liquid withdrawal* system uses a converter (vaporizer) to change the LP liquid to gas vapor. A pressure switch on the primary fuel source closes when fuel pressure drops, which energizes a relay that closes the primary fuel solenoid and opens the secondary or emergency fuel solenoid.

A separate LP gas load adjustment valve ensures the right fuel-to-air mixture in the carburetor. The load adjustment valve is located inline between the converter (vaporizer) and the carburetor. See Figure 6-8.




Figure 6-8 Natural Gas and LP Gas System, Liquid Withdrawal

The natural gas and *LP gas, vapor withdrawal* system contains a separate secondary gas regulator and solenoid valve for each fuel. The LP gas regulator typically mounts in the inverted position. A pressure switch on the primary fuel source closes when fuel pressure drops, which energizes a relay that closes the primary fuel solenoid and opens the secondary or emergency fuel solenoid. A separate LP gas load adjustment valve ensures the right fuel-to-air mixture in the carburetor.

The load adjustment valve is located inline between the secondary gas regulator and the carburetor. See Figure 6-9.




Figure 6-9 Natural Gas and LP Gas System, Vapor Withdrawal

6.6 Pipe Size Requirements for Gas Fuel Systems

The type of fuel, the distance it must travel from gas meter/tank to fuel shutoff solenoid, and the amount consumed by the engine must be considered when determining fuel line pipe size.

To find the correction necessary for the different specific gravity of the particular fuel used, refer to Figure 6-10.

Figure 6-11 is based on gas pressures of 3.4 kPa (0.5 psi, 13.8 in. water column) or less and a pressure drop of 0.12 kPa (0.018 psi, 0.5 in. water column) with a

0.60 specific gravity and with a normal amount of restriction from fittings. To calculate the correct pipe size for a specific installation, refer to the chart and follow the procedure outlined below.

Fuel	Specific Gravity	Correction Factor
Sewage Gas	0.55	1.040
Natural Gas	0.65	0.962
Air	1.00	0.775
Propane (LP)	1.50	0.633
Butane	2.10	0.535

Figure 6-10 Fuel Correction Factors

Nominal Iron Pipe Size (IPS), In.	Internal IPS Diameter, mm (in.)	Length of Pipe, m (ft.)							
		3.0 (10)	6.1 (20)	9.1 (30)	12.2 (40)	15.2 (50)	18.3 (60)	21.3 (70)	
		Fuel Consumption Value, m ³ /hr. (ft ³ /hr.)							
1/4	9.25 (0.364)	1.2 (43)	0.82 (29)	0.68 (24)	0.57 (20)	0.51 (18)	0.45 (16)	0.42 (15)	
3/8	12.52 (0.493)	2.7 (95)	1.8 (65)	1.5 (52)	1.3 (45)	1.1 (40)	1.0 (36)	0.93 (33)	
1/2	15.80 (0.622)	5.0 (175)	3.4 (120)	2.7 (97)	2.3 (82)	2.1 (73)	1.9 (66)	1.7 (61)	
3/4	20.93 (0.824)	10.2 (360)	7.1 (250)	5.7 (200)	4.8 (170)	4.3 (151)	3.9 (138)	3.5 (125)	
1	26.64 (1.049)	19.3 (680)	13.2 (465)	10.6 (375)	9.1 (320)	8.1 (285)	7.4 (260)	6.8 (240)	
1 1/4	35.05 (1.380)	39.6 (1400)	26.9 (950)	21.8 (770)	18.7 (660)	16.4 (580)	13.9 (490)	13.0 (460)	
1 1/2	40.89 (1.610)	59.5 (2100)	41.3 (1460)	33.4 (1180)	28.0 (990)	25.5 (900)	22.9 (810)	21.2 (750)	
2	52.50 (2.067)	111.9 (3950)	77.9 (2750)	62.3 (2200)	53.8 (1900)	47.6 (1680)	43.0 (1520)	39.6 (1400)	
2 1/2	62.71 (2.469)	178.4 (6300)	123.2 (4350)	99.7 (3520)	85.0 (3000)	75.0 (2650)	68.0 (2400)	63.7 (2250)	
3	77.93 (3.068)	311.5 (11000)	218.0 (7700)	177.0 (6250)	150.0 (5300)	134.6 (4750)	121.8 (4300)	110.4 (3900)	
4	102.26 (4.026)	651.2 (23000)	447.4 (15800)	362.5 (12800)	308.7 (10900)	274.7 (9700)	249.1 (8800)	229.4 (8100)	
Nominal Iron Pipe Size (IPS), In.	Internal IPS Diameter, mm (in.)	Length of Pipe, m (ft.)							
		24.4 (80)	27.4 (90)	30.5 (100)	38.1 (125)	45.7 (150)	53.3 (175)	61.0 (200)	
		Fuel Consumption Value, m ³ /hr. (ft ³ /hr.)							
1/4	9.25 (0.364)	0.39 (14)	0.37 (13)	0.34 (12)	0.31 (11)	0.28 (10)	0.25 (9)	0.23 (8)	
3/8	12.52 (0.493)	0.88 (31)	0.82 (29)	0.76 (27)	0.68 (24)	0.62 (22)	0.57 (20)	0.54 (19)	
1/2	15.80 (0.622)	1.6 (57)	1.5 (53)	1.4 (50)	1.2 (44)	1.1 (40)	1.0 (37)	0.99 (35)	
3/4	20.93 (0.824)	3.3 (118)	3.1 (110)	2.9 (103)	2.6 (93)	2.4 (84)	2.2 (77)	2.0 (72)	
1	26.64 (1.049)	6.2 (220)	5.8 (205)	5.5 (195)	5.0 (175)	4.5 (160)	4.1 (145)	3.8 (135)	
1 1/4	35.05 (1.380)	13.0 (460)	12.2 (430)	11.3 (400)	10.2 (360)	9.2 (325)	8.5 (300)	7.9 (280)	
1 1/2	40.89 (1.610)	19.5 (690)	18.4 (650)	17.6 (620)	15.6 (550)	14.2 (500)	13.0 (460)	12.2 (430)	
2	52.50 (2.067)	36.8 (1300)	34.5 (1220)	32.6 (1150)	28.9 (1020)	26.9 (950)	24.1 (850)	22.7 (800)	
2 1/2	62.71 (2.469)	58.1 (2050)	55.2 (1950)	52.4 (1850)	46.7 (1650)	42.5 (1500)	38.8 (1370)	36.2 (1280)	
3	77.93 (3.068)	104.8 (3700)	97.7 (3450)	92.0 (3250)	83.5 (2950)	75.0 (2650)	69.4 (2450)	64.6 (2280)	
4	102.26 (4.026)	212.4 (7500)	203.9 (7200)	189.7 (6700)	169.9 (6000)	155.7 (5500)	141.6 (5000)	130.3 (4600)	
Note: When the fuel has a specific gravity of 0.7 or less no correction factor is necessary—use this table without a correction factor.									

Figure 6-11 Maximum Flow Capacity of Pipe in Cubic Meters (Cubic Feet) of Gas per Hour

1. Refer to the fuel consumption on the generator set specification sheet. Note type of fuel used, generator set application rating, and the m^3/hr . (ft^3/hr .) consumption at 100% load.

Example:

80 kW, propane gas, 60 Hz standby rating = $12.0 \text{ m}^3/\text{hr}$. ($425 \text{ ft}^3/\text{hr}$.)

2. Refer to the Fuel Correction Factors in Figure 6-10. Locate the correction factor for specific gravity of the selected fuel.

When the fuel has a specific gravity of 0.7 or less no correction factor is necessary—use Figure 6-11 without a correction factor.

Example:

*propane gas specific gravity = 1.50
fuel correction factor = 0.633.*

3. Divide the consumption value from step 1 by the correction factor from step 2.

Example:

$12.0 \text{ m}^3/\text{hr}$. ($425 \text{ ft}^3/\text{hr}$.) divided by 0.633 = $19.0 \text{ m}^3/\text{hr}$. ($671 \text{ ft}^3/\text{hr}$.)

4. Determine the length of pipe between the gas meter/tank and the fuel shutoff solenoid at the generator set.

Example:

34.7 m (114 ft.).

5. Find the value closest to pipe length in the Length of Pipe column in Figure 6-11.

Example:

38.1 m (125 ft.).

Example:

At $28.9 \text{ m}^3/\text{hr}$. ($1020 \text{ ft}^3/\text{hr}$.) the pipe size = 2 in. IPS.

6. Move vertically down the table in Figure 6-11 from the determined value in Length of Pipe column.

Example:

38.1 m (125 ft.)

Stop at the value that is equal to or greater than corrected consumption value from step 3.

Example:


$28.9 \text{ m}^3/\text{hr}$. ($1020 \text{ ft}^3/\text{hr}$.)

7. Move to the left column from the value in step 6 to determine the correct pipe size.

Section 7 Electrical System

Before installing the generator set, provide for electrical connections through conduit to the transfer switch and other accessories for the generator set. Carefully install the selected generator set accessories. Route wiring to the generator set through flexible connections. Regarding the application of bushings and grommets for the entry of wiring, use Class 1 wiring methods for field wiring connections to a Class 2 circuit. Comply with applicable national and local codes when installing a wiring system.

AC circuit protection. All AC circuits must include circuit breaker or fuse protection. Select a circuit breaker for up to 125% of the rated generator set output current. The circuit breaker must open all ungrounded conductors. The circuit breaker or fuse must be mounted within 7.6 m (25 ft.) of the alternator output terminals.



Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.


(Decision-Maker® 3+ and 550 Controllers)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(Decision-Maker® 3000, 3500, and 6000 Controllers)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) If the controller is not already in the MAN (manual) mode, press the Controller Mode button and then press the MAN mode button. (2) If the generator set is running, press and hold the Manual-Stop button for at least 2 seconds to stop the generator set. (3) Press the Controller Mode button and then press the controller Off mode button. (4) Disconnect the power to the battery charger, if equipped. (5) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(Decision-Maker® 8000 Controller)



Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

7.1 Generator Set Voltage Reconnection

To change the voltage of 10- or 12-lead generator sets, *use the procedure shown in the operation manual containing the respective controller setup.* Adjust the governor and voltage regulator for frequency changes. Consult the generator set service manual for frequency adjustment information.

Voltage reconnection. Affix a notice to the generator set after reconnecting the set to a voltage different from the voltage on the nameplate. Order voltage reconnection decal 246242 from an authorized service distributor/dealer.

Equipment damage. Verify that the voltage ratings of the transfer switch, line circuit breakers, and other accessories match the selected line voltage.

Reconnect the generator set stator leads to change the output phase or voltage. Reference the appropriate voltage reconnection drawing in the respective Wiring Diagram Manual..

Follow the safety precautions at the front of this manual and in the text and observe National Electrical Code (NEC) guidelines.

7.2 Electrical Connections

Several electrical connections must be made between the generator set and other components of the system for proper operation. Because of the large number of accessories and possible combinations, this manual does not address specific applications. Refer to the submittal catalog accessory drawings and wiring diagrams for connection and location. Most field-installed accessory kits include installation instructions.

For customer-supplied wiring, select the wire temperature rating in Figure 7-1 based upon the following criteria:

- Select row 1, 2, 3, or 4 if the circuit rating is 110 amperes or less or requires #1 AWG (42.4 mm²) or smaller conductors.
- Select row 3 or 4 if the circuit rating is greater than 110 amperes or requires #1 AWG (42.4 mm²) or larger conductors.

Comply with applicable national and local codes when installing a wiring system.

Row	Temp. Rating	Copper (Cu) Only	Cu/Aluminum (Al) Combinations	Al Only
1	60°C (140°F) or 75°C (167°F)	Use No. * AWG, 60°C wire or use No. * AWG, 75°C wire	Use 60°C wire, either No. * AWG Cu, or No. * AWG Al or use 75°C wire, either No. * AWG Cu or No. * AWG Al	Use 60°C wire, No. * AWG or use 75°C wire, No. * AWG
2	60°C (140°F)	Use No. * AWG, 60°C wire	Use 60°C wire, either No. * AWG Cu or No. * AWG Al	Use 60°C wire, No. * AWG
3	75°C (167°F)	Use No. *† AWG, 75°C wire	Use 75°C wire, either No. *† AWG Cu or No. *† AWG Al	Use 75°C wire, No. *† AWG
4	90°C (194°F)	Use No. *† AWG, 90°C wire	Use 90°C wire, either No. *† AWG Cu or No. *† AWG Al	Use 90°C wire, No. *† AWG
* The wire size for 60°C (140°F) wire is not required to be included in the marking. If included, the wire size is based on ampacities for the wire given in Table 310-16 of the National Electrical Code®, in ANSI/NFPA 70, and on 115% of the maximum current that the circuit carries under rated conditions. The National Electrical Code® is a registered trademark of the National Fire Protection Association, Inc. † Use the larger of the following conductors: the same size conductor as that used for the temperature test or one selected using the guidelines in the preceding footnote.				

Figure 7-1 Terminal Markings for Various Temperature Ratings and Conductors

7.3 Load Lead Connections

Feed load leads to the generator junction box from one of several different areas. Generator sets rated 300 kW and below commonly use the bottom entry where conduit is stubbed up into the junction box from the concrete slab. Other methods include flexible conduit roughed into the sides or top of the junction box. When using flexible conduit, do not block the front or rear of the controller. See Figure 7-2.

Use a minimum of 13 mm (0.5 in.) spacing between the conduit bushing and any uninsulated live parts in the junction box. All conduit openings in the junction box must be made such that no metal particles including drill chips contaminate the components in the junction box.

Generator sets larger than 300 kW have the junction box mounted on the rear of the generator set. Larger sets may have oversized junction boxes supplied as an option or to accommodate bus bar connections. Refer to the generator set dimension drawing and/or the electrical contractor prints for detailed information including stub-up area recommendations.




Figure 7-2 Typical Load Lead Connection

The four bus bars contained in the optional bus bar kits simplify the connection process by offering a neutral bus bar in addition to the three load bars. Optional bus lugs offer an array of terminal and wire connections.

7.4 Grounding and Grounded Conductor (Neutral) Connections

Connect the electrical system grounding conductor to the equipment grounding connector on the alternator. See Figure 7-3. Depending upon code requirements, the grounded conductor (neutral) connection is typically grounded.




Figure 7-3 Generator Set Equipment Grounding Connection

Ungrounded neutral connections use an insulated standoff (not supplied) to isolate the neutral connection from the grounding connection. For grounding lug selection, see Figure 7-4.

The four bus bars contained in the optional bus bar kits simplify the connection process by offering a neutral bus bar in addition to the three load bars. Optional bus lugs offer an array of terminal and wire connections.

Generator sets are typically shipped from the factory with the neutral attached to the alternator in the junction box for safety reasons per NFPA 70. At installation, the neutral can remain grounded at the alternator or be lifted from the grounding stud and isolated if the installation requires an ungrounded neutral connection at the generator set. The generator set will operate properly in either configuration.

Various regulations and site configurations including the National Electrical Code® (NEC), local codes, and the type of transfer switch used in the application determine the grounding of the neutral at the generator set.

Allowable Ampacity, Amps	Min. Size of Equipment Copper Grounding Conductor, AWG or kcmil	Recommended Compression Lug, ILISCO Part No. or Equivalent (UL Listed)
20	12	SLUH-90
60	10	SLUH-90
90	8	SLUH-90/125
100	8	SLUH-90/125
150	6	SLUH-90/125/225
200	6	SLUH-90/125/225
300	4	SLUH-90/125/225
400	3	SLUH-90/125/225
500	1	SLUH-125/225
600	1	SLUH-125/225
800	1/0	SLUH-225/300/400
1000	2/0	SLUH-225/300/400
1200	3/0	SLUH-225/300/400
1600	4/0	SLUH-225/300/400/650
2000	250	SLUH-225/300/400/650
2500	350	SLUH-300/400/650
3000	400	SLUH-400/650
4000	500	SLUH-400/650
5000	700	SLUH-650
6000	800	SLUH-650

Figure 7-4 Grounding Lug Selection

7.5 Terminal Connector Torque

Use torque values shown in Figure 7-5 or Figure 7-6 for terminal connectors. Refer to UL 486A–486B and UL 486E for information on terminal connectors for aluminum and/or copper conductors. See Section 7.2, Electrical Connections, for information on temperature rating of the customer-supplied wire. Comply with applicable national and local codes when installing a wiring system.

If a connector has a clamp screw such as a slotted, hexagonal head screw with more than one means of tightening, test the connector using both applicable torque values provided in Figure 7-6.

Socket Size Across Flats, mm (in.)	Tightening Torque, Nm (in. lb.)
3.2 (1/8)	5.1 (45)
4.0 (5/32)	11.4 (100)
4.8 (3/16)	13.8 (120)
5.6 (7/32)	17.0 (150)
6.4 (1/4)	22.6 (200)
7.9 (5/16)	31.1 (275)
9.5 (3/8)	42.4 (375)
12.7 (1/2)	56.5 (500)
14.3 (9/16)	67.8 (600)
Note: For values of slot width or length not corresponding to those specified, select the largest torque value associated with the conductor size. Slot width is the nominal design value. Slot length is to be measured at the bottom of the slot.	

Figure 7-5 Tightening Torque for Pressure Wire Connectors with Internal-Drive Socket-Head Screws

Wire Size for Unit Connection AWG, kcmil (mm ²)	Tightening Torque, Nm (in. lb.)			
	Slot Head 4.7 mm (No. 10) or Larger*		Hexagonal Head—External Drive Socket Wrench	
	Slot Width <1.2 mm (0.047 in.) Slot Length <6.4 mm (0.25 in.)	Slot Width >1.2 mm (0.047 in.) Slot Length >6.4 mm (0.25 in.)	Split-Bolt Connectors	Other Connections
18–10 (0.82–5.3)	2.3 (20)	4.0 (35)	9.0 (80)	8.5 (75)
8 (8.4)	2.8 (25)	4.5 (40)	9.0 (80)	8.5 (75)
6–4 (13.3–21.2)	4.0 (35)	5.1 (45)	18.6 (165)	12.4 (110)
3 (26.7)	4.0 (35)	5.6 (50)	31.1 (275)	16.9 (150)
2 (33.6)	4.5 (40)	5.6 (50)	31.1 (275)	16.9 (150)
1 (42.4)	—	5.6 (50)	31.1 (275)	16.9 (150)
1/0–2/0 (53.5–67.4)	—	5.6 (50)	43.5 (385)	20.3 (180)
3/0–4/0 (85.0–107.2)	—	5.6 (50)	56.5 (500)	28.2 (250)
250–350 (127–177)	—	5.6 (50)	73.4 (650)	36.7 (325)
400 (203)	—	5.6 (50)	93.2 (825)	36.7 (325)
500 (253)	—	5.6 (50)	93.2 (825)	42.4 (375)
600–750 (304–380)	—	5.6 (50)	113.0 (1000)	42.4 (375)
800–1000 (406–508)	—	5.6 (50)	124.3 (1100)	56.5 (500)
1250–2000 (635–1016)	—	—	124.3 (1100)	67.8 (600)
* For values of slot width or length not corresponding to those specified, select the largest torque value associated with the conductor size. Slot width is the nominal design value. Slot length is to be measured at the bottom of the slot.				
Note: If a connector has a clamp screw such as a slotted, hexagonal head screw with more than one means of tightening, test the connector using both applicable torque values.				

Figure 7-6 Tightening Torque for Screw-Type Pressure Wire Connectors

7.6 Batteries

Battery location. When determining the battery placement, ensure that the location:

- Is clean, dry, and not exposed to extreme temperatures
- Provides easy access to battery caps for checking the electrolyte level (when using maintenance type batteries)
- Is close to the generator set to keep cables short, ensuring maximum output

Refer to the submittal drawings for the generator set when choosing a battery rack. Figure 7-7 shows a typical battery system.




Figure 7-7 Typical Battery System, Side View

Battery type. Starting batteries are usually the lead-acid type and are sized according to the engine manufacturer's recommendation for a particular ambient temperature and required cranking time. NFPA 110 recommends cranking periods, including a single 45-second cycle for generator sets below 15 kW and three 15-second crank cycles separated by 15-second rests for larger models. Refer to the respective generator set specification sheet for the required battery cold-cranking ampere (CCA) rating.

Nickel-cadmium batteries are sometimes used for standby generator sets because of their long life (20 years). However, initial high cost, larger space requirements, and special charging requirements can offset this benefit. Therefore, conventional lead-acid batteries have proven satisfactory for the majority of generator set applications.

Battery cables. A UL 2200 listed generator set requires battery cables with positive (+) lead boots. Factory-supplied and optional battery cables include positive (+) lead boots. When battery cables are not factory-supplied, source battery cables with positive (+) lead boots for UL 2200 compliance.

Note: Some units are equipped with an insulating and reflective heat shield sleeve on the battery cables and other wires that are fastened to the starter solenoid. This sleeve is a conductive material and must be secured approximately 25 mm (1 in.) away from the exposed cable terminal.

7.7 Battery Chargers

Most industrial generator sets use an engine-driven, battery-charging alternator to charge the batteries whenever the generator set operates. Engine-driven systems are normally capable of charge rates of 30 amps or more and can quickly restore the charge used in a normal cranking cycle. When the engine is not operating, a very low charge rate from an AC-powered battery charger is usually sufficient to maintain a full charge on the batteries.

Some industrial generator sets have no battery-charging alternator and, therefore, require a separate AC-powered battery charger.

Select an automatic or manual battery charger with a high charge rate of 2 amps and a trickle charge rate up to 300 milliamps. The low maximum charge rate makes the charger ill-suited to restore fully discharged batteries. For full recovery capability independent of the engine-driven charging system, use an automatic float battery charger with a high charge rate of at least 10 amps.

Use separate, self-contained battery chargers or units built into the automatic transfer switch. Run leads from a transfer switch-mounted battery charger in conduit separate from the conduit that holds the generator load cables or remote engine-start circuits.

Note: Digital controllers with microprocessor circuitry and vacuum fluorescent displays typically draw more than 300 milliamps, making trickle charge battery chargers inappropriate for systems with these controllers. Select only automatic float/equalize battery chargers with a 3 amp or greater rating for units with digital controllers.

Battery failure is the most common reason for emergency generator set start failure. Two common battery failure causes are a manual charge rate set too low to maintain the battery and a manual charge rate set too high, resulting in loss of battery electrolyte. To avoid battery failure, use an automatic float charger, which varies the charge rate in response to battery condition.

For large engines with two starters, use either one bank of batteries and chargers for both starters or use separate battery systems. The latter system is preferable because it reduces the chance of a single component failure rendering the entire system inoperative.

7.8 Component and Accessory Power Source Requirements

Several components require a power source other than the engine starting batteries. The utility power supply outlet or electrical box should be in close proximity to the generator set. Some factory-supplied enclosures are available with electrical hook-up connections. Most accessories require a dedicated circuit with separate circuit breaker. Comply with applicable national and local codes when providing an electrical power source connection. These items include but are not limited to the following items:

- **Alternator Strip Heater** requires a 110–120 volt or 190–240 volt, 50/60 Hz, 15-amp power source. Check the component and instructions for specific information.
- **Battery Charger** typically requires a 110–120 volt or 190–240 volt, 50/60 Hz power source. Some generator set models require multiple battery chargers. Check the component for specific information as some battery chargers are only 110–120 volt, 50/60 Hz. See Section 7.7 Battery Chargers for additional information.
- **Battery Heater** requires a 110–120 volt, 50/60 Hz, 15-amp power source. Some kits require multiple outlets for the plate and wrap connections. Check the component and instructions for specific information.
- **Controller Heater (APM802 Controller only)** requires a 220–240 volt, 50/60 Hz power source. Check the component and instructions for specific information.
- **Crankcase Ventilation Heater (Some 125/150 kW Gas Models only)** require a 110–120 volt, 50/60 Hz, 37.5 watt power source. Check the component and instructions for specific information.
- **Engine Block Heater** typically requires a 110–120 or 190–240 volt, 50/60 Hz, 15- or 20-amp power source. Some kits require multiple outlet circuits. Check the component and instructions for specific information. See Section 4.8 Block Heaters for additional information.

7.9 Optional Accessories

The generator set manufacturer offers optional accessories that require connection to other components in the system. These accessories enable the generator set to meet standards for local and national codes, make operation and service more convenient, or satisfy specific customer installation requirements.

Accessories vary with each generator set model and controller. Accessories are available factory-installed and/or shipped loose. See Figure 7-8 for a list of available kits. Some accessories are available only with the microprocessor and digital controllers. Obtain the most current list of accessories from the respective generator set specification sheet or by contacting your local authorized service distributor/ dealer.

Kit Description
Bus Bar Kits/Bus Lugs
Gas Fuel Valve
Line Circuit Breaker
Run Relay
Wireless Monitor

Figure 7-8 Optional Accessories

Additional accessories and connections are shown in the following sections based on controller specific information. See Figure 7-9.

Controller	Section
Decision-Maker 3+	8
Decision-Maker 550	9
Decision-Maker 3000	10
Decision-Maker 6000	11
Decision-Maker 8000	Refer to TP-6990
APM802	Refer to TP-7070

Figure 7-9 Controller Accessories

Accessory kits generally include installation instructions. See the wiring diagrams manual for electrical connections not shown in this section. See the installation instructions and drawings supplied with the kit for information on the kit mounting location.

The instructions provided with the accessory kit supersede these instructions, if different. In general, run AC and DC wiring in separate conduit. Use shielded cable for all analog inputs. Observe all applicable national and local electrical codes during accessory installation.

Accessory wiring. To determine the appropriate size for the customer-supplied wiring of the engine battery-powered accessories, use the guidelines in Figure 7-10. Use 18–20 gauge wire for *signal wires* up to 305 m (1000 ft.).

Length, m (ft.)	Wire Gauge
30.5 (100)	18–20
152.4 (500)	14
304.8 (1000)	10

Figure 7-10 Wire Length and Size, Lead N and 42B

Match the wire terminals to the terminal strip conductor screw size. Use a maximum of two wire terminals per terminal strip screw unless otherwise noted on the respective accessory drawing or installation instruction.

Accessory connections. Do not direct-connect accessories to the controller terminal strip. Connect accessories to either a single-relay dry contact kit or ten-relay dry contact kit. Connect the dry contact kit(s) to the controller (customer) connection kit. Connect all accessories except the emergency stop kit to the connection kit terminal strip(s).

Terminal strips and available connections vary by controller. Refer to the respective controller operation manual and the accessory wiring diagrams in the wiring diagram manual for connection of kits. Field-installed accessories include installation instructions and/or wiring diagrams.

7.9.1 Bus Bar Kits/Bus Lugs

The four bus bars contained in the optional bus bar kits simplify the connection process by offering a neutral bus bar in addition to the three load bars. Optional bus lugs offer an array of terminal and wire connections. See Figure 7-11.




Figure 7-11 Bus Bar Kits/Bus Lugs

7.9.2 Gas Fuel Valve Kit

This section provides the wiring information for an *additional* gas fuel valve kit required for UL Approval. See Figure 7-12. Refer to the respective generator set wiring diagrams for additional information and for LP liquid applications.




Figure 7-12 Gas Fuel Valve Kit Connections

7.9.3 Line Circuit Breaker

The line circuit breaker interrupts generator output if an overload or short circuit occurs. Use the line circuit breaker to manually disconnect the generator set from the load during generator set service. See Figure 7-13.

The circuit breaker must open all ungrounded connectors. Refer to Service Bulletin 611 for circuit breaker instantaneous overcurrent trip adjustment information.




Figure 7-13 Line Circuit Breaker

7.9.4 Run Relay Kit

The run relay kit energizes only during generator set operation. The three sets of contacts typically control air intake and/or radiator louvers. However, alarms and other signaling devices can also connect to the contacts. See Figure 7-14.




Figure 7-14 Run Relay Kit

7.9.5 Wireless Monitor

The wireless monitor system has two components: a wireless monitor unit and a website. The monitor unit transmits messages in response to signals received from the equipment controller and notifies designated recipients of selected operating conditions. The website monitors these messages.

There are three monitor models: GM23409-KP1 for use with hardwire inputs; GM23409-KP2 for use with a 550 controller using Modbus® communication; and GM23409-KP3 for use with a 550 controller using hardwire inputs that require a customer interface board.

Note: The 550 controller supports only one connection for Modbus® communication. If the controller's RS-485 connection is already used for Modbus® communication with other equipment, use wireless monitor model GM23409-KP1 or -KP3 with hardwire inputs through a customer connection board for monitoring.

Typical messages might include:

- Overcrank
- Low oil pressure
- Overspeed
- Common fault

At the website, the user configures which individuals will receive messages regarding selected operating conditions and the message delivery method. Delivery methods include pagers (alphanumeric, numeric), fax, XML, e-mail, PCS, or telephone (voice delivery). Each message sent will contain the condition that generated the transmission and also the make, model, and location of the equipment. Up to 40 messages each day can be delivered. Single or multiple messages can be sent to selected recipients via multiple delivery methods. More than one delivery method can be used for each recipient.

The wireless monitor is powered by the equipment power source or by the generator set and constantly monitors the inputs. When an input is triggered, the wireless monitor sends the condition over the North American AMPS (advanced mobile phone system). An operations center server receives the transmission and forwards the message to the selected recipients according to the configured delivery method.

Every 24 hours, the wireless monitor also sends information about itself and the system it is monitoring. This *heartbeat* transmission tells the Kohler center that the wireless monitor is properly functioning, powered,

and able to generate messages. If a device fails to report a nightly heartbeat for more than a day, the system sends a *Unit Failed to Report Heartbeat* alarm message to the website.

Generator set run times and the number of cycles are reported. Models GM23409-KP1 and -KP3 accumulate run times over a 24-hour period and report the run times with the heartbeat message. Model GM23409-KP2 (for the 550 controller only) reports the total accumulated run time and the total number of starts. Run times for model GM23409-KP2 are also totaled using the Control Panel function and can be updated upon request.

Upon power loss, a rechargeable battery powers the wireless monitor. The monitor continues to transmit messages for 15 minutes, then transmits a loss of power signal and enters the *sleep* mode. The sleep mode can last up to 18 hours, until the battery completely discharges or power is restored. The wireless monitor continues to send scheduled heartbeat messages during the sleep mode until the battery discharges completely.




Figure 7-15 Wireless Monitor

7.10 Wiring Connections

Although equipment and connections vary, Figure 7-16 shows examples of the options and wire connections necessary to make an industrial system operational. Always refer to the wiring diagram for details of wire size, location, and number.




Figure 7-16 Generator Set Connections, Typical

Notes

Section 8 Decision-Maker® 550 Controller Accessories

8.1 Accessories and Connections

Several accessories help finalize installation, add convenience to operation and service, and establish state and local code compliance.

Accessories vary with each generator set model and controller. Select factory-installed and/or shipped-loose accessories. See Figure 8-1 for a list of available kits. Obtain the most current accessory information from your local authorized service distributor/dealer.

This section illustrates several accessories available at print time of this publication. Accessory kits generally include installation instructions. See wiring diagrams manual for electrical connections not shown in this section. See the installation instructions and drawings supplied with kit for information on kit mounting location.

The instructions provided with the accessory kit supersede these instructions where there are differences. In general, run AC and DC wiring in separate conduit. Use shielded cable for all analog inputs. Observe all applicable national, state, and local electrical codes during accessory installation.

8.1.1 Audiovisual Alarm Kit

An audiovisual alarm warns the operator at a remote location of fault shutdowns and prealarm conditions. Audiovisual alarms include an alarm horn, an alarm silence switch, and common fault lamp. See Figure 8-2 and Figure 8-3. See Section 8.2, Accessory Connections, for terminal identification.

Note: Use the audiovisual alarm with a dry contact kit.

Kit Description
Audiovisual Alarm
Common Failure Relay (Terminal 32A)
Controller (Customer) Connection
Float/Equalize Battery Charger (with alarms)
Ground Fault Annunciation
Idle (Speed) Mode Feature
Low Fuel (Level) Switch
Low Fuel (Pressure) Switch
Prime Power Switch
Remote Emergency Stop
Remote Reset Feature
Remote Serial Annunciator (RSA III)
Shunt-Trip Line Circuit Breaker and Shunt-Trip Wiring
Single-Relay Dry Contact
Ten-Relay Dry Contact
Twenty-Relay Dry Contact

Figure 8-1 Optional Accessories




Figure 8-2 Audiovisual Alarm




Figure 8-3 Audiovisual Alarm Connections

8.1.2 Common Failure Relay Kit

The common failure relay kit provides one set of contacts to trigger user-provided warning devices if a fault occurs. The common failure relay faults are user-defined. See the respective operation manual for status and faults available for this function.

Connect up to three common failure relay kits to the controller output. See Figure 8-4 and Figure 8-5. See Section 8.2, Accessory Connections, for terminal identification.

8.1.3 Controller (Customer) Connection Kit

The controller connection kit allows easy connection of controller accessories without accessing the controller terminal strip. The supplied wiring harness connects controller connector P23 and terminal strips TB1-3 and TB1-4 to the controller connection kit connector P25 and terminal strips TB6, TB7, TB8, and TB9. Connect all accessories (except the emergency stop kit) to the controller connection kit terminal strips. See Figure 8-6. See Section 8.2, Accessory Connections, for terminal identification.

8.1.4 Float/Equalize Battery Charger Kit with Alarm Option

The float/equalize battery charger with alarm option provides battery charging to the engine starting battery(ies) and connects to the controller for fault detection. Battery chargers for 12- or 24-volt models are available as a generator set accessory. See Figure 8-7. See Section 8.2, Accessory Connections, for terminal identification.




Figure 8-4 Common Failure Relay Kit




Figure 8-5 Common Failure Relay Kit Connections




Figure 8-6 Controller (Customer) Connection Kit




Figure 8-7 Float/Equalize Battery Charger Connections

8.1.5 Ground Fault Annunciation

A relay contact for customer connection indicates a ground fault condition and is part of a ground fault alarm. See Figure 8-8 for electrical connections and the following procedure for controller setup. Use the instructions with the kit when provided to install and setup this accessory.





Figure 8-8 Ground Fault Connections



Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

Ground Fault Controller Setup Procedure

1. Reconnect battery, if not already done.
2. Place the controller master switch to the AUTO position.
3. Press the Alarm Off key to silence the alarm horn, if necessary.
4. If the programming mode LED is not flashing, go to the step 5. If the programming mode LED is flashing, go to step 6.
5. Set Programming Mode to Local.

a. Press keys .

b. Press key until *Programming Mode-Local* is displayed.

c. Press the YES key .

d. When the *Enter Code* displays, press the factory default or the user password keys and . The programming mode LED should be flashing.

6. Set digital input #6 to ground fault.

a. Press . *Menu 9 Input Setup* should be displayed.

b. Press until *Digital Input 06 Warning* is displayed.

c. Press once to select this input.

d. Press until *Ground Fault* is displayed.

e. Press to define Digital Input #06 as ground fault. *Entry Accepted* is displayed.

f. Press to display *Digital Input #06 Inhibit Time*.

g. Press to enter the inhibit time. *Entry Accepted* is displayed and the inhibit time 0:00 is now displayed.

- h. Press  to display *Digital Input #06 Delay Time*.
- i. Press   to enter delay time. *Entry Accepted* is displayed. Default delay time is 5 sec.
- j. Press .

7. Verify Programming.

- a. Move handle of ground fault circuit breaker at generator set to simulate a ground fault.
- b. Verify that display shows *D06 Ground Fault*. The System Warning LED should be illuminated and the alarm horn should sound. If these indicators are not present, recheck steps 6a. through 6j.
- c. Return handle of ground fault circuit breaker to the non-ground fault position. *D06 Ground Fault* display should now be cleared.

8. Set Programming Mode to Off.

- a. Press    .
- b. Press key  until *Programming Mode Off* is displayed.
- c. Press the YES key  .
- d. When the *Enter Code* displays, press the factory default   or the user password keys and . The programming mode LED should now be off.

9. Place the controller master switch to the OFF/ RESET position.
10. Disconnect the battery negative (-) lead to power down the generator set.
11. After 2-3 minutes, reconnect the battery negative (-) lead.
12. Reset the controller clock. See Menu 6—Time and Date.

8.1.6 Idle (Speed) Mode Feature

The idle (speed) mode feature provides the ability to start and run the engine at idle (reduced) speed for a selectable time period (0–10 minutes) during warm-up. The controller will override the idle speed mode if the engine reaches the preprogrammed engine warmed-up temperature before the idle mode times out. See Figure 8-9 for user-supplied switch connection.




Figure 8-9 Idle (Speed) Mode Switch

8.1.7 Low Fuel (Level/Pressure) Switch

Some gaseous-fueled models offer a low fuel pressure switch. The low fuel pressure switch connects to the same terminal as the low fuel *level* switch on diesel- or gasoline-fueled models. See Figure 8-10 and Figure 8-11. See Section 8.2, Accessory Connections, for terminal identification.

Note: The main tank or the transfer/day tank includes the low fuel level switch. The fuel tank supplier typically provides the low fuel level switch.




Figure 8-10 Low Fuel Switch (Level or Pressure)

Switch Rating	12 volts DC minimum, 0.5 amp minimum
Wiring Recommendation	
Gauge	mm (ft.)
18-20	30.5 (100)
14	153 (500)
10	305 (1000)

Figure 8-11 Switch Rating & Wiring Recommendation

8.1.8 Prime Power Switch Kit

The prime power switch kit prevents battery drain during generator set nonoperation periods and when the generator set battery cannot be maintained by an AC battery charger. See Figure 8-12 for an illustration of the kit and Figure 8-13 for the electrical connections.




Figure 8-12 Prime Power Switch Installation Location




Figure 8-13 Prime Power Switch Connections

Stop the generator set using the stopping procedures in the respective operation manual before placing the generator set in the prime power mode. Move the prime power switch located on the back of the controller to the *DOWN* position. The controller including the digital display, LEDs, and alarm horn does not function when the generator set is in the prime power mode.

Move the prime power switch located on the back of the controller to the *UP* position and reset the controller time and date before attempting to start the generator set.

8.1.9 Remote Emergency Stop Kit

The emergency stop kit allows immediate shutdown of the generator set from a remote location. See Figure 8-14 and Figure 8-15. If the emergency stop switch activates, the EMERGENCY STOP lamp lights and the unit shuts down. Before attempting to restart the generator set, reset the emergency stop switch (by replacing the glass piece) and reset the generator set by placing the master switch in the OFF/RESET position.

Use the single glass piece located inside the switch for replacement and order additional glass pieces as service parts. See the respective operation manual for the Emergency Stop Switch Reset Procedure. See Section 8.2, Accessory Connections, for terminal identifications.




Figure 8-14 Emergency Stop Kit




Figure 8-15 Remote Emergency Stop Kit Connections

8.1.10 Remote Reset Feature

The remote reset switch provides generator set resetting after a fault shutdown at a remote location. See Figure 8-16 and Figure 8-17 for user-supplied switch connection.

Press and hold the switch for 2-3 seconds and release to reset the generator set controller.




Figure 8-16 Remote Reset Switch Connections

Switch Rating	12 volts DC minimum, 1 amp minimum
Wiring Recommendation	
Gauge	mm (ft.)
18-20	30.5 (100)
14	153 (500)
10	305 (1000)

Figure 8-17 Switch Rating and Wiring Recommendations

8.1.11 Remote Serial Annunciator (RSA III)

Adapted from Instruction TT-1625 9/14b.

The following information summarizes the setup items when installing the remote serial annunciator. Refer to the RSA installation instructions TT-1625 for operation and function.

RSA III Features and Connections

RSA III is an annunciator panel offered in several kit configurations to support Kohler power equipment. The RSA III is a remote serial annunciator that monitors the condition of the generator set and/or ATS from a remote location. The RSA III alerts the operator through visual and audible signals using LED indication and a horn. An alarm silence and lamp test switch are included.

An RSA III annunciator can be used for a single generator set (Figure 8-18) or with a combination of a generator set and automatic transfer switch(es) (Figure 8-19 or Figure 8-20). In systems using more than a single RSA III, one must be designated as the master device to broadcast to additional RSA III annunciators, designated as slave devices. Up to five RSA III slave devices can be used with an RSA III master device. All RSA III annunciators are factory set as the master device, but can be changed to a slave device using a PC and SiteTech™ software that connects to the RSA III front panel via a universal serial bus (USB) connection.

The RSA II can be connected with the RSA III provided that the master remote annunciator is an RSA III.

The RSA III meets NFPA 110, Level 1 (2005) applications that require remote controls and alarms be powered by a storage battery such as the engine starting battery. AC adaptor kit GM62466-KP1 is available when NFPA is not required.

See Section 8.2, Accessory Connections, for terminal identifications.

A PC with SiteTech™ software is required to make the RSA III functional. Use your SecurID to access KOHLERnet, click on the TechTools button, and follow the instructions to download the files. See SiteTech™ Software Settings and refer to TP-6701 SiteTech™ Software Operation Manual for more information.

If a fault occurs, the RSA III horn activates and the corresponding LED illuminates. The following paragraphs describe specific features of the RSA III.

If the RSA III is used with an Ethernet communication network, order Modbus® Ethernet converter GM41143-KP2 and refer to TT-1405 Converters,

Modbus® is a registered trademark of Schneider Electric.

Connections, and Controller Setup for Network Communication for system installation.




Figure 8-18 Remote Serial Annunciator (RSA III)




Figure 8-19 RSA III with Single ATS Control




Figure 8-20 RSA III with Four ATS Controls

If there is only one RSA III, it is the master. If several RSA III are installed, choose either the RSA III closest to the generator set or determine which RSA III is more practical for use as a master and use a daisy chain wiring configuration for the remaining RSAs. The RSA III connected to the controller **MUST** be assigned as the RSA III master.

Note: When an RSA III is installed into a system with existing older RSAs, the RSA III must be configured as the master.

Note: Should any communication issues occur when adding RSA III slaves and/or transfer switches to the system, be sure to power down the RSA III master and then power up the RSA III master so that the RSA III master can recognize the changes.

Use the SiteTech™ software to select either that the generator set controller activates EPS Supplying Load LED or the transfer switch activates LED or local EPS supplying load.

Use the SiteTech™ software to select the high speed mode for direct connection to the DEC 550 controller. Select lower speed for network connection with the Modbus®/ Ethernet converter. The lower speed allows network functionality reducing loss of communication faults.

Terminating Resistor and Wiring

For communication between the controller and RSA III master, see Figure 8-21. For communication between RSA III Master and RSA III Slave, see Figure 8-22. Place the terminating resistor on the last RSA III slave in the daisy chain connection.

Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.

P27 RS-485 Connections (from Controller to Master)	
P27-1	(-) Black (from controller)
P27-2	(+) White (from controller)
P27-3	Shield (from controller)
P27-4	(-) Black (to slave or terminating resistor)
P27-5	(+) White (to slave or terminating resistor)
P27-6	Shield (to slave or open)
Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.	

Figure 8-21 P27 Connector on Master RSA III

Communication between RSA III Master and RSA III Slave. Select and connect the RS-485 wiring from the RSA III master to the RSA III slave(s) in a daisy chain wiring configuration using Belden #9841 or equivalent. Figure 8-22 shows the master/slave RS-485 connections and Figure 8-23 shows the RSA III with P27 location.

P27 RS-485 Connections (from Master to Slave)	
P27-1	(-) Black (from master or previous slave)
P27-2	(+) White (from master or previous slave)
P27-3	Shield (from master or previous slave)
P27-4	(-) Black (to next slave or terminating resistor)
P27-5	(+) White (to next slave or terminating resistor)
P27-6	Shield (to next slave or open)
Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.	

Figure 8-22 P27 Connection on RSA III Slave




Figure 8-23 RSA III Circuit Board GM86125 Connectors

8.1.12 Shunt-Trip Line Circuit Breaker

A shunt-trip line circuit breaker provides a 12- or 24-DC volt solenoid within the line circuit breaker case that can energize the trip mechanism. This feature allows the circuit breaker to be tripped by a customer-selected fault such as alternator overload, overspeed, overvoltage, or defined common fault. Connection requires a shunt-trip wiring kit and a dry contact kit. See Figure 8-24.




Figure 8-24 Shunt-Trip Line Circuit Breaker and Shunt-Trip Wiring Kit Connections

8.1.13 Single-Relay Dry Contact Kit

The single-relay dry contact kit provides normally open and normally closed contacts in a form C configuration to activate warning devices and other user- provided accessories allowing remote monitoring of the generator set. Typically, lamps, audible alarms, or other devices signal faults or status conditions. Connect any controller fault output to the single-relay dry contact kit.

A total of three dry contact kits may connect to a single controller output. See Figure 8-25 and Figure 8-26. See Section 8.2, Accessory Connections, for terminal identifications.




Figure 8-25 Single-Relay Dry Contact Kit, Typical





Figure 8-26 Single-Relay Dry Contact Kit Connections

8.1.14 Ten-Relay Dry Contact Kit

The ten-relay dry contact kit provides normally open and normally closed contacts in a form C configuration to activate warning devices and other user-provided accessories allowing remote monitoring of the generator set. Connect any controller fault output to the


ten-relay dry contact kit. Typically, lamps, audible alarms, or other devices signal the fault conditions.

Refer to Figure 8-27 for an internal view of the contact kit. See Figure 8-28 for electrical connections. See Section 8.2, Accessory Connections, for terminal identifications.



A-273936

Figure 8-27 Ten-Relay Dry Contact Kit



GM13984-/354246B-

Figure 8-28 Ten-Relay Dry Contact Kit Connections

8.1.15 Twenty-Relay Dry Contact Kit

The twenty-relay dry contact kit provides normally open and normally closed contacts in a form C configuration to activate warning devices and other user-provided accessories allowing remote monitoring of the generator set. Typically, lamps, audible alarms, or other devices signal faults or status conditions. Connect any generator set fault output to the dry contact kit.

Refer to Figure 8-29 for an internal view of the contact kit. See Figure 8-30 for electrical connections. See Section 8.2, Accessory Connections, for terminal identifications.




Figure 8-29 Twenty-Relay Dry Contact Kits




Figure 8-30 Twenty-Relay Dry Contact Relay Kit Connections

8.2 Accessory Connections

The 550 controller contains circuit boards equipped with terminal strip(s) for use in connecting a controller connection kit. Do not connect accessories directly to the controller terminal strip(s). Connect accessories to either a controller connection kit or a dry contact kit. Connect the dry contact kit(s) to the controller connection kit. Connect alarms, battery chargers, remote switches, and other accessories to the dry contact kit relay(s).

For specific information on accessory connections, refer to the accessory wiring diagrams in the wiring diagram manual and the instruction sheet accompanying the kit. See Figure 8-31 and Figure 8-32 for controller interconnection circuit board connections. See Figure 8-33 and Figure 8-34 for controller (customer) connection kit connections. See NO TAG, NO TAG, and Appendix G Wiring Diagrams for accessory connection wiring diagrams.




Figure 8-31 Terminal Strips on Controller Interconnection Circuit Board (Controller Back Panel Folded Down)

TB1 Terminal Strip—Engine Start and Emergency Stop Connections**Term. Description**

1	Emergency stop ground
1A	Emergency stop
3	Remote start
4	Remote start

TB2 Terminal Strip—Analog Input Connections**Term. Description**

1	ACH1 (CTS) Signal (non-ECM including Waukesha)
2	ACH1 (CTS) Supply (non-ECM including Waukesha)
3	ACH2 (OPS) Signal (non-ECM including Waukesha)
4	ACH2 (OPS) Supply (non-ECM including Waukesha)
5	ACH3 Signal (air intake temp. for Waukesha)
6	ACH3 Supply (air intake temp. for Waukesha)
7	ACH4 Signal (oil temp. for Waukesha)
8	ACH4 Supply (oil temp. for Waukesha)
9	ACH5 Signal
10	ACH5 Supply
11	ACH6 Signal
12	ACH6 Supply (VSG for Volvo, GM, Doosan)
13	ACH7 Signal (optional analog voltage adjust signal)
14	ACH7 Supply
15	N/C
16	ACH1 (CTS) Return (non-ECM)
17	ACH1 (CTS) Shield ground (non-ECM)
18	ACH2 (OPS or OPS2) Return (non-ECM)
19	ACH2 (OPS) Shield ground (non-ECM)
20	ACH3 (IAT or OPS1) Return
21	ACH3 Shield ground
22	ACH4 (Oil Temp) Return
23	ACH4 Shield ground
24	ACH5 Return
25	ACH5 Shield ground
26	ACH6 Return
27	ACH6 Shield ground
28	ACH7 Return
29	ACH7 Shield ground
30	N/C

TB3 Terminal Strip—Accessory Power Output Connections**Term. Description**


1	+12 VDC (OEM use only)
2	+12 VDC (OEM use only)
3	+12 VDC (OEM use only)
4	Fused battery (+) (42A) (5 amp)
5	Fused battery (+) (42A) (5 amp)
6	Fused battery (+) (42A) (5 amp)
7	Battery (-)
8	Battery (-)
9	Battery (-)
10	Battery (-)
11	Battery (-)
12	Panel lamp output

TB4 Terminal Strip—Input Factory Connections**Term. Description**

1	DCH1 Battery charger fault
2	DCH2 Low fuel
3	DCH3 Low coolant temp. with ECM models or warning default with non-ECM models
4	DCH4 Field overvoltage with M4/M5/M7 alternators or warning default with non-M4/M5/M7 alternators
5	DCH5 Breaker Closed, Paralleling Applications
6	DCH6 Enable Synch, Paralleling Applications
7	DCH7 Warning
8	DCH8 Warning
9	DCH9 Warning
10	DCH10 Warning
11	DCH11 AFM Shutdown, Waukesha engine
12	DCH12 Detonation Warning, Waukesha engine
13	DCH13 Detonation Shutdown, Waukesha engine
14	DCH14 Warning
15	DCH15 Remote shutdown
16	DCH16 Remote reset
17	DCH17 VAR PF mode
18	DCH18 Voltage lower
19	DCH19 Voltage raise
20	DCH20 Air damper
21	DCH21 Idle mode functional with ECM-equipped engines only
22	DCH1 Return
23	DCH2 Return
24	DCH3 Return
25	DCH4 Return
26	DCH5 Return
27	DCH6 Return
28	DCH7 Return
29	DCH8 Return
30	DCH9 Return
31	DCH10 Return
32	DCH11 Return
33	DCH12 Return
34	DCH13 Return
35	DCH14 Return
36	DCH15 Return
37	DCH16 Return
38	DCH17 Return
39	DCH18 Return
40	DCH19 Return
41	DCH20 Return
42	DCH21 Return

Note: TB4-1 through TB4-21 are user definable with factory defaults listed. Terminals TB4-3, TB4-4, TB4-14, and TB4-21 have different functions depending upon the generator set configuration. See comments above. See Menu 9—Input Setup for changing inputs.

Figure 8-32 Controller Terminal Strip Identification



GM13984-

Figure 8-33 Terminal Strips TB6, TB7, TB8, and TB9 on the Controller Connection Kit in the Junction Box

TB6 Terminal Strip—RDOs 1-7

Term.	Description
42A	Battery (+)
GND	Battery (-)
N/C	
RDO1	Overspeed (lead 39)
RDO2	Overcrank (lead 12)
RDO3	High coolant temperature shutdown (lead 36)
RDO4	Low oil pressure shutdown (lead 38)
RDO5	Low coolant temperature (lead 35)
RDO6	High coolant temperature warning (lead 40)
RDO7	Low oil pressure warning (lead 41)

TB7 Terminal Strip—RDOs 8-17

Term.	Description
RDO8	Low fuel (lead 63)
RDO9	Master switch not in auto (lead 80)
RDO10	NFPA 110 common alarm (lead 32)*
RDO11	Battery charger fault (lead 61)
RDO12	Low battery voltage (lead 62)
RDO13	High battery voltage
RDO14	Emergency stop (lead 48)
RDO15	Generator set running (lead 70R)
RDO16	Time delay engine cooldown (TDEC) (lead 70C)
RDO17	System ready (lead 60)

TB8 Terminal Strip—RDOs 18-23

Term.	Description
42A	Battery (+)
42A	Battery (+)
GND	Battery (-)
GND	Battery (-)
RDO18	Defined common fault (lead 32A)
RDO19	Low coolant level
RDO20	Overvoltage (lead 26)
RDO21	Idle mode
RDO22	EPS supplying load
RDO23	Air damper indicator (lead 56)

TB9 Terminal Strip—RDOs 24-31

Term.	Description
RDO24	Speed sensor fault
RDO25	Loss of AC sensing
RDO26	ECM loss of communication
RDO27	Undervoltage
RDO28	Overfrequency
RDO29	Underfrequency
RDO30	Load shed kW overload
RDO31	Load shed underfrequency
3	Remote start
4	Remote start

Note:Lead numbers shown in parentheses are the factory default wire designations.

Note:RDO-1 though RDO-31 are user definable with the following factory defaults: emergency stop, high coolant temperature, low oil pressure, overcrank, and overspeed

*NFPA-110 common alarm faults include:

Air damper indicator (RDO-23)
 Battery charger fault (RDO-11)
 EPS supplying load (RDO-22)
 High battery voltage (RDO-13)
 High coolant temperature warning (RDO-06)
 High coolant temperature shutdown (RDO-03)
 Low battery voltage (RDO-012)
 Low coolant level (RDO-19)
 Low coolant temperature warning (RDO-05)
 Low fuel (level or pressure) (RDO-08)
 Low oil pressure warning (RDO-07)
 Low oil pressure shutdown (RDO-04)
 Master switch not in auto (RDO-09)
 Overcrank (RDO-02)
 Overspeed (RDO-01)

Figure 8-34 Controller (Customer) Connection Kit Terminal Strip Identification with Relay Driver Outputs (RDOs)

Notes

Section 9 Decision-Maker® 3000 Controller Accessories

9.1 Accessories and Connections

Several accessories help finalize installation, add convenience to operation and service, and establish state and local code compliance.

Accessories vary with each generator set model and controller. Select factory-installed and/or shipped-loose accessories. See Figure 9-1 for a list of available kits. Obtain the most current accessory information from your local authorized service distributor/dealer.

This section illustrates several accessories available at print time of this publication. Accessory kits generally include installation instructions. See wiring diagrams manual for electrical connections not shown in this section. See the installation instructions and drawings supplied with kit for information on kit mounting location.

The instructions provided with the accessory kit supersede these instructions where there are differences. In general, run AC and DC wiring in separate conduit. Use shielded cable for all analog inputs. Observe all applicable national, state, and local electrical codes during accessory installation.

See Section 9.2, Accessory Connections, for terminal identification.

Kit Description
Common Fault/Failure (32A) Connections
Float/Equalize Battery Charger (with alarms)
Input/Output Module Board
Low Fuel (Level) Switch
Low Fuel (Pressure) Switch
Prime Power Switch
Remote Emergency Stop
Remote Reset Feature
Remote Serial Annunciator (RSA III)
Shunt-Trip Line Circuit Breaker

Figure 9-1 Optional Accessories

9.1.1 Common Fault/Failure (32A) Relay

The common fault relay is standard on the controller circuit board and located at the TB2 terminal strip connections. Contacts are rated at 2 amps at 32 VDC or 0.5 amps at 120 VAC max. See Figure 9-2 and Figure 9-3.

The optional common fault relay shown in Figure 9-3 as DCB2 has contacts rated at 10 amps at 28 VDC or 120 VAC and can be connected to user-supplied accessories.

The optional common fault relay shown in Figure 9-3 as DCB1 has contacts rated at 10 amps at 28 VDC or 120 VAC and is used to trigger the shunt-trip line circuit breaker kit (mentioned later in this section).




Figure 9-2 Common Fault Relay Wiring (Standard)




Figure 9-3 Common Fault Relay Kit and Shunt-Trip Relay Kit Wiring

9.1.2 Float/Equalize Battery Charger Kit with Alarm Option

The float/equalize battery charger with alarm option provides battery charging to the engine starting battery(ies) and connects to the controller for fault detection. Battery chargers for 12- or 24-volt models are available as a generator set accessory. See Figure 9-4 and Figure 9-5 for battery connections.




Figure 9-4 Float/Equalize Battery Charger Connections




Figure 9-5 Battery Charger to Controller Connections

9.1.3 Input/Output (I/O) Module Board

The I/O module board provides a generator set mounted panel with two analog or digital inputs and five digital outputs. See Figure 9-6 for circuit board components and electrical connections to the controller. See Figure 9-7 for connections of analog inputs. Refer to Figure 9-27 for accessory connections.

See Section 9.2, Accessory Connections, for terminal identification.




Figure 9-6 Input/Output (I/O) Module Board Kit




Figure 9-7 Analog Input Connections P28

9.1.4 Low Fuel (Level/Pressure) Switch

Some gas-fueled models offer a low fuel pressure switch. The low fuel pressure switch connects to the same controller terminal as the low fuel *level* switch on diesel-fueled models. See Figure 9-8, Figure 9-9, and Figure 9-10.

Note: The main tank or the transfer/day tank includes the low fuel level switch. The fuel tank supplier typically provides the low fuel level switch.




Figure 9-8 Low Fuel Switch (Level or Pressure)




Figure 9-9 Low Fuel Switch Connection to Controller Connection

Switch Rating	12 volts DC minimum, 0.5 amp minimum
Wiring Recommendation	
Gauge	mm (ft.)
18-20	30.5 (100)
14	153 (500)
10	305 (1000)

Figure 9-10 Switch Rating & Wiring Recommendation

9.1.5 Prime Power Switch Kit

The prime power switch kit prevents battery drain during generator set non-operation periods and when the generator set battery cannot be maintained by an AC battery charger. See Figure 9-11 for an illustration of the kit and Figure 9-12 for the electrical connections.

Stop the generator set using the stopping procedures in respective operation manual before placing the generator set in the prime power mode. Move the prime power switch located on the junction box to the *DOWN* position. The controller including the digital display, LEDs, and alarm horn does not function when the generator set is in the prime power mode.

Move the prime power switch located on the junction box to the *UP* position. The generator set is now ready for starting.




Figure 9-11 Prime Power Switch




Figure 9-12 Prime Power Switch Connections

9.1.6 Remote Emergency Stop Kit

The emergency stop kit allows immediate shutdown of the generator set from a remote location. See Figure 9-13 and Figure 9-14. If the emergency stop switch activates, the EMERGENCY STOP lamp lights and the unit shuts down. Before attempting to restart the generator set, reset the emergency stop switch (by replacing the glass piece) and reset the generator set by pressing the master control switch OFF/RESET button.

Use the single glass piece located inside the switch for replacement and order additional glass pieces as service parts. See the respective operation manual for Emergency Stop Switch Resetting.

See Section 9.2, Accessory Connections, for terminal identifications.




Figure 9-13 Emergency Stop Kit




Figure 9-14 Remote Emergency Stop Kit Connections

9.1.7 Remote Reset Feature

The remote reset switch provides generator set controller resetting after a fault shutdown at a remote location. See Figure 9-15 and Figure 9-16 for user-supplied switch connection.

Press and hold the switch for 2-3 seconds and release to reset the generator set controller.

See Section 9.2, Accessory Connections, for terminal identifications.




Figure 9-15 Remote Reset Switch Connections

Switch Rating	12 volts DC minimum, 1 amp minimum
Wiring Recommendation	
Gauge	m (ft.)
18-20	30.5 (100)
14	153 (500)
10	305 (1000)

Figure 9-16 Switch Rating and Wiring Recommendations

9.1.8 Remote Serial Annunciator (RSA III)

Adapted from Instruction TT-1625 9/14.

The following information summarizes the setup items when installing the remote serial annunciator. Refer to the RSA installation instructions TT-1625 for operation and function.

RSA III Features and Connections

RSA III is an annunciator panel offered in several kit configurations to support Kohler power equipment. The RSA III is a remote serial annunciator that monitors the condition of the generator set and/or ATS from a remote location. The RSA III alerts the operator through visual and audible signals using LED indication and a horn. An alarm silence and lamp test switch are included.

An RSA III annunciator can be used for a single generator set (Figure 9-17) or with a combination of a generator set and automatic transfer switch(es) (Figure 9-18 or Figure 9-19). In systems using more than a single RSA III, one must be designated as the master device to broadcast to additional RSA III annunciators, designated as slave devices. Up to five RSA III slave devices can be used with an RSA III master device. All RSA III annunciators are factory set as the master device, but can be changed to a slave device using a PC and SiteTech™ software that connects to the RSA III front panel via a universal serial bus (USB) connection.

The RSA II can be connected with the RSA III provided that the master remote annunciator is an RSA III.

The RSA III meets NFPA 110, Level 1 (2005) applications that require remote controls and alarms be powered by a storage battery such as the engine starting battery. AC adaptor kit GM62466-KP1 is available when NFPA is not required.

See Section 9.2, Accessory Connections, for terminal identifications.

A PC with SiteTech™ software is required to make the RSA III functional. Use your SecurID to access KOHLERnet, click on the TechTools button, and follow the instructions to download the files. See SiteTech™ Software Settings and refer to TP-6701 SiteTech™ Software Operation Manual for more information.

If a fault occurs, the RSA III horn activates and the corresponding LED illuminates. The following paragraphs describe specific features of the RSA III.

If the RSA III is used with an Ethernet communication network, order Modbus® Ethernet converter GM41143-KP2 and refer to TT-1405 Converters,

Modbus® is a registered trademark of Schneider Electric.

Connections, and Controller Setup for Network Communication for system installation.




Figure 9-17 Remote Serial Annunciator (RSA III)




Figure 9-18 RSA III with Single ATS Control




Figure 9-19 RSA III with Four ATS Controls

If there is only one RSA III, it is the master. If several RSA III are installed, choose either the RSA III closest to the generator set or determine which RSA III is more practical for use as a master and use a daisy chain wiring configuration for the remaining RSAs. The RSA III connected to the controller **MUST** be assigned as the RSA III master.

Note: When an RSA III is installed into a system with existing older RSAs, the RSA III must be configured as the master.

Note: Should any communication issues occur when adding RSA III slaves and/or transfer switches to the system, be sure to power down the RSA III master and then power up the RSA III master so that the RSA III master can recognize the changes.

Use the SiteTech™ software to select either that the generator set controller activates EPS Supplying Load LED or the transfer switch activates LED or local EPS supplying load.

Use the SiteTech™ software to select the high speed mode for direct connection to the DEC 3000 controller. Select lower speed for network connection with the Modbus®/Ethernet converter. The lower speed allows network functionality reducing loss of communication faults.

Terminating Resistor and Wiring

For communication between the controller and RSA III master, see Figure 9-20. For communication between RSA III Master and RSA III Slave, see Figure 9-21. Place the terminating resistor on the last RSA III slave in the daisy chain connection.

Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.

P27 RS-485 Connections (from Controller to Master)	
P27-1	(-) Black (from controller)
P27-2	(+) White (from controller)
P27-3	Shield (from controller)
P27-4	(-) Black (to slave or terminating resistor)
P27-5	(+) White (to slave or terminating resistor)
P27-6	Shield (to slave or open)
Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.	

Figure 9-20 P27 Connector on Master RSA III

Communication between RSA III Master and RSA III Slave. Select and connect the RS-485 wiring from the RSA III master to the RSA III slave(s) in a daisy chain wiring configuration using Belden #9841 or equivalent. Figure 9-21 shows the master/slave RS-485 connections and Figure 9-22 shows the RSA III with P27 location.

P27 RS-485 Connections (from Master to Slave)	
P27-1	(-) Black (from master or previous slave)
P27-2	(+) White (from master or previous slave)
P27-3	Shield (from master or previous slave)
P27-4	(-) Black (to next slave or terminating resistor)
P27-5	(+) White (to next slave or terminating resistor)
P27-6	Shield (to next slave or open)
Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.	

Figure 9-21 P27 Connection on RSA III Slave




Figure 9-22 RSA III Circuit Board GM86125 Connectors

9.1.9 Shunt-Trip Line Circuit Breaker

A shunt-trip line circuit breaker provides a 12- or 24-DC volt solenoid within the line circuit breaker case that can energize the trip mechanism. This feature allows the circuit breaker to be tripped by the common fault (32A). Connection requires a shunt-trip wiring kit and a dry contact kit. See Figure 9-23 and Figure 9-24.

The optional common fault relay shown in Figure 9-24 as DCB1 has contacts rated at 10 amps at 28 VDC or 120 VAC and is used to trigger the shunt-trip line circuit breaker kit.




Figure 9-23 Shunt-Trip Wiring (Standard)




Figure 9-24 Shunt-Trip Relay Kit and Line Circuit Breaker Wiring (Shown with Common Fault/Failure Relay Kit)

9.2 Accessory Connections

The controller contains a circuit board equipped with terminal strip(s) for use in connecting external optional accessories including alarms, battery chargers, and remote switches. The optional I/O board provides an additional two analog or digital inputs and five digital outputs.

For specific information on accessory connections, refer to the accessory wiring diagrams in the wiring diagram manual and the instruction sheet accompanying the kit. See Figure 9-25, Figure 9-26, and NO TAG for controller circuit board connections.




Figure 9-25 Controller Circuit Board Connections

TB1 Terminal Strip		
Analog and Digital Input Connections		
Terminal	Description	Connection
TB1-DI 1	DCH1	No Function
TB1-DI 2	DCH2	Aux. Warning Switch
TB1-DI 3	DCH3	Battery Charger Fault
TB1-AI 1	ACH1	No Function
TB1-AI 2	ACH2	No Function
TB1-GND	Ground	Common A/D Ground
TB2 Terminal Strip		
KI Relay Outputs		
Terminal	Description	Connection
TB2-COM	Common	User-Defined
TB2-COM	Common	Common Fault (2)
TB2-NO	Normally Open	Common Fault (32A)
TB2-NC	Normally Closed	User-Defined
TB3 Terminal Strip		
Accessory Power Output Connections		
Terminal	Description	Connection
TB3-1	E-Stop	E-Stop Ground
TB3-1A	E-Stop	E-Stop
TB3-3	Remote Start	Remote Start
TB3-4	Remote Start	Remote Start
TB3-AUX	Auxiliary	Aux. Shutdown Sw.
TB3-AUXR	Auxiliary-R	Aux. Shutdown Sw.

P1 24-Pin Connector		
Engine Wiring Harness		
Terminal	Description	Connection
P1-12	14P +12VDC	Prime Power Switch
P21 6-Pin Connector		
RS-485 (RSA II)		
Terminal	Description	Connection
P21-1	GND	Shield
P21-2	(+)	Red
P21-3	(-)	Black
P21-4	GND	Shield
P21-5	(+)	Red
P21-6	(-)	Black
TB1 Terminal Strip Designations		
Analog and Digital Input Connections		
Terminals on Board	Controller Designation	SiteTech Designation
TB1-DI 1	DIn A1	A1
TB1-DI 2	DIn A2	A2
TB1-DI 3	DIn A3	A3
TB1-AI 1	AIn A1	—
TB1-AI 2	AIn A2	A1
TB1-GND	—	—

Figure 9-26 Controller Connections

P25 Connector	
RJ45 Remote I/O In	
Connects to DEC 3000 P23	
P26 Connector	
RJ45 Remote I/O Out	
Open	
P27 Connector	
CAN Terminator	
Place the P27 jumper on the IN pins	
P28 Connector	
Single-Ended (0-5 V) Analog Input Connections	
Terminal	Description
P28-GND	AGND Analog Return
P28-VN1	NO Connection
P28-VP1	ACH1 Signal
P28-+5V	Supply (.05 amp max.)
P28-GND	AGND Analog Return
P28-VN2	NO Connection
P28-VP2	ACH2 Signal
P28-+5V	Supply (0.05 amp max.)
P28 Connector	
Differential (+/-3 V) Analog Input Connections	
Terminal	Description
P28-GND	AGND Analog Reference
P28-VN1	ACH1 Negative Differential Signal
P28-VP1	ACH1 Positive Differential Signal
P28-+5V	Supply (.05 amp max.)
P28-GND	AGND Analog Reference
P28-VN2	ACH2 Negative Differential Signal
P28-VP2	ACH2 Positive Differential Signal
P28-+5V	Supply (0.05 amp max.)
P29 Connector	
2 Amp. K1 Relay Output (2.1) Connections	
Terminal	Description
P29-NC	Normally Closed
P29-COM	Common
P29-NO	Normally Open

P30 Connector	
2 Amp. K2 Relay Output (2.2) Connections	
Terminal	Description
P30-NC	Normally Closed
P30-COM	Common
P30-NO	Normally Open
P31 Connector	
2 Amp. K3 Relay Output (2.3) Connections	
Terminal	Description
P31-NC	Normally Closed
P31-COM	Common
P31-NO	Normally Open
P32 Connector	
10 Amp. K4 Relay Output (2.4) Connections	
Terminal	Description
P32-NC	Normally Closed
P32-COM	Common
P32-NO	Normally Open
10 Amp. K5 Relay Output (2.5) Connections	
Terminal	Description
P32-NC	Normally Closed
P32-COM	Common
P32-NO	Normally Open

P28 Connector Designations		
Terminals on Board	Controller Designation	SiteTech Designation
P28-GND	DIn B1	B1
P28-VN1		
P28-VP1		
P28-+5V	Din B2	B2
P28-GND		
P28-VN2		
P28-VP2		
P28-+5V		

Figure 9-27 Input/Output Module Board Connections

Notes

Section 10 Decision-Maker® 3500 Controller Accessories

10.1 Accessories and Connections

Several accessories help finalize installation, add convenience to operation and service, and establish state and local code compliance.

Accessories vary with each generator set model and controller. Select factory-installed and/or shipped-loose accessories. See Figure 7-8 for a list of available kits. Obtain the most current accessory information from your local authorized service distributor/dealer.

This section illustrates several accessories available at print time of this publication. Accessory kits generally include installation instructions. See wiring diagrams manual for electrical connections not shown in this section. See the installation instructions and drawings supplied with kit for information on kit mounting location.

The instructions provided with the accessory kit supersede these instructions where there are differences. In general, run AC and DC wiring in separate conduit. Use shielded cable for all analog inputs. Observe all applicable national, state, and local electrical codes during accessory installation.

See Section 8.2, Accessory Connections, for terminal identification.

Kit Description

Fifteen-Relay Dry Contact
Remote Emergency Stop
Remote Serial Annunciator (RSA III)

Figure 10-1 Optional Accessories

10.1.1 Fifteen-Relay Dry Contact

The 15-relay dry contact board has four digital inputs and two analog inputs. There are 14 individual relay driver outputs (RDOs) with one common fault RDO.

See Figure 9-6 for circuit board components and electrical connections to the controller. See Figure 9-7 for connections of analog inputs.

See Section 8.2, Accessory Connections, for terminal identification.

The normally open (NO) relay contacts are rated:

- 10 amp @ 120 VAC
- 10 amp @ 28 VDC (max.)
- 0.01 amp @ 28 VDC (min.)




Figure 10-2 15-Relay Dry Contact Board




Figure 10-3 Analog Input Connections P36

10.1.2 Remote Emergency Stop Kit

The emergency stop (E-stop) kit allows immediate shutdown of the generator set from a remote location. See Figure 8-15. If the emergency stop switch activates, the EMERGENCY STOP lamp lights and the unit shuts down. Before attempting to restart the generator set, reset the emergency stop switch (by replacing the glass piece) and reset the generator set by pressing the master control switch OFF/RESET button.

Use the single glass piece located inside the switch for replacement and order additional glass pieces as service parts. See the respective operation manual for the Emergency Stop Switch Reset Procedure.

See Section 10.2, Accessory Connections, for terminal identifications.




Figure 10-4 Remote E-Stop Kit Connections

10.1.3 Remote Serial Annunciator (RSA III)

Adapted from Instruction TT-1625 9/14b.

The following information summarizes the setup items when installing the remote serial annunciator. Refer to the RSA installation instructions TT-1625 for operation and function.

RSA III Features and Connections

RSA III is an annunciator panel offered in several kit configurations to support Kohler power equipment. The RSA III is a remote serial annunciator (Figure 10-5, Figure 10-6, and Figure 10-7) that monitors the condition of the generator set and/or ATS from a remote location. The RSA III alerts the operator through visual and audible signals using LED indication and a horn. An alarm silence and lamp test switch are included.

An RSA III annunciator can be used for a single generator set or with a combination of a generator set and automatic transfer switch. In systems using more than a single RSA III, one must be designated as the master device to broadcast to additional RSA III annunciators, designated as slave devices. Up to five RSA III slave devices can be used with an RSA III master device. All RSA III annunciators are factory set as the master device, but can be changed to a slave device using a PC and SiteTech™ software that connects to the RSA III front panel via a universal serial bus (USB) connection.

The RSA II can be connected with the RSA III provided that the master remote annunciator is an RSA III.

The RSA III meets NFPA 110, Level 1 (2005) applications that require remote controls and alarms be powered by a storage battery such as the engine starting battery. AC adaptor kit GM62466-KP1 is available when NFPA is not required.

See Section 10.2, Accessory Connections, for terminal identifications.

A PC with SiteTech™ software is required to make the RSA III functional. Use your SecurID to access KOHLERnet, click on the TechTools button, and follow the instructions to download the files. See SiteTech™ Software Settings and refer to TP-6701 SiteTech™ Software Operation Manual for more information.

If a fault occurs, the RSA III horn activates and the corresponding LED illuminates. The following paragraphs describe specific features of the RSA III.

If the RSA III is used with an Ethernet communication network, order Modbus® Ethernet converter GM41143-KP2 and refer to TT-1405 Converters,

Modbus® is a registered trademark of Schneider Electric.

Connections, and Controller Setup for Network Communication for system installation.




Figure 10-5 Remote Serial Annunciator (RSA III)




Figure 10-6 RSA III with Single ATS Control




Figure 10-7 RSA III with Four ATS Controls

If there is only one RSA III, it is the master. If several RSA III are installed, choose either the RSA III closest to the generator set or determine which RSA III is more practical for use as a master and use a daisy chain wiring configuration for the remaining RSAs. The RSA III connected to the controller **MUST** be assigned as the RSA III master.

Note: When an RSA III is installed into a system with existing older RSAs, the RSA III must be configured as the master.

Note: Should any communication issues occur when adding RSA III slaves and/or transfer switches to the system, be sure to power down the RSA III master and then power up the RSA III master so that the RSA III master can recognize the changes.

Use the SiteTech™ software to select either that the generator set controller activates EPS Supplying Load LED or the transfer switch activates LED or local EPS supplying load.

Use the SiteTech™ software to select the high speed mode for direct connection to the DEC 6000 controller. Select lower speed for network connection with the Modbus®/ Ethernet converter. The lower speed allows network functionality reducing loss of communication faults.

Terminating Resistor and Wiring

For communication between the controller and RSA III master, see Figure 10-8. For communication between RSA III Master and RSA III Slave, see Figure 10-9. Place the terminating resistor on the last RSA III slave in the daisy chain connection.

Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.

P27 RS-485 Connections (from Controller to Master)	
P27-1	(-) Black (from controller)
P27-2	(+) White (from controller)
P27-3	Shield (from controller)
P27-4	(-) Black (to slave or terminating resistor)
P27-5	(+) White (to slave or terminating resistor)
P27-6	Shield (to slave or open)
Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.	

Figure 10-8 P27 Connector on Master RSA III

Communication between RSA III Master and RSA III Slave. Select and connect the RS-485 wiring from the RSA III master to the RSA III slave(s) in a daisy chain wiring configuration using Belden #9841 or equivalent. Figure 10-9 shows the master/slave RS-485 connections and Figure 10-10 shows the RSA III with P27 location.

P27 RS-485 Connections (from Master to Slave)	
P27-1	(-) Black (from master or previous slave)
P27-2	(+) White (from master or previous slave)
P27-3	Shield (from master or previous slave)
P27-4	(-) Black (to next slave or terminating resistor)
P27-5	(+) White (to next slave or terminating resistor)
P27-6	Shield (to next slave or open)
Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.	

Figure 10-9 P27 Connection on RSA III Slave




Figure 10-10 RSA III Circuit Board GM86125 Connectors

10.2 Accessory Connections

The controller contains a circuit board equipped with connectors for use in connecting external optional accessories including alarms, battery chargers, and remote switches. The optional fifteen relay dry contact board provides an additional four digital inputs and two analog inputs.

For specific information on accessory connections, refer to the accessory wiring diagrams in the wiring diagram manual and the instruction sheet accompanying the kit.

Circuit Board Connections (see Figure 10-11)

DEC 3500 Controller Front Panel (see Figure 10-12)

Panel Power Connections (see Figure 10-13)

P1 (35-Pin) Connector for engine/generator wiring harness.

P2 (14-Pin) Connector for sensor input connections and relay driver output connections.

P3 (8-Pin) Connector for generator set output voltage connection and paralleling bus voltage sensing connections.

P4 (Ethernet) RG 45 Connector connects to a network communication line.

P7 (10-Pin) Connector for factory use only.

Mini USB Connector for connection of a PC with SiteTech™ software programming or for firmware updates.

TB10 Terminal Strip for CAN, remote emergency stop, and remote start connections.

See Figure 10-14 for controller circuit board connections. See Appendix G, Wiring Diagrams for accessory connection wiring diagrams.




Figure 10-11
Main Circuit Board Connectors (Back of DEC 3500 Controller)




Figure 10-12 DEC 3500 Controller Front Panel




Figure 10-13 TB10 Terminal Strip (located inside the Power Panel)

P1 35-Pin Connector		
Engine/Generator Wiring Harness		
Terminal	Description	Connection
P1-1	71	P31-3 (71)
P1-2	RTC	P48-23 (RTC)
P1-3	N10	P48-31 (14N1)
P1-4	3B	P7-8 (3B)
P1-5	YEL	P48-34 (YEL)
P1-6	GRN	P48-33 (GRN)
P1-7	Open	-
P1-8	Open	-
P1-9	YEL	TB10-CAN(+)
P1-10	GRN	TB10-CAN(-)
P1-11	Open	-
P1-12	Open	-
P1-13	70	P30-3 (70)
P1-14	1	ESS-1 (local E-stop)
P1-15	3	TB10-3
P1-16	IR	P7-4 (IR)
P1-17	12	P7-2 (I2)
P1-18	7	P48-22 (7)
P1-19	63	P48-21 (63)
P1-20	Open	-
P1-21	Open	-
P1-22	Open	-
P1-23	Open	-
P1-24	P2	P4B-9 (P1)
P1-25	31A	P48-15 (31A)
P1-26	1A	TB10-1A
P1-27	Open	-
P1-28	13	P7-3 (I3)
P1-29	11	P7-1 (I1)
P1-30	35A	P48-14 (35A)
P1-31	BGA	P48-31 (14N1)
P1-32	Open	-
P1-33	64	P7-11 (64)
P1-34	Open	-
P1-35	Open	-

P4 Connector	
RJ45 Ethernet	
Open	Network communications

P2 14-Pin Connector		
Analog/Digital Input and Relay Driver Output Connections		
Terminal	Description	Connection
P2-1	Open	-
P2-2	Open	-
P2-3	Open	-
P2-4	Open	-
P2-5	Open	-
P2-6	Open	-
P2-7	Open	-
P2-8	Open	-
P2-9	Open	-
P2-10	SS3	P7-7
P2-11	SS2	P7-6
P2-12	SS1	P7-5
P2-13	AHN	P4B-1
P2-14	Open	-
P3 8-Pin Connector		
Output Voltage and Paralleling Bus Voltage Sensing Connections		
Terminal	Description	Connection
P3-1	A	IS15
P3-2	B	IS16
P3-3	Open	-
P3-4	Open	-
P3-5	C	IS17
P3-6	NEU	IS18
P3-7	Open	-
P3-8	Open	-
TB10 8-Position Terminal Strip		
CAN, Remote E-Stop, and Remote Start Connections		
Terminal	Description	Connection
TB10-1	P	42A Battery (+)
TB10-2	7N	2 Battery (-)
TB10-3	CAN(+)	P1-9
TB10-4	CAN(-)	P1-10
TB10-5	1A	Remote E-stop
TB10-6	ESS	Remote E-stop
TB10-7	3	Remote start (ATS)
TB10-8	4	Remote start (ATS)

Figure 10-14 Controller Connections

Section 11 Decision-Maker® 6000 Controller Accessories

11.1 Accessories and Connections

Several accessories help finalize installation, add convenience to operation and service, and establish state and local code compliance.

Accessories vary with each generator set model and controller. Select factory-installed and/or shipped-loose accessories. See Figure 11-1 for a list of available kits. Obtain the most current accessory information from your local authorized service distributor/dealer.

This section illustrates several accessories available at print time of this publication. Accessory kits generally include installation instructions. See wiring diagrams manual for electrical connections not shown in this section. See the installation instructions and drawings supplied with kit for information on kit mounting location.

The instructions provided with the accessory kit supersede these instructions where there are differences. In general, run AC and DC wiring in separate conduit. Use shielded cable for all analog inputs. Observe all applicable national, state, and local electrical codes during accessory installation.

11.1.1 Audiovisual Alarm Kit

An audiovisual alarm warns the operator at a remote location of fault shutdowns and prealarm conditions. Audiovisual alarms include an alarm horn, an alarm silence switch, and common fault lamp. See Figure 11-2 and Figure 11-3. See Section 11.2, Accessory Connections, for terminal identification.

Note: Use the audiovisual alarm with a dry contact kit.

Kit Description
Audiovisual Alarm
Common Failure Relay (Terminal 32A)
Float/Equalize Battery Charger (with alarms)
Ground Fault Annunciation
Idle (Speed) Mode Feature
Low Fuel (Level) Switch
Low Fuel (Pressure) Switch
Prime Power Switch
Remote Emergency Stop
Remote Reset Feature
Remote Serial Annunciator (RSA III)
Shunt-Trip Line Circuit Breaker and Shunt-Trip Wiring
Single-Relay Dry Contact
Ten-Relay Dry Contact
Twenty-Relay Dry Contact

Figure 11-1 Available Accessories




Figure 11-2 Audiovisual Alarm




Figure 11-3 Audiovisual Alarm Connections

11.1.2 Common Failure Relay Kit

The common failure relay kit provides one set of contacts to trigger user-provided warning devices if a fault occurs. The common failure relay faults are user-defined. See Section 2, Operation, Menu 10—Output Setup, for status and faults available for this function.

Connect up to three common failure relay kits to the controller output. See Figure 11-4 and Figure 11-5. See Section 11.2, Accessory Connections, for terminal identification.

11.1.3 Float/Equalize Battery Charger Kit with Alarm Option

The float/equalize battery charger with alarm option provides battery charging to the engine starting battery(ies) and connects to the controller for fault detection. Battery chargers for 12- or 24-volt models are available as a generator set accessory. See Figure 11-6. See Section 11.2, Accessory Connections, for terminal identification.




Figure 11-4 Common Failure Relay Kit




Figure 11-5 Common Failure Relay Kit Connections




Figure 11-6 Float/Equalize Battery Charger Connections

11.1.4 Ground Fault Annunciation

A relay contact for customer connection indicates a ground fault condition and is part of a ground fault alarm. See Figure 11-7 for electrical connections and the following procedure for controller setup. Use the instructions with the kit when provided to install and setup this accessory.





Figure 11-7 Ground Fault Connections



Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

Ground Fault Controller Setup Procedure

1. Reconnect battery, if not already done.
2. Press the controller master switch AUTO button.
3. Press the Alarm Off key to silence the alarm horn, if necessary.
4. If the programming mode LED is not flashing, go to the step 5. If the programming mode LED is flashing, go to step 6.
5. Set Programming Mode to Local.

a. Press keys .

b. Press key until *Programming Mode-Local* is displayed.

c. Press the YES key .

d. When the *Enter Code* displays, press the factory default or the user password keys and . The programming mode LED should be flashing.

6. Set digital input #6 to ground fault.

a. Press . *Menu 9 Input Setup* should be displayed.

b. Press until *Digital Input 06 Warning* is displayed.

c. Press once to select this input.

d. Press until *Ground Fault* is displayed.

e. Press to define Digital Input #06 as ground fault. *Entry Accepted* is displayed.

f. Press to display *Digital Input #06 Inhibit Time*.

g. Press to enter the inhibit time. *Entry Accepted* is displayed and the inhibit time 0:00 is now displayed.

- h. Press  to display *Digital Input #06 Delay Tlme.*
- i. Press   to enter delay time. *Entry Accepted* is displayed. Default delay time is 5 sec.
- j. Press .

7. Verify Programming.

- a. Move handle of ground fault circuit breaker at generator set to simulate a ground fault.
- b. Verify that display shows *D06 Ground Fault*. The System Warning LED should be illuminated and the alarm horn should sound. If these indicators are not present, recheck steps 6a. through 6j.
- c. Return handle of ground fault circuit breaker to the non-ground fault position. *D06 Ground Fault* display should now be cleared.

8. Set Programming Mode to Off.

- a. Press    .
- b. Press key  until *Programming Mode Off* is displayed.
- c. Press the YES key  .
- d. When the *Enter Code* displays, press the factory default   or the user password keys and . The programming mode LED should now be off.

9. Press the controller master switch OFF button.
10. Disconnect the battery negative (-) lead to power down the generator set.
11. After 2-3 minutes, reconnect the battery negative (-) lead.
12. Reset the controller clock. See Menu 6—Time and Date.

11.1.5 Idle (Speed) Mode Feature

The idle (speed) mode feature provides the ability to start and run the engine at idle (reduced) speed for a selectable time period (0–10 minutes) during warm-up. The controller will override the idle speed mode if the engine reaches the preprogrammed engine warmed-up temperature before the idle mode times out. See Figure 11-8 for user-supplied switch connection.




Figure 11-8 Idle (Speed) Mode Switch

11.1.6 Low Fuel (Level/Pressure) Switch

Some gaseous-fueled models offer a low fuel pressure switch. The low fuel pressure switch connects to the same terminal as the low fuel *level* switch on diesel- or gasoline-fueled models. See Figure 11-9 and Figure 11-10. See Section 11.2, Accessory Connections, for terminal identification.

Note: The main tank or the transfer/day tank includes the low fuel level switch. The fuel tank supplier typically provides the low fuel level switch.




Figure 11-9 Low Fuel Switch (Level or Pressure)

Switch Rating	12 volts DC minimum, 0.5 amp minimum
Wiring Recommendation	
Gauge	mm (ft.)
18–20	30.5 (100)
14	153 (500)
10	305 (1000)

Figure 11-10 Switch Rating & Wiring Recommendation

11.1.7 Prime Power Switch Kit

The prime power switch kit prevents battery drain during generator set nonoperation periods and when the generator set battery cannot be maintained by an AC battery charger. See Figure 11-11 for an illustration of the kit and Figure 11-12 for the electrical connections.




Figure 11-11 Prime Power Switch Installation Location




Figure 11-12 Prime Power Switch Connections

Stop the generator set using the stopping procedures in the respective operation manual before placing the generator set in the prime power mode. Move the prime power switch located on the back of the controller to the *DOWN* position. The controller including the digital display, LEDs, and alarm horn does not function when the generator set is in the prime power mode.

Move the prime power switch located on the back of the controller to the *UP* position and reset the controller time and date before attempting to start the generator set.

11.1.8 Remote Emergency Stop Kit

The emergency stop kit allows immediate shutdown of the generator set from a remote location. See Figure 11-13 and Figure 11-14. If the emergency stop switch activates, the EMERGENCY STOP lamp lights and the unit shuts down. Before attempting to restart the generator set, reset the emergency stop switch (by replacing the glass piece) and reset the generator set by placing the master switch in the OFF/RESET position.

Use the single glass piece located inside the switch for replacement and order additional glass pieces as service parts. See the respective operation manual for the Emergency Stop Switch Reset Procedure. See Section 11.2, Accessory Connections, for terminal identifications.




Figure 11-13 Emergency Stop Kit




Figure 11-14 Remote Emergency Stop Kit Connections

11.1.9 Remote Reset Feature

The remote reset switch provides generator set resetting after a fault shutdown at a remote location. See Figure 11-15 and Figure 11-16 for user-supplied switch connection.

Press and hold the switch for 2–3 seconds and release to reset the generator set controller.




Figure 11-15 Remote Reset Switch Connections

Switch Rating	12 volts DC minimum, 1 amp minimum
Wiring Recommendation	
Gauge	mm (ft.)
18–20	30.5 (100)
14	153 (500)
10	305 (1000)

Figure 11-16 Switch Rating and Wiring Recommendations

11.1.10 Remote Serial Annunciator (RSA III)

Adapted from Instruction TT-1625 9/14b.

The following information summarizes the setup items when installing the remote serial annunciator. Refer to the RSA installation instructions TT-1625 for operation and function.

RSA III Features and Connections

RSA III is an annunciator panel offered in several kit configurations to support Kohler power equipment. The RSA III is a remote serial annunciator that monitors the condition of the generator set and/or ATS from a remote location. The RSA III alerts the operator through visual and audible signals using LED indication and a horn. An alarm silence and lamp test switch are included.

An RSA III annunciator can be used for a single generator set (Figure 11-17) or with a combination of a generator set and automatic transfer switch(es) (Figure 11-18 or Figure 11-19). In systems using more than a single RSA III, one must be designated as the master device to broadcast to additional RSA III annunciators, designated as slave devices. Up to five RSA III slave devices can be used with an RSA III master device. All RSA III annunciators are factory set as the master device, but can be changed to a slave device using a PC and SiteTech™ software that connects to the RSA III front panel via a universal serial bus (USB) connection.

The RSA II can be connected with the RSA III provided that the master remote annunciator is an RSA III.

The RSA III meets NFPA 110, Level 1 (2005) applications that require remote controls and alarms be powered by a storage battery such as the engine starting battery. AC adaptor kit GM62466-KP1 is available when NFPA is not required.

See Section 11.2, Accessory Connections, for terminal identifications.

A PC with SiteTech™ software is required to make the RSA III functional. Use your SecurID to access KOHLERnet, click on the TechTools button, and follow the instructions to download the files. See SiteTech™ Software Settings and refer to TP-6701 SiteTech™ Software Operation Manual for more information.

If a fault occurs, the RSA III horn activates and the corresponding LED illuminates. The following paragraphs describe specific features of the RSA III.

If the RSA III is used with an Ethernet communication network, order Modbus® Ethernet converter GM41143-KP2 and refer to TT-1405 Converters,

Modbus® is a registered trademark of Schneider Electric.

Connections, and Controller Setup for Network Communication for system installation.




Figure 11-17 Remote Serial Annunciator (RSA III)




Figure 11-18 RSA III with Single ATS Control




Figure 11-19 RSA III with Four ATS Controls

If there is only one RSA III, it is the master. If several RSA III are installed, choose either the RSA III closest to the generator set or determine which RSA III is more practical for use as a master and use a daisy chain wiring configuration for the remaining RSAs. The RSA III connected to the controller **MUST** be assigned as the RSA III master.

Note: When an RSA III is installed into a system with existing older RSAs, the RSA III must be configured as the master.

Note: Should any communication issues occur when adding RSA III slaves and/or transfer switches to the system, be sure to power down the RSA III master and then power up the RSA III master so that the RSA III master can recognize the changes.

Use the SiteTech™ software to select either that the generator set controller activates EPS Supplying Load LED or the transfer switch activates LED or local EPS supplying load.

Use the SiteTech™ software to select the high speed mode for direct connection to the DEC 6000 controller. Select lower speed for network connection with the Modbus®/ Ethernet converter. The lower speed allows network functionality reducing loss of communication faults.

Terminating Resistor and Wiring

For communication between the controller and RSA III master, see Figure 11-20. For communication between RSA III Master and RSA III Slave, see Figure 11-21. Place the terminating resistor on the last RSA III slave in the daisy chain connection.

Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.

P27 RS-485 Connections (from Controller to Master)	
P27-1	(-) Black (from controller)
P27-2	(+) White (from controller)
P27-3	Shield (from controller)
P27-4	(-) Black (to slave or terminating resistor)
P27-5	(+) White (to slave or terminating resistor)
P27-6	Shield (to slave or open)
Note: When using RS-485 communication cable, connect the “shield” wire at either end but not at both ends.	

Figure 11-20 P27 Connector on Master RSA III

Communication between RSA III Master and RSA III Slave. Select and connect the RS-485 wiring from the RSA III master to the RSA III slave(s) in a daisy chain NO TAGwiring configuration using Belden #9841 or equivalent. Figure 11-21 shows the master/slave RS-485 connections and Figure 11-22 shows the RSA III with P27 location.

P27 RS-485 Connections (from Master to Slave)	
P27-1	(-) Black (from master or previous slave)
P27-2	(+) White (from master or previous slave)
P27-3	Shield (from master or previous slave)
P27-4	(-) Black (to next slave or terminating resistor)
P27-5	(+) White (to next slave or terminating resistor)
P27-6	Shield (to next slave or open)

Note: When using RS-485 communication cable, connect the "shield" wire at either end but not at both ends.

Figure 11-21 P27 Connection on RSA III Slave




Figure 11-22 RSA III Circuit Board GM86125 Connectors

11.1.11 Shunt-Trip Line Circuit Breaker

A shunt-trip line circuit breaker provides a 12- or 24-DC volt solenoid within the line circuit breaker case that can energize the trip mechanism. This feature allows the circuit breaker to be tripped by a customer-selected fault such as alternator overload, overspeed, overvoltage, or defined common fault. Connection requires a shunt-trip wiring kit and a dry contact kit. See Figure 11-23.




Figure 11-23 Shunt-Trip Line Circuit Breaker and Shunt-Trip Wiring Kit Connections

11.1.12 Single-Relay Dry Contact Kit

The single-relay dry contact kit provides normally open and normally closed contacts in a form C configuration to activate warning devices and other user- provided accessories allowing remote monitoring of the generator set. Typically, lamps, audible alarms, or other devices signal faults or status conditions. Connect any controller fault output to the single-relay dry contact kit.

A total of three dry contact kits may connect to a single controller output. See Figure 11-24 and Figure 11-25. See Section 11.2, Accessory Connections, for terminal identifications.

11.1.13 Ten-Relay Dry Contact Kit

The ten-relay dry contact kit provides normally open and normally closed contacts in a form C configuration to activate warning devices and other user-provided accessories allowing remote monitoring of the generator set. Connect any controller fault output to the ten-relay dry contact kit. Typically, lamps, audible alarms, or other devices signal the fault conditions.

Refer to Figure 11-26 for an internal view of the contact kit. See Figure 11-27 for electrical connections. See Section 11.2, Accessory Connections, for terminal identifications.




Figure 11-24 Single-Relay Dry Contact Kit, Typical




Figure 11-25 Single-Relay Dry Contact Kit Connections




Figure 11-26 Ten-Relay Dry Contact Kit




Figure 11-27 Ten-Relay Dry Contact Kit Connections

11.1.14 Twenty-Relay Dry Contact Kit

The twenty-relay dry contact kit provides normally open and normally closed contacts in a form C configuration to activate warning devices and other user-provided accessories allowing remote monitoring of the generator set. Typically, lamps, audible alarms, or other devices signal faults or status conditions. Connect any generator set fault output to the dry contact kit.

Refer to Figure 11-28 for an internal view of the contact kit. See Figure 11-29 for electrical connections. See Section 11.2, Accessory Connections, for terminal identifications.




Figure 11-28 Twenty-Relay Dry Contact Kits




Figure 11-29 Twenty-Relay Dry Contact Relay Kit Connections

11.2 Accessory Connections

The controller contains circuit boards equipped with terminal strip(s) for use in connecting accessories. Connect accessories to either the controller customer connection terminal strip or a dry contact kit. Connect the dry contact kit(s) to the controller customer connection terminal strip. Connect alarms, battery chargers, remote switches, and other accessories to the dry contact kit relay(s).

For specific information on accessory connections, refer to the accessory wiring diagrams in the wiring diagram manual and the instruction sheet accompanying the kit. See Figure 11-30 and Figure 11-31 for controller interconnection circuit board connections. See Figure 11-32 and Figure 11-33 for controller (customer) connection terminal strip connections. See Appendix G, Wiring Diagrams for accessory connection wiring diagrams.




Figure 11-30 Terminal Strips on Controller Interconnection Circuit Board (Controller Back Panel Folded Down)

TB1 Terminal Strip—Engine Start and Emergency Stop Connections**Term. Description**

- 1 Remote start (3)
- 2 Remote start (4)
- 3 Emergency stop ground (1)
- 4 Emergency stop (1A)

TB2 Terminal Strip—Analog Input Connections**Term. Description**

- 1 ACH1 Signal
- 2 ACH1 Supply
- 3 ACH2 Signal
- 4 ACH2 Supply
- 5 ACH3 Signal
- 6 ACH3 Supply
- 7 ACH4 Signal
- 8 ACH4 Supply
- 9 ACH5 Signal
- 10 ACH5 Supply
- 11 ACH6 Signal
- 12 ACH6 Supply
- 13 ACH7 Signal (optional analog voltage adjust signal)
- 14 ACH7 Supply
- 15 N/C
- 16 ACH1 Return
- 17 ACH1 Shield ground
- 18 ACH2 Return
- 19 ACH2 Shield ground
- 20 ACH3 Return
- 21 ACH3 Shield ground
- 22 ACH4 Return
- 23 ACH4 Shield ground
- 24 ACH5 Return
- 25 ACH5 Shield ground
- 26 ACH6 Return
- 27 ACH6 Shield ground
- 28 ACH7 Return
- 29 ACH7 Shield ground
- 30 N/C

TB3 Terminal Strip—Accessory Power Output Connections**Term. Description**

- 1 +12 VDC (OEM use only)
- 2 +12 VDC (OEM use only)
- 3 +12 VDC (OEM use only)
- 4 Fused battery (+) (42A) (5 amp)
- 5 Fused battery (+) (42A) (5 amp)
- 6 Fused battery (+) (42A) (5 amp)
- 7 Battery (-)
- 8 Battery (-)
- 9 Battery (-)
- 10 Battery (-)
- 11 Battery (-)
- 12 Panel lamp output

TB4 Terminal Strip—Input Factory Connections**Term. Description**

- 1 DCH1 Battery charger fault
- 2 DCH2 Low fuel
- 3 DCH3 Low coolant temp. with ECM models or warning default with non-ECM models
- 4 DCH4 Field over voltage with M4/M5/M7/M10 alternators or warning default with non-M4/M5/M7/M10 alternators
- 5 DCH5 Breaker closed, paralleling applications
- 6 DCH6 VAR/PF
- 7 DCH7 Base load mode
- 8 DCH8 I/E mode
- 9 DCH9 Low fuel shutdown (GM only)
- 10 DCH10 Load enable
- 11 DCH11 Synch auto, paralleling applications
- 12 DCH12 Synch permissive, paralleling applications
- 13 DCH13 Synch check test
- 14 DCH14 Low coolant level
- 15 DCH15 Remote shutdown
- 16 DCH16 Remote reset
- 17 DCH17 Voltage lower
- 18 DCH18 Voltage raise
- 19 DCH19 Speed lower
- 20 DCH20 Speed raise
- 21 DCH21 Breaker tripped
- 22 DCH1 Return
- 23 DCH2 Return
- 24 DCH3 Return
- 25 DCH4 Return
- 26 DCH5 Return
- 27 DCH6 Return
- 28 DCH7 Return
- 29 DCH8 Return
- 30 DCH9 Return
- 31 DCH10 Return
- 32 DCH11 Return
- 33 DCH12 Return
- 34 DCH13 Return
- 35 DCH14 Return
- 36 DCH15 Return
- 37 DCH16 Return
- 38 DCH17 Return
- 39 DCH18 Return
- 40 DCH19 Return
- 41 DCH20 Return
- 42 DCH21 Return

Note: TB4-1 through TB4-21 are user definable with factory defaults listed. Terminals TB4-3 and TB4-4 have different functions depending upon the generator set configuration. See comments above. See Menu 9—Input Setup for changing inputs.

Figure 11-31 Controller Terminal Strip Identification




Figure 11-32 Terminal Strips TB6, TB7, TB8, and TB9 on the Controller Customer Connection Terminal Strip

TB6 Terminal Strip—RDOs 1-7

Term.	Description
42A	Battery (+)
GND	Battery (-)
N/C	
RDO1	System ready (lead 60)
RDO2	Emergency stop (lead 48)
RDO3	Defined common fault (lead 32A)
RDO4	Time delay engine cooldown (TDEC) (lead 70C)
RDO5	Low fuel (lead 63)
RDO6	High coolant temperature warning (lead 40)
RDO7	Low coolant temperature warning (lead 35)

TB7 Terminal Strip—RDOs 8-17

Term.	Description
RDO8	Low coolant level
RDO9	Low oil pressure warning (lead 41)
RDO10	NFPA 110 common alarm faults (lead 32)*
RDO11	Low battery voltage (lead 62)
RDO12	Battery charger fault (lead 61)
RDO13	Maintenance due
RDO14	Over current
RDO15	Delay engine start
RDO16	Starting aid
RDO17	Ground fault

TB8 Terminal Strip—RDOs 18-23

Term.	Description
42A	Battery (+)
42A	Battery (+)
GND	Battery (-)
GND	Battery (-)
RDO18	EPS supplying load
RDO19	Alternator protection shutdown
RDO20	Engine derate active
RDO21	Key switch locked
RDO22	Generator running (lead 70R)
RDO23	Master switch not in auto (lead 80)

TB9 Terminal Strip—RDOs 24-31

Term.	Description
RDO24	Defined common warning
RDO25	Common load shed
RDO26	Missing PGEN node
RDO27	In synch
RDO28	Circuit breaker common fault
RDO29	Common protective relay output
RDO30	Close breaker
RDO31	Breaker trip
3	Remote start
4	Remote start

Note:Lead numbers shown in parentheses are the factory default wire designations.

Note:RDO-1 though RDO-31 are user definable with the following factory defaults: emergency stop, high coolant temperature, low oil pressure, overcrank, and overspeed

*NFPA-110 common alarm faults typically include:

Air damper indicator
 Battery charger fault (RDO-12)
 EPS supplying load (RDO-18)
 High battery voltage
 High coolant temperature warning (RDO-06)
 High coolant temperature shutdown
 Low battery voltage (RDO-11)
 Low coolant level (RDO-08)
 Low coolant temperature warning (RDO-07)
 Low fuel (level or pressure) (RDO-05)
 Low oil pressure warning (RDO-09)
 Low oil pressure shutdown
 Master switch not in auto (RDO-23)
 Overcrank
 Overspeed

Figure 11-33 Controller Customer Connection Terminal Strip Identification with Relay Driver Outputs (RDOs)


Section 12 Remote Adjustment/Control Systems

This section provides information about changes and adjustments when the system involves remote starting/control systems, voltage regulation, and paralleling generator set applications. Use the respective switchgear literature as supplied with the unit. Some of the items mentioned are available generator set accessories.

Before installing the generator set, provide for electrical connections through conduit to the transfer switch and other accessories for the generator set. Carefully install the selected generator set accessories. Route wiring to the generator set through flexible connections. Comply with all applicable codes when installing a wiring system.

See Section 7, Electrical System for additional wiring information.

**WARNING**



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

(Decision-Maker® 3+ and 550 Controllers)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(Decision-Maker® 3000, 3500, and 6000 Controllers)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) If the controller is not already in the MAN (manual) mode, press the Controller Mode button and then press the MAN mode button. (2) If the generator set is running, press and hold the Manual-Stop button for at least 2 seconds to stop the generator set. (3) Press the Controller Mode button and then press the controller Off mode button. (4) Disconnect the power to the battery charger, if equipped. (5) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(Decision-Maker® 8000 Controller)

**WARNING**



Hazardous voltage. Moving parts.
Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

12.1 Automatic Transfer Switches

A typical standby system has at least one automatic transfer switch connected to the generator set output to automatically transfer the electrical load to the generator set if the normal source fails. When normal power returns, the switch transfers the load back to the normal power source and then signals the generator set to stop.

The transfer switch uses a set of contacts to signal the engine/generator to start. When the normal source fails and the generator set master switch is in the AUTO position, the transfer switch contacts close to start the generator set.

The engine start terminals are usually located near the transfer switch contactor with an engine start decal identifying the terminals. Refer to the transfer switch decal, operation/installation manual, or wiring diagram manual to identify the engine start terminals prior to making connections.

Make connections to the transfer switch engine-start terminals and remote manual engine-start switch using wire run through conduit. Use separate conduits for engine-start leads, generator set load cables, battery charger leads, and remote annunciator wiring.

Use a minimum of 13 mm (0.5 in.) spacing between the conduit bushing and any uninsulated live parts in the ATS enclosure. All conduit openings in the ATS enclosure must be made such that no metal particles including drill chips contaminate the components in the ATS enclosure.

12.2 Decision-Maker® 550 Controller, Voltage Regulator and Paralleling Applications

The controller has a voltage regulation function that is internal to the processor.

See the Decision-Maker® 550 Controller Operation Manual for further details regarding voltage adjustment and paralleling operation setup.

12.3 Decision-Maker® 3000 Controller Voltage Regulator

The controller has a voltage regulation function that is internal to the processor.

See the Decision-Maker® 3000 Controller and SiteTech™ Operation Manuals for further details regarding voltage adjustment setup.

12.4 Decision-Maker® 3500 Controller Voltage Regulator

The controller has a voltage regulation function that is internal to the processor.

See the Decision-Maker® 3500 Controller and SiteTech™ Operation Manuals for further details regarding voltage adjustment setup.

12.5 Decision-Maker® 6000 Controller Voltage Regulator and Paralleling Applications

The controller has a voltage regulation function that is internal to the processor.

See the Decision-Maker® 6000 Controller, Decision-Maker® Paralleling (DPS), and SiteTech™

Operation Manuals for further details regarding voltage adjustment and paralleling operation setup.

12.6 Decision-Maker® 8000 Controller Voltage Regulator and Paralleling Applications

The generator set uses a Marathon® DVR® 2000EC voltage regulator.

See the Decision-Maker® 8000 Controller Operation Manual and TP-5579 Operation Manual, DVR® 2000 Voltage Regulator for further details regarding voltage adjustment and paralleling operation setup.

12.7 Remote Speed Adjustment

This kit provides remote engine speed adjustments with an approximate range of $\pm 5\%$ at 1800 rpm. This kit requires a generator set with an electronic governor. See Figure 12-1 and Figure 12-2.




Figure 12-1 Remote Speed Adjusting Control Wiring Diagram




Figure 12-2 Remote Speed Potentiometer Installation

To program the 550 controller, MDEC-equipped DDC/MTU engines only, use the following instructions. See the 550 controller operation manual for further information, if necessary.

1. Go to Menu 14—PROGRAMMING MODE to enable LOCAL programming.
2. Go to Menu 7—GENERATOR SYSTEM.
3. Press MENU Down ↓ Key to access ENABLE VSG (variable governor speed) data.
4. Press the YES Key.
5. Press the ENTER ← Key to confirm entry.
6. Verify ENABLE VSG code YES appears on the display.
7. Go to Menu 14—PROGRAMMING MODE to change to programming mode OFF.

12.8 Remote Voltage Adjustment

This kit provides the ability to fine adjust the generator output voltage from a remote location. The maximum recommended wire length from the potentiometer to the generator set is 15 ft. (4.6 m); 18-gauge twisted pair wire is recommended. See Figure 12-3 and Figure 12-4.




Figure 12-3 Potentiometer Installation




Figure 12-4 Disconnection of Controller Voltage Adjusting Potentiometer

12.9 Remote Wiring

Figure 12-5 is the accessory interconnection diagram showing the remote wiring for the 550 controller.




Figure 12-5 550 Controller Remote Wiring

12.10 Voltage Regulator DVR 2000/ Remote Voltage Regulator Kit, 350 kW and Above

The DVR® 2000E is used with nonparalleling applications and the DVR® 2000EC is used when paralleling is required.

If the voltage configuration is changed, make adjustments to the DVR® 2000 voltage regulator at the voltage regulator. Remove the junction box cover to adjust the DVR® 2000 voltage regulator. See Figure 12-6, Figure 12-7, and TP-5579 Operation Manual, DVR® 2000 Voltage Regulator for more information.

Use Figure 12-7 for installation and troubleshooting of the electrical wiring system.





Figure 12-6 DVR® 2000 Voltage Regulator Mounting Location



GM20500-

Figure 12-7 DVR® 2000 Voltage Regulator/Alternator Interconnection Wiring Diagram

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

A, amp	ampere	cfm	cubic feet per minute	exh.	exhaust
ABDC	after bottom dead center	CG	center of gravity	ext.	external
AC	alternating current	CID	cubic inch displacement	F	Fahrenheit, female
A/D	analog to digital	CL	centerline	FHM	flat head machine (screw)
ADC	advanced digital control; analog to digital converter	cm	centimeter	fl. oz.	fluid ounce
adj.	adjust, adjustment	CMOS	complementary metal oxide substrate (semiconductor)	flex.	flexible
ADV	advertising dimensional drawing	com	communications (port)	freq.	frequency
Ah	amp-hour	coml	commercial	FS	full scale
AHWT	anticipatory high water temperature	Coml/Rec	Commercial/Recreational	ft.	foot, feet
AISI	American Iron and Steel Institute	conn.	connection	ft. lb.	foot pounds (torque)
ALOP	anticipatory low oil pressure	cont.	continued	ft./min.	feet per minute
alt.	alternator	CPVC	chlorinated polyvinyl chloride	ftp	file transfer protocol
Al	aluminum	crit.	critical	g	gram
ANSI	American National Standards Institute (formerly American Standards Association, ASA)	CSA	Canadian Standards Association	ga.	gauge (meters, wire size)
AO	anticipatory only	CT	current transformer	gal.	gallon
APDC	Air Pollution Control District	Cu	copper	gen.	generator
API	American Petroleum Institute	cUL	Canadian Underwriter's Laboratories	genset	generator set
approx.	approximate, approximately	CUL	Canadian Underwriter's Laboratories	GFI	ground fault interrupter
APU	Auxiliary Power Unit	cu. in.	cubic inch	GND, ⊕	ground
AQMD	Air Quality Management District	cw.	clockwise	gov.	governor
AR	as required, as requested	CWC	city water-cooled	gph	gallons per hour
AS	as supplied, as stated, as suggested	cyl.	cylinder	gpm	gallons per minute
ASE	American Society of Engineers	D/A	digital to analog	gr.	grade, gross
ASME	American Society of Mechanical Engineers	DAC	digital to analog converter	GRD	equipment ground
assy.	assembly	dB	decibel	gr. wt.	gross weight
ASTM	American Society for Testing Materials	dB(A)	decibel (A weighted)	H x W x D	height by width by depth
ATDC	after top dead center	DC	direct current	HC	hex cap
ATS	automatic transfer switch	DCR	direct current resistance	HCHT	high cylinder head temperature
auto.	automatic	deg., °	degree	HD	heavy duty
aux.	auxiliary	dept.	department	HET	high exhaust temp., high engine temp.
avg.	average	dia.	diameter	hex	hexagon
AVR	automatic voltage regulator	DI/EO	dual inlet/end outlet	Hg	mercury (element)
AWG	American Wire Gauge	DIN	Deutsches Institut für Normung e. V. (also Deutsche Industrie Normenausschuss)	HH	hex head
AWM	appliance wiring material	DIP	dual inline package	HHC	hex head cap
bat.	battery	DPDT	double-pole, double-throw	HP	horsepower
BBDC	before bottom dead center	DPST	double-pole, single-throw	hr.	hour
BC	battery charger, battery charging	DS	disconnect switch	HS	heat shrink
BCA	battery charging alternator	DVR	digital voltage regulator	hsg.	housing
BCI	Battery Council International	E ² PROM, EEPROM	electrically-erasable programmable read-only memory	HVAC	heating, ventilation, and air conditioning
BDC	before dead center	E, emer.	emergency (power source)	HWT	high water temperature
BHP	brake horsepower	ECM	electronic control module, engine control module	Hz	hertz (cycles per second)
blk.	black (paint color), block (engine)	EDI	electronic data interchange	IBC	International Building Code
blk. htr.	block heater	EFR	emergency frequency relay	IC	integrated circuit
BMEP	brake mean effective pressure	e.g.	for example (<i>exempli gratia</i>)	ID	inside diameter, identification
bps	bits per second	EG	electronic governor	IEC	International Electrotechnical Commission
br.	brass	EGSA	Electrical Generating Systems Association	IEEE	Institute of Electrical and Electronics Engineers
BTDC	before top dead center	EIA	Electronic Industries Association	IMS	improved motor starting
Btu	British thermal unit	EI/EO	end inlet/end outlet	in.	inch
Btu/min.	British thermal units per minute	EMI	electromagnetic interference	in. H ₂ O	inches of water
C	Celsius, centigrade	emiss.	emission	in. Hg	inches of mercury
cal.	calorie	eng.	engine	in. lb.	inch pounds
CAN	controller area network	EPA	Environmental Protection Agency	Inc.	incorporated
CARB	California Air Resources Board	EPS	emergency power system	ind.	industrial
CAT5	Category 5 (network cable)	ER	emergency relay	int.	internal
CB	circuit breaker	ES	engineering special, engineered special	int./ext.	internal/external
CC	crank cycle	ESD	electrostatic discharge	I/O	input/output
cc	cubic centimeter	est.	estimated	IP	internet protocol
CCA	cold cranking amps	E-Stop	emergency stop	ISO	International Organization for Standardization
ccw.	counterclockwise	etc.	et cetera (and so forth)	J	joule
CEC	Canadian Electrical Code			JIS	Japanese Industry Standard
cert.	certificate, certification, certified			k	kilo (1000)
cfh	cubic feet per hour			K	kelvin
				kA	kiloampere
				KB	kilobyte (2 ¹⁰ bytes)
				KBus	Kohler communication protocol
				kg	kilogram

kg/cm ²	kilograms per square centimeter	NBS	National Bureau of Standards	RTU	remote terminal unit
kgm	kilogram-meter	NC	normally closed	RTV	room temperature vulcanization
kg/m ³	kilograms per cubic meter	NEC	National Electrical Code	RW	read/write
kHz	kilohertz	NEMA	National Electrical Manufacturers Association	SAE	Society of Automotive Engineers
kJ	kilojoule	NFPA	National Fire Protection Association	scfm	standard cubic feet per minute
km	kilometer	Nm	newton meter	SCR	silicon controlled rectifier
kOhm, kΩ	kilo-ohm	NO	normally open	s, sec.	second
kPa	kilopascal	no., nos.	number, numbers	SI	<i>Système international d'unités</i> , International System of Units
kph	kilometers per hour	NPS	National Pipe, Straight	SI/EO	side in/end out
kV	kilovolt	NPSC	National Pipe, Straight-coupling	sil.	silencer
kVA	kilovolt ampere	NPT	National Standard taper pipe thread per general use	SMTP	simple mail transfer protocol
kVAR	kilovolt ampere reactive	NPTF	National Pipe, Taper-Fine	SN	serial number
kW	kilowatt	NR	not required, normal relay	SNMP	simple network management protocol
kWh	kilowatt-hour	ns	nanosecond	SPDT	single-pole, double-throw
kWm	kilowatt mechanical	OC	overcrank	SPST	single-pole, single-throw
kWth	kilowatt-thermal	OD	outside diameter	spec	specification
L	liter	OEM	original equipment manufacturer	specs	specification(s)
LAN	local area network	OF	overfrequency	sq.	square
L x W x H	length by width by height	opt.	option, optional	sq. cm	square centimeter
lb.	pound, pounds	OS	oversize, overspeed	sq. in.	square inch
lbm/ft ³	pounds mass per cubic feet	OSHA	Occupational Safety and Health Administration	SMS	short message service
LCB	line circuit breaker	OV	overvoltage	SS	stainless steel
LCD	liquid crystal display	oz.	ounce	std.	standard
LED	light emitting diode	p., pp.	page, pages	stl.	steel
Lph	liters per hour	PC	personal computer	tach.	tachometer
Lpm	liters per minute	PCB	printed circuit board	TB	terminal block
LOP	low oil pressure	pF	picofarad	TCP	transmission control protocol
LP	liquefied petroleum	PF	power factor	TD	time delay
LPG	liquefied petroleum gas	ph., ∅	phase	TDC	top dead center
LS	left side	PHC	Phillips® head Crimptite® (screw)	TDEC	time delay engine cooldown
L _{wa}	sound power level, A weighted	PHH	Phillips® hex head (screw)	TDEN	time delay emergency to normal
LWL	low water level	PHM	pan head machine (screw)	TDES	time delay engine start
LWT	low water temperature	PLC	programmable logic control	TDNE	time delay normal to emergency
m	meter, milli (1/1000)	PMG	permanent magnet generator	TDOE	time delay off to emergency
M	mega (10 ⁶ when used with SI units), male	pot	potentiometer, potential	TDON	time delay off to normal
m ³	cubic meter	ppm	parts per million	temp.	temperature
m ³ /hr.	cubic meters per hour	PROM	programmable read-only memory	term.	terminal
m ³ /min.	cubic meters per minute	psi	pounds per square inch	THD	total harmonic distortion
mA	milliampere	psig	pounds per square inch gauge	TIF	telephone influence factor
man.	manual	pt.	pint	tol.	tolerance
max.	maximum	PTC	positive temperature coefficient	turbo.	turbocharger
MB	megabyte (2 ²⁰ bytes)	PTO	power takeoff	typ.	typical (same in multiple locations)
MCCB	molded-case circuit breaker	PVC	polyvinyl chloride	UF	underfrequency
MCM	one thousand circular mils	qt.	quart, quarts	UHF	ultrahigh frequency
meggar	megohmmeter	qty.	quantity	UIF	user interface
MHz	megahertz	R	replacement (emergency)	UL	Underwriter's Laboratories, Inc.
mi.	mile	rad.	power source	UNC	unified coarse thread (was NC)
mil	one one-thousandth of an inch	RAM	radiator, radius	UNF	unified fine thread (was NF)
min.	minimum, minute	RDO	random access memory	univ.	universal
misc.	miscellaneous	ref.	relay driver output	URL	uniform resource locator (web address)
MJ	megajoule	rem.	reference	US	undersize, underspeed
mJ	millijoule	Res/Coml	remote	UV	ultraviolet, undervoltage
mm	millimeter	RFI	Residential/Commercial radio frequency interference	V	volt
mOhm, mΩ	milliohm	RH	round head	VAC	volts alternating current
MOhm, MΩ	megohm	RHM	round head machine (screw)	VAR	voltampere reactive
MOV	metal oxide varistor	rly.	relay	VDC	volts direct current
MPa	megapascal	rms	root mean square	VFD	vacuum fluorescent display
mpg	miles per gallon	rnd.	round	VGA	video graphics adapter
mph	miles per hour	RO	read only	VHF	very high frequency
MS	military standard	ROM	read only memory	W	watt
ms	millisecond	rot.	rotate, rotating	WCR	withstand and closing rating
m/sec.	meters per second	rpm	revolutions per minute	w/	with
mtg.	mounting	RS	right side	WO	write only
MTU	Motoren-und Turbinen-Union	RTDs	Resistance Temperature Detectors	w/o	without
MW	megawatt			wt.	weight
mW	milliwatt			xfrm	transformer
μF	microfarad				
N, norm.	normal (power source)				
NA	not available, not applicable				
nat. gas	natural gas				

Appendix B Common Hardware Application Guidelines

Use the information below and on the following pages to identify proper fastening techniques when no specific reference for reassembly is made.

Bolt/Screw Length: When bolt/screw length is not given, use Figure 1 as a guide. As a general rule, a minimum length of one thread beyond the nut and a maximum length of 1/2 the bolt/screw diameter beyond the nut is the preferred method.

Washers and Nuts: Use split lock washers as a bolt locking device where specified. Use SAE flat washers with whiz nuts, spiralock nuts, or standard nuts and preloading (torque) of the bolt in all other applications.

See Appendix C, General Torque Specifications, and other torque specifications in the service literature.




Figure 1 Acceptable Bolt Lengths

Steps for common hardware application:

1. Determine entry hole type: round or slotted.
2. Determine exit hole type: fixed female thread (weld nut), round, or slotted.

For round and slotted exit holes, determine if hardware is greater than 1/2 inch in diameter, or 1/2 inch in diameter or less. Hardware that is *greater than 1/2 inch* in diameter takes a standard nut and SAE washer. Hardware *1/2 inch or less* in diameter can take a properly torqued whiz nut or spiralock nut. See Figure 2.

3. Follow these SAE washer rules after determining exit hole type:
 - a. Always use a washer between hardware and a slot.
 - b. Always use a washer under a nut (see 2 above for exception).
 - c. Use a washer under a bolt when the female thread is fixed (weld nut).
4. Refer to Figure 2, which depicts the preceding hardware configuration possibilities.




Figure 2 Acceptable Hardware Combinations

Appendix C General Torque Specifications

American Standard Fasteners Torque Specifications					
Size	Torque Measurement	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 2 or 5
		Grade 2	Grade 5	Grade 8	
8-32	Nm (in. lb.)	1.8 (16)	2.3 (20)	—	See Note 3
10-24	Nm (in. lb.)	2.9 (26)	3.6 (32)	—	
10-32	Nm (in. lb.)	2.9 (26)	3.6 (32)	—	
1/4-20	Nm (in. lb.)	6.8 (60)	10.8 (96)	14.9 (132)	
1/4-28	Nm (in. lb.)	8.1 (72)	12.2 (108)	16.3 (144)	
5/16-18	Nm (in. lb.)	13.6 (120)	21.7 (192)	29.8 (264)	
5/16-24	Nm (in. lb.)	14.9 (132)	23.1 (204)	32.5 (288)	
3/8-16	Nm (ft. lb.)	24 (18)	38 (28)	53 (39)	
3/8-24	Nm (ft. lb.)	27 (20)	42 (31)	60 (44)	
7/16-14	Nm (ft. lb.)	39 (29)	60 (44)	85 (63)	
7/16-20	Nm (ft. lb.)	43 (32)	68 (50)	95 (70)	
1/2-13	Nm (ft. lb.)	60 (44)	92 (68)	130 (96)	
1/2-20	Nm (ft. lb.)	66 (49)	103 (76)	146 (108)	
9/16-12	Nm (ft. lb.)	81 (60)	133 (98)	187 (138)	
9/16-18	Nm (ft. lb.)	91 (67)	148 (109)	209 (154)	
5/8-11	Nm (ft. lb.)	113 (83)	183 (135)	259 (191)	
5/8-18	Nm (ft. lb.)	128 (94)	208 (153)	293 (216)	
3/4-10	Nm (ft. lb.)	199 (147)	325 (240)	458 (338)	
3/4-16	Nm (ft. lb.)	222 (164)	363 (268)	513 (378)	
1-8	Nm (ft. lb.)	259 (191)	721 (532)	1109 (818)	
1-12	Nm (ft. lb.)	283 (209)	789 (582)	1214 (895)	

Metric Fasteners Torque Specifications, Measured in Nm (ft. lb.)				
Size (mm)	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 5.8 or 8.8
	Grade 5.8	Grade 8.8	Grade 10.9	
M6 x 1.00	6.2 (4.6)	9.5 (7)	13.6 (10)	See Note 3
M8 x 1.25	15 (11)	23 (17)	33 (24)	
M8 x 1.00	16 (11)	24 (18)	34 (25)	
M10 x 1.50	30 (22)	45 (34)	65 (48)	
M10 x 1.25	31 (23)	47 (35)	68 (50)	
M12 x 1.75	53 (39)	80 (59)	115 (85)	
M12 x 1.50	56 (41)	85 (63)	122 (90)	
M14 x 2.00	83 (61)	126 (93)	180 (133)	
M14 x 1.50	87 (64)	133 (98)	190 (140)	
M16 x 2.00	127 (94)	194 (143)	278 (205)	
M16 x 1.50	132 (97)	201 (148)	287 (212)	
M18 x 2.50	179 (132)	273 (201)	390 (288)	
M18 x 1.50	189 (140)	289 (213)	413 (305)	
M20 x 2.50	245 (181)	374 (276)	535 (395)	
M20 x 1.50	264 (195)	402 (297)	576 (425)	
M22 x 2.50	332 (245)	507 (374)	725 (535)	
M22 x 1.50	351 (259)	535 (395)	766 (565)	
M24 x 3.00	425 (314)	649 (479)	928 (685)	
M24 x 2.00	447 (330)	682 (503)	976 (720)	
M27 x 3.00	—	937 (692)	1341 (990)	
M27 x 2.00	—	985 (727)	1409 (1040)	
M30 x 3.50	—	1278 (943)	1829 (1350)	
M30 x 2.00	—	1349 (996)	1931 (1425)	

Notes:

1. The torque values above are general guidelines. Always use the torque values specified in the service manuals and/or assembly drawings when they differ from the above torque values.
2. The torque values above are based on new plated threads. Increase torque values by 15% if non-plated threads are used.
3. Hardware threaded into aluminum must have either two diameters of thread engagement or a 30% or more reduction in the torque to prevent stripped threads.
4. Torque values are calculated as equivalent stress loading on American hardware with an approximate preload of 90% of the yield strength and a friction coefficient of 0.125.

Appendix D Fuel Physical Properties

Physical Property @ 15°C (60°F)	Butane	Propane	Natural Gas	Manufactured or Sewage Gas	Gasoline	Diesel Fuel
Normal atmospheric state	Gas	Gas	Gas	Gas	Liquid	Liquid
Boiling point, Initial, °C (°F) End, °C (°F)	— 0 (32)	— 42 (-44)	— -162 (-259)	— —	36 (97) 216 (420)	177 (350) 357 (675)
Heating value, Btu /gal. (net, LHV*) /gal. (gross) /ft ³ (gas)	94670 102032 3264	83340 91500 2516	63310 — 1000	— — 600-700	116400 124600 6390	130300 139000 —
Density, Ft ³ of gas/gal.	31.26	36.39	57.75	—	19.5	—
Wt./gal. liquid, lb.	4.81	4.24	2.65	—	6.16	7.08
Octane Number Research Motor	94 90	110+ 97	110+ —	— —	80-100 75-90	— —
* Lower Heating Value						

Figure 3 Engine Fuels, Physical Properties

Characteristic, LP Gas*	Butane	Propane
Formula	C ₄ H ₁₀	C ₃ H ₈
Boiling point, °C (°F)	0 (32)	-42 (-44)
Specific gravity of gas (air = 1.00)	2.00	1.53
Specific gravity of liquid (water = 1.00)	0.58	0.51
Btu/lb. of gas	21221	21591
Ft. ³ of vapor at 16°C (60°F)/lb. of liquid at 16°C (60°F)	6.506	8.547
Latent heat of vaporization at boiling point, Btu/gal.	808.0	785.0
Combustion Data:		
Ft ³ air required to burn 1 ft. ³ of gas	31.02 N/A	23.86 -104 (-156)
Flash point, °C (°F)	482-538	493-549
Ignition temperature in air, °C (°F)	(900-1000)	(920-1020)
Max. flame temperature in air, °C (°F)	1991 (3615)	1979 (3595)
Limits of inflammability, percentage of gas in air mixture:		
At lower limit, %	1.9	2.4
At upper limit, %	8.6	9.6
Octane Number (ISO-Octane = 100)	92	Over 100
* Commercial quality. Figures shown in this chart represent average values.		

Figure 4 Additional LP Gas Characteristics

Appendix E Gas Fuel Vapor Pressures




Figure 1 Vapor Pressures of LP Gases Graph

Temperature, °C (°F)	Approximate Pressure, kg/cm ² (PSIG)			
	Propane	50/50 Mixture	Butane	
-40 (-40)	0.1 (1)	—	—	
-36 (-33)	0.4 (5)	—	—	
-28 (-20)	0.7 (10)	—	—	
-23 (-10)	1.2 (17)	0.2 (3)	—	
-18 (0)	1.7 (24)	0.4 (5)	—	
-12 (10)	2.2 (32)	0.6 (8)	—	
-7 (20)	3.0 (42)	0.9 (13)	—	
-1 (30)	3.7 (52)	1.3 (19)	—	
4 (40)	4.6 (65)	1.8 (26)	0.1 (2)	
10 (50)	5.5 (78)	2.4 (34)	0.5 (7)	
15 (60)	6.5 (93)	3.0 (42)	0.8 (12)	
21 (70)	7.7 (109)	3.5 (50)	1.2 (17)	
27 (80)	9.6 (136)	4.2 (60)	1.7 (24)	
32 (90)	10.3 (147)	5.1 (72)	2.2 (32)	
38 (100)	11.9 (169)	6.0 (85)	2.8 (40)	
43 (110)	14.1 (200)	7.0 (100)	3.5 (50)	

Figure 2 Vapor Pressures of LP Gases Table

Appendix F Gas Fuel System Installation Planning

Determining Propane Cylinder Quantity

Guide for Installing 100 lb. Cylinders

For continuous draws where temperatures may reach -18°C (0°F). Assume the vaporization rate of 100 lb. cylinder as approximately 50000 Btu/hr.

$$\text{Number of cylinders/side} = \frac{\text{Total load in Btu}}{50000}$$

Example:

Assume total load = 20000 Btu/hour.

$$\text{Cylinders/side} = \frac{20000}{50000} = 4 \text{ cylinders/side}$$

The chart in Figure 1 shows the vaporization rate of containers in terms of the temperature of the liquid and the wet surface area of the container. When the temperature is lower or if the container contains less liquid, the vaporization rate of the container is a lower value.

Lb. of Propane in Cyl.	Maximum Continuous Draw In Btu/Hour At Various Temperatures In °C (°F)				
	-18°C (0°F)	-7°C (20°F)	4°C (40°F)	16°C (60°F)	21°C (70°F)
100	113000	167000	214000	277000	300000
90	104000	152000	200000	247000	277000
80	94000	137000	180000	214000	236000
70	83000	122000	160000	199000	214000
60	75000	109000	140000	176000	192000
50	64000	94000	125000	154000	167000
40	55000	79000	105000	131000	141000
30	45000	66000	85000	107000	118000
20	36000	51000	68000	83000	92000
10	28000	38000	49000	60000	66000

Figure 1 Vaporization Rate, 100 lb. Propane Cylinders, Approximate

Determining Propane Vaporization Capacity

Guide for ASME LP Gas Storage Containers

% of Container Filled	K Equals	Propane* Vaporization Capacity at -18°C (0°F) in Btu/Hr.†
60	100	D x L x 100
50	90	D x L x 90
40	80	D x L x 80
30	70	D x L x 70
20	60	D x L x 60
10	45	D x L x 45

* These formulae allow for the temperature of the liquid to refrigerate to -29°C (-20°F), producing a temperature differential of -7°C (20°F) for the transfer of heat from the air to the container's *wetted* surface and then into the liquid. The vapor space area of the vessel is not considered since its effect is negligible.

† D=outside diameter in inches
L=overall length in inches
K=constant for percent volume of liquid in container.

Figure 2 Propane Vaporization Capacity

Vaporizing Capacities for Other Air Temperatures

Multiply the results obtained with the formulae in Figure 2 by one of the factors in the following table for the prevailing air temperature.

Prevailing Air Temperature	Multiplier
-26°C (-15°F)	0.25
-23°C (-10°F)	0.50
-21°C (-5°F)	0.75
-18°C (0°F)	1.00
-15°C (5°F)	1.25
-12°C (10°F)	1.50
-26°C (15°F)	1.75
-7°C (20°F)	2.00

Figure 3 Propane Vaporization Temperature

Notes

TP-5700 12/16t

Original Instructions (English)

© 2008, 2011, 2012, 2013, 2014, 2015, 2016 by Kohler Co. All rights reserved.

KOHLER® Power Systems

KOHLER CO. Kohler, Wisconsin 53044
Phone 920-457-4441, Fax 920-459-1646
For the nearest sales/service outlet in the
US and Canada, phone 1-800-544-2444
KOHLERPower.com

Kohler Power Systems
Asia Pacific Headquarters
7 Jurong Pier Road
Singapore 619159
Phone (65) 6264-6422, Fax (65) 6264-6455